




TOURING MODELS

2017 HARLEY-DAVIDSON® PARTS CATALOG

94000406

GENERAL INFORMATION

THIS IS NOT AN ASSEMBLY MANUAL AND SHOULD NOT BE USED AS SUCH

About This Manual

This Parts Catalog has been prepared to make it easier for you to order parts for your 2016 motorcycles. Located at the back of the book is a complete Hardware Listing for your convenience. The numbers shown in the illustrations correspond to the numbers in the "INDEX NO." column in the parts lists. Consult the illustrations when ordering parts to make sure that you receive all the required parts. The number in parentheses following the part description is the quantity needed for complete assembly. If there is no number in parentheses, only one is used. Prices of parts in this catalog are published separately.

When ordering parts the following instructions should be followed carefully.

- The "MODEL(S)" column in the parts lists may include one or more two-character (three-character for FLT, Dyna and Softail) codes that correspond to the vehicle identification number (VIN) model designations and engine type. The models and their respective two-character (three-character for FLT, Dyna and Softail) codes are listed at the bottom of each right side page for your reference. If a part fits all models, "ALL" is in the corresponding "MODEL(S)" column.
- Make sure to specify the correct part number for each item. The part numbers appear under the "PART NO." column in the parts lists.
- Orders may be placed via your computer for all parts. Review your system documentation on placing orders electronically. All non-warranty replacement crankcase orders require return of the complete left crankcase half with vehicle identification number (VIN). All non-warranty replacement frame orders require return of the steering neck with vehicle identification number (VIN). Non-compliance will result in a fine. See non-warranty frame and crankcase policy or contact Dealer Services.
- The sale or use of these parts or accessories does not grant the purchaser a license or other right under any Harley-Davidson patent.
- For all 2008 and later painted parts, refer to the Service Section of h-dnet.com which features a listing of painted part numbers, except CVO (Custom Vehicle Operations) models which are located in their own respective catalogs.
- All parts that were added for the new model year have a vertical bar on the parts list page left of the index number. This can be used to identify any new parts that are unique to a specific model, and help distinguish new and previous model year parts. In the back of the book is a New Parts List. This list serves as a summary of new parts.
- Parts marked "RESTRICTED SALE PART" are limited edition items and can only be ordered as direct replacements.
- Orientation symbols are used when the illustration is not in the standard "Right-Front" orientation. The symbol is a motorcycle with an arrow in the front indicating the direction of view. The symbol is at the bottom left or right side of the illustration page.

To the best knowledge of Harley-Davidson Motor Company, the material contained herein is accurate as of the date this publication was approved for printing. Harley-Davidson Motor Company reserves the right to change specifications, equipment or designs at any time without notice and without incurring obligation.

Common Service Parts

There is a Common Service Parts section located at the back of this parts catalog. This section contains the most commonly ordered parts for service on vehicles covered in this catalog. These parts are ordered through the normal ordering process.

Loose Parts

There is a loose parts section located at the back of this parts catalog. This section indicates the parts which are shipped unfastened with the vehicles covered by this catalog.

Process for Requesting Missing/Loose Parts

Simply submit a Return Material Authorization (RMA) form with code "T-part not included with vehicle" for all vehicle missing parts claims. Then place an order for the missing item on your next Parts and Accessories order. Upon filing the RMA claim your dealership will be credited for the dealer net cost of the part. The Vehicle Identification Number must be written on the RMA form in order for you to receive credit. Your RMA claim should be faxed to (414) 343-7762. This process is to be used for vehicles manufactured at all plants.

2017 Touring Models Parts Catalog

ALPHABETICAL LIST

PARTS

HARDWARE LIST

NEW PARTS LIST

NUMERICAL INDEX

COMPONENT TYPES AND INTRODUCTION DATES

COMMON SERVICE PARTS

ABS MODULE

AIR CLEANER

AIR CLEANER COVER

AIR FILTER, ENGINE

ALTERNATOR AND REGULATOR

ANTENNAS

AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC

AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL

BALANCER ASSEMBLY

BATTERY

BATTERY CABLES

BELT, CHAINS AND SPROCKETS

BELT, REAR 140 TEETH

BODY CONTROL MODULE (BCM)

BRAKE CALIPER, FRONT

BRAKE CALIPER, REAR

BRAKE CONTROL, FRONT

BRAKE CONTROL, REAR

BRAKE DISC, FRONT

BRAKE DISC, REAR

BRAKE LEVER, FRONT

BRAKE LEVER, REAR

BRAKE LINE, FRONT - NON-ABS

BRAKE LINE, REAR, NON-ABS

BRAKE LINES AND MODULE, REAR - ABS

BRAKE LINES, FRONT - ABS

BRAKE MASTER CYLINDER, FRONT

BRAKE MASTER CYLINDER, REAR

BRAKE MODULE, ABS

BUMPER, REAR FENDER

CAMSHAFT SUPPORT ASSEMBLY

CAMSHAFTS AND CAMSHAFT COVER

CHAIN, PRIMARY

CHECK VALVE, OIL PRESSURE

CLUTCH

CLUTCH CONTROL

CLUTCH CONTROL HAND LEVER

CLUTCH LINE

CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)

CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2)

COOLANT DISTRIBUTION, AIR-COOLED

COOLANT DISTRIBUTION, TWIN-COOLED™

COOLING SYSTEM, ENGINE, AIR-COOLED

COOLING SYSTEM, ENGINE, TWIN-COOLED™

COVER, PUSHRODS

COVERS AND AIR DEFLECTORS

CRANKCASE AND ENGINE OIL FILTER

CRANKCASE

CYLINDER HEADS

CYLINDERS, HEADS AND VALVES

DEBRIS DEFLECTOR

DIPSTICK

ELECTRONIC CONTROL MODULE (ECM) AND COIL

ENGINE ASSEMBLY, AIR-COOLED

ENGINE ASSEMBLY, TWIN-COOLED™

ENGINE MOUNTS AND STABILIZER LINK

EVAPORATIVE EMISSIONS COMPONENTS

EXHAUST SYSTEM

FAIRING LOWERS, AIR COOLED - FLHTCU

FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU

FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)

FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)

FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)

FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)

FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)

FAIRING, OUTER - FLHTCU, FLHTK, FLHX AND FLHXS

FAIRING, OUTER - FLTRU, FLTRX AND FLTRXS

FENDERS, FRONT

FENDERS, REAR (1 OF 2)

FENDERS, REAR (2 OF 2)

FLYWHEEL

FOOTBOARDS AND FOOTPEGS, PASSENGER

FOOTBOARDS, OPERATOR

FORK BRACKETS, FRONT

FORK, FRONT, LEFT AND RIGHT - LOW

FORK, FRONT, LEFT AND RIGHT - STANDARD

FORK, REAR

FRAME AND FORK, REAR AND TOUR-PAK SUPPORT

FRAME AND JIFFY STAND

FRAME, MAIN

FRAME, REAR

FUEL FILTER

FUEL FILTER

FUEL INJECTOR

FUEL PUMP - FLHR AND FLHRC

FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS

FUEL TANK - FLHR AND FLHRC

FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS

[illegible]


MODULE, SECURITY SYSTEM
MODULE, TURN SIGNAL CANCELLER
MUFFLERS
NACELLE AND HEADLAMP - FLHR AND FLHRC
OIL COOLER
OIL FILTER, ENGINE
OIL PAN, TRANSMISSION
OIL PUMP
PISTONS AND FLYWHEEL ASSEMBLY
PRIMARY COVER
PRIMARY HOUSING
PUSHRODS
RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
RADIO CONTROL, PASSENGER
REGULATOR, VOLTAGE
REMOTE CONTROL FOB
RIM STRIP
RIM STRIP
ROCKER ARM ASSEMBLY AND PUSHRODS
ROTOR, ENGINE
SADDLEBAGS (1 OF 2)
SADDLEBAGS (2 OF 2)
SADDLEBAGS - FLHRC
SEATS
SENSOR, AIR TEMP
SENSOR, COOLANT TEMPERATURE
SENSOR, CRANKSHAFT POSITION
SENSOR, ENGINE TEMP
SENSOR, KNOCK
SENSOR, SPEED
SENSOR, TEMPERATURE MANIFOLD ABSOLUTE PRESSURE
SENSOR, TEMPERATURE MANIFOLD ABSOLUTE PRESSURE
SENSORS AND SWITCHES, ENGINE
SHIFTER CAMSHAFT
SHIFTER FORK
SHIFTER, GEAR
SHOCK ABSORBERS, REAR
SOLENOID, AUTO COMPRESSION RELEASE
SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
SPARK PLUGS
SPEAKER, FRONT
SPEAKER, FRONT
SPEAKER, REAR
SPEEDOMETER - FLHR AND FLHRC
SPEEDOMETER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS
SPEEDOMETER - FLTRU, FLTRX AND FLTRXS
SPROCKET, REAR 68 TEETH
SPROCKET, TRANSMISSION 32 TEETH

STABILIZER LINK, ENGINE
STARTER MOTOR
STATOR
SWITCH, IGNITION - FLHR AND FLHRC
SWITCH, IGNITION
SWITCH, NEUTRAL INDICATOR
SWITCH, OIL PRESSURE
SWITCH, SPOT AND ACCESSORY - FLHR
SWITCHES
SWITCHES, HANDLEBAR, LEFT
SWITCHES, HANDLEBAR, RIGHT
TACHOMETER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS
TACHOMETER - FLTRU, FLTRX AND FLTRXS
TAIL LAMP (1 OF 2)
TAIL LAMP (2 OF 2)
TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)
THROTTLE CONTROL
TIRE, FRONT
TIRE, REAR
TOUR-PAK (BOTTOM)
TOUR-PAK (COVER)
TOUR-PAK SUPPORT
TRANSMISSION BEARINGS AND COVERS
TRANSMISSION GEARS
TRANSMISSION HOUSING, TOP COVER AND OIL PAN
TURN SIGNALS, FRONT - FLHR AND FLHRC
TURN SIGNALS, FRONT - FLHTC AND FLHTK
TURN SIGNALS, FRONT - FLHX AND FLHXS
TURN SIGNALS, FRONT - FLTRU, FLRTX AND FLTRXS
TURN SIGNALS, REAR
VALVES
VOLTMETER - FLTRU, FLTRX AND FLTRXS
WHEELS, FRONT
WHEELS, REAR
WINDSHIELD - FLHR AND FLHRC
WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (2 OF 2)
WIRING HARNESS, CONSOLE - FLHR AND FLHRC
WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8)

WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8)

WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8)
WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)
WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)
PARTS

ENGINE ASSEMBLY, AIR-COOLED




Index No.	Part No.	Description	Model(s)
1	16200248	ENGINE ASSEMBLY, complete	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX,

			FLTRXS
2	16200265	ENGINE ASSEMBLY, shortblock, with 91800064, crankcase, flywheel assembly, camshaft support plate assembly, balancer and cylinder studs (See Note)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
3	91800064	KIT, shortblock installation, with 25700729 upper end gasket kit, 25700746 inner primary gasket kit, camshaft sprocket, camshaft drive chain and camshaft tensioner	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS

Note: Cylinders, cylinder heads, camshaft, rocker arms, pushrods, pushrod covers, piston assemblies, tappets, oil pump, oil filter adapter, oil filter and cosmetic covers are not included with the shortblock assembly. These parts must be removed from the original engine and installed on the replacement shortblock assembly.

ENGINE ASSEMBLY, TWIN-COOLED™




Index No.	Part No.	Description	Model(s)
1	16200249	ENGINE ASSEMBLY, complete	FLHTK, FLHTKL,

			FLTRU
2	16200265	ENGINE ASSEMBLY, shortblock, with 91800064, crankcase, flywheel assembly, camshaft support plate assembly, balancer and cylinder studs (See Note)	FLHTK, FLHTKL, FLTRU
3	91800064	KIT, shortblock installation, with 25700729 upper end gasket kit, 25700746 inner primary gasket kit, camshaft sprocket, camshaft drive chain and camshaft tensioner	FLHTK, FLHTKL, FLTRU

Note: Cylinders, cylinder heads, camshaft, rocker arms, pushrods, pushrod covers, piston assemblies, tappets, oil pump, oil filter adapter, oil filter and cosmetic covers are not included with the shortblock assembly. These parts must be removed from the original engine and installed on the replacement shortblock assembly.


CYLINDERS, HEADS AND VALVES



Index No.	Part No.	Description	Model(s)
1	16589-99A	DOWEL PIN (4)	ALL

2	10200303	FLANGE NUT (dull silver) (8)	ALL
3	10900015	STUD, exhaust port (4)	ALL
4	16500326	GASKET, cylinder head (2)	ALL
5	16500332	GASKET, cylinder base (2)	ALL
6	16500388	CYLINDER HEAD, rear, with 65324-83B, 10900015, 18000016, 18000034, 18100043, 18100044, 18100045, 18100060 and 18400073, AIR-COOLED (black)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
	16500498	CYLINDER HEAD, rear, with 65324-83B, 10900015, 18000016, 18000034, 18100043, 18100044, 18100045, 18100060 and 18400073, TWIN-COOLED™ (black)	FLHTK, FLHTKL, FLTRU
	16500393	CYLINDER HEAD, front, with 65324-83B, 10900015, 18000016, 18000034, 18100043, 18100044, 18100045, 18100060 and 18400073, AIR-COOLED (black)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
	16500508	CYLINDER HEAD, front, with 65324-83B, 10900015, 18000016, 18000034, 18100043, 18100044, 18100045, 18100060 and 18400073, TWIN-COOLED™ (black)	FLHTK, FLHTKL, FLTRU
7	16800063	STUD, cylinder (8)	ALL
8	16800095	CYLINDER ASSEMBLY, front, with 16589-99A (black)	ALL
	16800100	CYLINDER ASSEMBLY, rear, with 16589-99A (black)	ALL
9	18000016	INTAKE VALVE (4)	ALL
10	18000034	EXHAUST VALVE (4)	ALL
11	18100043	VALVE SPRING (8)	ALL
12	18100044	SEAL, valve (8)	ALL
13	18100045	COLLAR, valve spring (8)	ALL
14	18100060	KEEPER, valve (16)	ALL
15	18400073	SOLENOID, auto compression release (ACR) (2)	ALL
16	25700729	GASKET KIT, top end	ALL
	25700730	GASKET KIT, engine overhaul	ALL


ROCKER ARM ASSEMBLY AND PUSHRODS



Index No.	Part No.	Description	Model(s)
1	3976	SCREW (2)	ALL
2	4741A	SCREW (8)	ALL
3	6762D	WASHER (4)	ALL

4	11132A	O-RING, pushrod cover (4)	ALL
5	11145A	O-RING, pushrod cover (4)	ALL
6	11293	O-RING (4)	ALL
7	17945-36B	CAP, cover spring (4)	ALL
8	17947-36	SPRING, pushrod cover (4)	ALL
9	17948-99	COVER, pushrod (upper) (4)	ALL
10	17968-99	RETAINER, spring cap (4)	ALL
11	18538-99C	HYDRAULIC LIFTER (4)	ALL
12	10200258	SCREW (2)	ALL
13	10200308	SCREW (20)	ALL
14	10200446	SCREW (8)	ALL
15	10200503	SCREW (8)	ALL
16	10500069	SPACER, rocker cover (2)	ALL
17	11900116	O-RING (2)	ALL
18	17300053	ROCKER ARM, rear intake, front exhaust (2)	ALL
19	17300055	ROCKER ARM, front intake, rear exhaust (2)	ALL
20	17300059	SHAFT, rocker arm (4)	ALL
21	17900030	PUSHROD, intake, 10.301 in long (light blue stripes) (2)	ALL
22	17900031	PUSHROD, exhaust, 10.531 in long (yellow stripes) (2)	ALL
23	17900034	ANTI-ROTATION DEVICE, rear cylinder	ALL
	17900035	ANTI-ROTATION DEVICE, front cylinder	ALL
24	25700362	GASKET, lifter cover (2)	ALL
25	25700372	GASKET, rocker arm cover (2)	ALL
26	25700409	ROCKER COVER (chrome) (2)	ALL
27	25700410	LIFTER COVER, front (chrome)	ALL
	25700411	LIFTER COVER, rear (chrome)	ALL
28	25700414	ROCKER COVER, lower (chrome) (2)	ALL
29	25700425	GASKET, rocker housing, lower (2)	ALL
30	25700488	COVER, pushrod (lower) (4)	ALL
31	25700731	GASKET KIT, camshaft service	ALL
32	29400183	BREATHING ASSEMBLY, rear, with 11900116	ALL
	29400210	BREATHING ASSEMBLY, front, with 11900116	ALL


COOLING SYSTEM, ENGINE, TWIN-COOLED™



Index No.	Part No.	Description	Model(s)
1	10200446	SCREW (2)	FLHTK, FLHTKL, FLTRU
2	10800052	CLAMP (2)	FLHTK, FLHTKL, FLTRU
3	11900090	O-RING, coolant manifold (4)	FLHTK, FLHTKL, FLTRU

4	26900117	BRACKET, coolant tube (2)	FLHTK, FLHTKL, FLTRU
5	26900133	COOLANT LINE ASSEMBLY, water, with 11900090 and 26900117	FLHTK, FLHTKL, FLTRU


COOLING SYSTEM, ENGINE, AIR-COOLED



Index No.	Part No.	Description	Model(s)
1	4705	SCREW	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS

2	10200446	SCREW (4)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
3	10800052	CLAMP (3)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
4	11900090	O-RING, coolant manifold (4)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
5	11900092	O-RING, transmission oil return	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
6	26900117	BRACKET, coolant tube (2)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
7	62700146	FITTING ASSEMBLY, transmission oil return, with 11900092	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
8	62800028	COOLANT LINE ASSEMBLY, oil, with 10800052, 11900090 and 26900117	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS


COOLANT DISTRIBUTION, TWIN-COOLED™



Index No.	Part No.	Description	Model(s)
1	10318	CLIP, wire retention	FLHTK, FLHTKL, FLTRU
2	10344	CLAMP	FLHTK, FLHTKL, FLTRU
3	11692	GROMMET (2)	FLHTK, FLHTKL, FLTRU

4	10200414	SCREW (2)	FLHTK, FLHTKL, FLTRU
5	10200422	SCREW (2)	FLHTK, FLHTKL, FLTRU
6	10800052	CLAMP (3)	FLHTK, FLHTKL, FLTRU
7	12700091	BRACKET, voltage regulator	FLHTK, FLHTKL, FLTRU
8	26600048	PUMP, coolant	FLHTK, FLHTKL, FLTRU
9	26800077	COVER, coolant pump	FLHTK, FLHTKL, FLTRU
10	26900088	HOSE, outlet, water pump	FLHTK, FLHTKL, FLTRU


COOLANT DISTRIBUTION, AIR-COOLED



Index No.	Part No.	Description	Model(s)
1	10080	CLAMP	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS

2	10318	RETAINER, wire harness	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
3	10344	CLAMP	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
4	10354	CLAMP (2)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
5	11692	GROMMET (2)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
6	10200414	SCREW (2)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
7	10200422	SCREW (4)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
8	10800052	CLAMP	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
9	12100113	GROMMET	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
10	12600016	CLIP, push-in (2)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
11	12700090	BRACKET, voltage regulator	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
12	26800092	COVER, oil cooler	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
13	62700143	HOSE, inlet, oil cooler	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
14	62700144	HOSE, outlet, oil cooler	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
15	62700196	OIL COOLER, with 12100113	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
16	69201286	COVER, electrical connector, with 12600016	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS

RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™




Index No.	Part No.	Description	Model(s)
1	7716	LOCKNUT	FLHTK, FLHTKL,

			FLTRU
2	10006	CABLE STRAP (6)	FLHTK, FLHTKL, FLTRU
3	10147	CLIP, connector (2)	FLHTK, FLHTKL, FLTRU
4	10344	CLAMP (4)	FLHTK, FLHTKL, FLTRU
5	26780-05A	CAP ASSEMBLY, coolant bottle	FLHTK, FLHTKL, FLTRU
6	72063-06	HOUSING, two-way socket (black)	FLHTK, FLHTKL, FLTRU
7	72111-06	SECONDARY LOCK, two-way socket	FLHTK, FLHTKL, FLTRU
8	72168-07	TERMINAL, socket, 18-20 AWG (6)	FLHTK, FLHTKL, FLTRU
9	72177-07BK	HOUSING, four-way socket (black)	FLHTK, FLHTKL, FLTRU
10	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLHTK, FLHTKL, FLTRU
11	72484-08	TERMINAL, socket, 20 AWG (2)	FLHTK, FLHTKL, FLTRU
12	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLHTK, FLHTKL, FLTRU
13	72606-08	HOUSING, two-way socket (black) (2)	FLHTK, FLHTKL, FLTRU
14	72607-08	HOUSING, two-way pin (black) (2)	FLHTK, FLHTKL, FLTRU
15	72608-08	TERMINAL, pin, 16-20 AWG (4)	FLHTK, FLHTKL, FLTRU
16	72609-08	SECONDARY LOCK, two-way (4)	FLHTK, FLHTKL, FLTRU
17	72610-08	WIRE SEAL, 18-20 AWG (white) (8)	FLHTK, FLHTKL, FLTRU
18	10800023	CLAMP (2)	FLHTK, FLHTKL, FLTRU
19	10800052	CLAMP (4)	FLHTK, FLHTKL, FLTRU

20	10800078	CLAMP (3)	FLHTK, FLHTKL, FLTRU
21	26800005	CORE, radiator (right)	FLHTK, FLHTKL, FLTRU
22	26800006	CORE, radiator (left)	FLHTK, FLHTKL, FLTRU
23	26800007A	FAN ASSEMBLY, with 72213-94, 72606-08, 72609-08 and 72610-08 (left)	FLHTK, FLHTKL, FLTRU
24	26800019A	FAN ASSEMBLY, with 72213-94, 72606-08, 72609-08 and 72610-08 (right)	FLHTK, FLHTKL, FLTRU
25	26800020A	FILL NECK, coolant	FLHTK, FLHTKL, FLTRU
26	26800021	CAP, pressure	FLHTK, FLHTKL, FLTRU
27	26900008	HOSE, coolant, left cross tube	FLHTK, FLHTKL, FLTRU
28	26900009	LINE, coolant, right to left	FLHTK, FLHTKL, FLTRU
29	26900010	HOSE, coolant, right cross tube	FLHTK, FLHTKL, FLTRU
30	26900014	BOTTLE ASSEMBLY, coolant, with 26780-05A	FLHTK, FLHTKL, FLTRU
31	26900016	HOSE, coolant vent	FLHTK, FLHTKL, FLTRU
32	26900017	HOSE, coolant overflow	FLHTK, FLHTKL, FLTRU
33	26900018	HOSE, coolant fill	FLHTK, FLHTKL, FLTRU
34	26900114	HOSE, radiator to engine outlet	FLHTK, FLHTKL, FLTRU
35	26900115	HOSE, radiator to pump inlet	FLHTK, FLHTKL, FLTRU
36	32700066	SENSOR, coolant temperature	FLHTK, FLHTKL, FLTRU
37	62800004	CLIP, coolant line to frame (2)	FLHTK, FLHTKL, FLTRU
38	69200271	HOUSING, two-way socket (black)	FLHTK,

			FLHTKL, FLTRU
39	69200311	WIRE HARNESS, twin cooling jumper, with 10147, 72168-07, 72607-08, 72608-08, 72609-08, 72610-08 and 69200271 (right)	FLHTK, FLHTKL, FLTRU
40	69201548	WIRE HARNESS, twin cooling jumper, with 10147, 72063-06, 72111-06, 72168-07, 72177-07BK, 72484-08, 72486-08, 72607-08, 72608-08, 72609-08 and 72610-08 (left)	FLHTK, FLHTKL, FLTRU


PISTONS AND FLYWHEEL ASSEMBLY



Index No.	Part No.	Description	Model(s)
1	11177A	RETAINING RING	ALL
2	22097-99	LOCK RING, piston pin (4)	ALL
3	21900049	PISTON AND RINGS ASSEMBLY, with 22097-99, 22000060 and 22100006, standard (2)	ALL

4	22000060	PISTON RING SET, standard (2)	ALL
5	22100006	PISTON PIN (2)	ALL
6	24100057	FLYWHEEL ASSEMBLY KIT, with 11177A	ALL
7	35200027	BALANCER ASSEMBLY	ALL


CRANKCASE AND ENGINE OIL FILTER



Index No.	Part No.	Description	Model(s)
1	703B	SCREW (2)	ALL
2	765	PLUG (5)	ALL
3	8972	WASHER	ALL

4	9215	NEEDLE BEARING, left side, camshaft	ALL
5	16574-99A	DOWEL PIN (2)	ALL
6	16589-99A	DOWEL PIN (4)	ALL
7	24605-07	BEARING, main (2)	ALL
8	26352-95A	ADAPTER	ALL
9	35114-02	RING, retaining, internal	ALL
10	63731-99A	OIL FILTER (black)	ALL
11	68042-99	SCREW (4)	ALL
12	10200343	SCREW (12)	ALL
13	11000134	SEAL, oil	ALL
14	11900010	O-RING (TWIN-COOLED™)	FLHTK, FLHTKL, FLTRU
15	12400099	SPACER, front mount (2)	ALL
16	24100080	BEARING KIT, with 8972, 24605-07, 35114-02 and inner race	ALL
17	24400120	CRANKCASE SET, with 2, 5, 6, 7, 9, 11, 12, 15, 18, 20, 21 and 22 (black)	ALL
18	25700433	GASKET, piston jet (2)	ALL
19	29900041	SPACER, sprocket shaft	ALL
20	35200021	BEARING, balancer (2)	ALL
21	62700089	PISTON JET ASSEMBLY, front, with 25700433	ALL
22	62700117	PISTON JET ASSEMBLY, rear, with 25700433	ALL
23	62800013	PLUG, with 11900010 (TWIN-COOLED™)	FLHTK, FLHTKL, FLTRU


CAMSHAFTS AND CAMSHAFT COVER



Index No.	Part No.	Description	Model(s)
1	601	ROLL PIN	ALL
2	942	SCREW (2)	ALL

3	4740A	SCREW (15)	ALL
4	4822A	SCREW (4)	ALL
5	6294	WASHER	ALL
6	8873	BALL (7)	ALL
7	9215	NEEDLE BEARING, camshaft	ALL
8	11293	O-RING	ALL
9	16589-99A	DOWEL PIN	ALL
10	25566-06	CAMSHAFT DRIVE SPROCKET RETENTION KIT, with 6294, screws and washer	ALL
11	25673-06	SPROCKET, camshaft drive on crankshaft, 17 T	ALL
12	25675-06	CHAIN, primary camshaft drive	ALL
13	25729-06	SPACER, camshaft drive sprocket alignment 0.100 in thick (use as required)	ALL
	25731-06	SPACER, camshaft drive sprocket alignment 0.110 in thick (use as required)	ALL
	25734-06	SPACER, camshaft drive sprocket alignment 0.120 in thick (use as required)	ALL
	25736-06	SPACER, camshaft drive sprocket alignment 0.130 in thick (use as required)	ALL
	25737-06	SPACER, camshaft drive sprocket alignment 0.140 in thick (use as required)	ALL
	25738-06	SPACER, camshaft drive sprocket alignment 0.150 in thick (use as required)	ALL
14	26210-99	SPRING, relief valve	ALL
15	68120-00	SCREW (2)	ALL
16	11900103	O-RING	ALL
17	25400103	SPROCKET, camshaft drive, 34 teeth	ALL
18	25400133	CAMSHAFT SUPPORT PLATE, with 8873 and 16589-99A	ALL
19	25400190	CAMSHAFT	ALL
20	25400257	CAMSHAFT CHAIN AND FASTENER KIT, with 25566-06, 25673-06, 25675-06 and 25400103	ALL
21	25500013	CHAIN TENSIONER, camshaft drive chain	ALL
22	25600042	COVER, timer cover	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	25600049	COVER, timer cover	FLHTK, FLHTKL
23	25700367	CAMSHAFT COVER (chrome)	ALL
24	25700370	GASKET, camshaft cover	ALL
25	25700731	GASKET KIT, camshaft service	ALL
26	62400052	GEROTOR ASSEMBLY	ALL
27	62400055	GEROTOR ASSEMBLY, feed (TWIN-COOLED™)	FLHTK, FLHTKL, FLTRU
	62400126	GEROTOR ASSEMBLY, feed (AIR-COOLED)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
28	62400121	OIL PUMP ASSEMBLY, with 601, 8873, 26210-99, 62400052, 62400132 and body (AIR-COOLED) Also order 62400126	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
	62400124	OIL PUMP ASSEMBLY, with 601, 8873, 26210-99, 62400052, 62400132 and body (TWIN-COOLED™) Also order 62400055	FLHTK, FLHTKL, FLTRU
29	62400125	COVER, oil pump assembly	ALL
30	62400132	RELIEF VALVE, oil pump bypass	ALL


ENGINE MOUNTS AND STABILIZER LINK



Index No.	Part No.	Description	Model(s)
1	4688	SCREW (3)	ALL
2	6127	WASHER	ALL
3	16219-09	STABLIZER LINK	ALL

4	10100062	LOCKNUT	ALL
5	10200393	SCREW	ALL
6	10200408	SCREW (2)	ALL
7	10200463	SCREW (2)	ALL
8	16300005	ENGINE MOUNT, front (2)	ALL
9	16400041	BRACKET, tie link	ALL
10	16400042	END CAP, front mount	ALL


INDUCTION MODULE, FUEL



Index No.	Part No.	Description	Model(s)
1	3275	SCREW (4)	ALL
2	29465-08A	BREATHER BOLT (2)	ALL
3	10200373	SCREW (5)	ALL

4	12100069	PLUG, purge tube cap	ALL
5	16400049	BRACKET, induction module	ALL
6	27200025	MANIFOLD THROTTLE BODY INTAKE KIT, with 27300122, 27400019 and 91800058	ALL
7	27300082	GASKET, throttle body to manifold	ALL
8	27300086	FLANGE, intake (2)	ALL
9	27300087	SEAL, intake (2)	ALL
10	27300121	INTAKE MANIFOLD ASSEMBLY, with 27300082	ALL
11	27300122	THROTTLE BODY ASSEMBLY, with 12100069	ALL
12	27400015	FUEL INJECTOR ASSEMBLY, with O-rings (2)	ALL
13	27400019	FUEL RAIL KIT	ALL
14	32700065	SENSOR, temperature manifold absolute pressure, with O-ring	ALL
15	61200022	FUEL LINE	ALL
16	91800058	HARDWARE KIT, induction module	ALL


AIR CLEANER



Index No.	Part No.	Description	Model(s)
1	946	SCREW (3)	ALL
2	29108-08	WARNING LABEL, air cleaner (chrome)	ALL

		(Domestic, California)	
3	29269-83A	SCREW	ALL
4	29465-08A	BREATHING BOLT (2)	ALL
5	29000106	SEAL, air cleaner cover	ALL
6	29000108	GASKET, induction module to backplate	ALL
7	29000120	BACKPLATE ASSEMBLY (Domestic)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	29000121	BACKPLATE ASSEMBLY (HDI)	FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
8	29400211	BREATHING HOSE	ALL
9	29400212	FILTER ELEMENT	ALL
10	29000216	COVER KIT, air cleaner, with 29108-08	ALL
11	61300467	INSERT, air cleaner cover	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	61300501	INSERT, air cleaner cover	FLHTK, FLHTKL


ALTERNATOR AND REGULATOR



Index No.	Part No.	Description	Model(s)
1	3050	SCREW (3)	ALL
2	10039	CABLE STRAP (3)	ALL
3	10177	CABLE STRAP, anchored	ALL

4	10200422	SCREW (4)	ALL
5	29900038	ROTOR ASSEMBLY	ALL
6	29900041	SPACER, sprocket shaft	ALL
7	29900042	STATOR ASSEMBLY, 3-phase, 50 A	ALL
8	69201423	DC LEAD ASSEMBLY, voltage regulator (from main wiring harness)	ALL
9	74700025	VOLTAGE REGULATOR ASSEMBLY	ALL


ELECTRONIC CONTROL MODULE (ECM) AND COIL



Index No.	Part No.	Description	Model(s)
1	3634	SCREW (2)	ALL
2	4705	SCREW (2)	ALL

3	4813A	SCREW (2)	ALL
4	10177	CABLE STRAP, anchored (6)	ALL
5	70681-09	RETAINER, wire harness	ALL
6	31600012	SPARK PLUG, M10 (4)	ALL
7	31600017	IGNITION COIL	ALL
8	31600018	SPARK PLUG CABLE, right front cylinder, with 10177	ALL
9	31600023	SPARK PLUG CABLE, right rear cylinder, with 10177	ALL
10	31600078	SPARK PLUG CABLE, left front cylinder, with 10177	ALL
11	31600079	SPARK PLUG CABLE, left rear cylinder, with 10177	ALL
12	41000307	ELECTRONIC CONTROL MODULE (ECM), base level (Domestic, HDI) Requires digital programming.	ALL
13	69200174	CADDY, electronic control module (ECM)	ALL
14	69201178	BRACKET, battery hold down	ALL


SENSORS AND SWITCHES, ENGINE



Index No.	Part No.	Description	Model(s)
1	3275	SCREW (2)	ALL
2	4705	SCREW	ALL


3	10177	CABLE STRAP, anchored	ALL
4	11289A	O-RING, crankshaft position sensor	ALL
5	74194-98	TERMINAL PIN, DTM 20-24 (2)	ALL
6	11900010	O-RING,	ALL
7	32700048	SENSOR, crankshaft position, with 11289A, 74194-98 and 69201302	ALL
8	32700054	SENSOR, engine temperature, with 10177, 69201299, 69201300 and 69201301	ALL
9	32700065	SENSOR, temperature manifold absolute pressure (TMAP), with O-ring	ALL
10	62700141	CHECK VALVE, oil pressure, with 11900010 (AIR-COOLED)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
11	62800013	PLUG ASSEMBLY, with 11900010 (TWIN-COOLED™)	FLHTK, FLHTKL, FLTRU
12	69200840	SENSOR, knock (2)	ALL
13	69201299	HOUSING, socket, two-way, key B	ALL
14	69201300	TERMINAL, socket, 20 AWG (2)	ALL
15	69201301	WIRE SEAL, 22 AWG (green) (2)	ALL
16	69201302	CONNECTOR ANCHOR	ALL
17	71400112	OIL PRESSURE SWITCH	ALL

STARTER MOTOR



Index No.	Part No.	Description	Model(s)
1	4419	SCREW (2)	ALL
2	27444-00Y	O-RING, starter-to-case	ALL
3	31400053	STARTER ASSEMBLY COMPLETE (black)	ALL


SHIFTER, GEAR



Index No.	Part No.	Description	Model(s)
1	780	SCREW	ALL
2	856A	SCREW	ALL

3	3275	SCREW (2)	ALL
4	5817	SPACER	ALL
5	6497HW	WASHER	ALL
6	7330	ACORN NUT	ALL
7	11150	RETAINING RING	ALL
8	11389	RING, shift camshaft retaining	ALL
9	11575	RING, shift camshaft retaining	ALL
10	33389-07	SPRING, detent	ALL
11	33409-06B	DETENT ARM ASSEMBLY, with 33389-07	ALL
12	33719-79B	SHIFTER ROD	ALL
13	33895-82D	SHIFT LEVER KIT, with 3275 and shifter lever (2)	ALL
14	34064-00C	SPRING, shift lever centering	ALL
15	34611-65A	TOE SHIFTER PEG KIT (2)	ALL
16	34987-06	SPRING, ratchet lever	ALL
17	35081-06	SHIFT MECHANISM, with 34064-00C and 34987-06	ALL
18	35082-07	CENTERING SCREW, shift lever	ALL
19	35186-06	SLEEVE	ALL
20	35187-06	FORK, shift 1 - 2	ALL
21	35210-06	FORK, shift 3 - 4	ALL
22	35217-06	FORK, shift 5 - 6	ALL
23	35222-06	SHAFT, 5 - 6 shift fork	ALL
24	35223-06	SHAFT, 1 - 2 and 3 - 4 shift fork	ALL
25	35243-06	SLEEVE	ALL
26	35244-06	SCREW	ALL
27	35249-06A	LOCK PLATE, shift camshaft	ALL
28	35259-06	SCREW (2)	ALL
29	11000101	OIL SEAL	ALL
30	33600088	LEVER, gear shifter	ALL
31	33600091	SHAFT	ALL
32	33900172	SHIFTER CAMSHAFT ASSEMBLY, with 11389, 11575 and bearing	ALL
33	33900175	LEVER, shifter rod	ALL
34	35000198	GEAR PACK, FORKS AND DRUM SUBASSEMBLY, with 8, 9, 10, 11, 20, 21, 22, 23, 24, 25, 26, 27, 28, 32, 7340, 35260-06B, input shaft, countershaft and gears (black)	ALL


TRANSMISSION BEARINGS AND COVERS



Index No.	Part No.	Description	Model(s)
1	221	PIN (2)	ALL
2	3249	SCREW (8)	ALL

3	4705	SCREW (4)	ALL
4	4718A	SCREW (4)	ALL
5	4741A	SCREW (2)	ALL
6	4890	BLEEDER SCREW	ALL
7	7340	NUT, mainshaft and countershaft (2)	ALL
8	8963	BEARING, needle	ALL
9	8967	BEARING	ALL
10	8970A	BEARING	ALL
11	9701A	BUSHING	ALL
12	11132A	O-RING, dipstick	ALL
13	11161	RETAINING RING	ALL
14	12074	SEAL	ALL
15	16583-00A	BUSHING, dowel (2)	ALL
16	35082-07	CENTERING SCREW, shift lever	ALL
17	35087-99A	RETAINING RING (2)	ALL
18	35186-06	SLEEVE	ALL
19	35260-06B	BEARING HOUSING ASSEMBLY, with 221, 8970A, 16583-00A, 35087-99A and 11000010 (black)	ALL
20	35654-06	GASKET, bearing housing	ALL
21	36805-06	GASKET, cover	ALL
22	37065-06A	DIPSTICK (chrome)	ALL
23	11000010	BEARING	ALL
24	11000101	OIL SEAL	ALL
25	11900092	O-RING	ALL
26	24400215	GASKET	ALL
27	25700178	INNER SIDE COVER, transmission	ALL
28	25800048	INSERT, side cover, six speed	FLHTK, FLHTKL
	25800049	INSERT, side cover, six speed	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
29	25800054	SIDE COVER, transmission, with 25800109 and 25800110 (chrome)	ALL
30	25800056	SIDE COVER ASSEMBLY, transmission, with 25800048 and 25800054 (chrome)	FLHTK, FLHTKL
	25800057	SIDE COVER ASSEMBLY, transmission, with 25800049 and 25800054 (chrome)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
31	25800109	TRIM, rubber	ALL
32	25800110	TAPE, foam	ALL
33	37200131	SECONDARY CLUTCH ACTUATOR, with 4890	ALL
34	62700146	FITTING ASSEMBLY, transmission oil return, with 11900092 (AIR-COOLED)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
35	62700150	PLUG, transmission, with 11900092 (TWIN-COOLED™)	FLHTK, FLHTKL, FLTRU


TRANSMISSION HOUSING, TOP COVER AND OIL PAN



Index No.	Part No.	Description	Model(s)
1	3699D	SCREW (2)	ALL
2	3983	SCREW (2)	ALL

3	4705	SCREW	ALL
4	4741A	SCREW (18)	ALL
5	7792	NUT	ALL
6	11105	O-RING (2)	ALL
7	11120	O-RING	ALL
8	11289A	O-RING	ALL
9	16574-99A	DOWEL PIN (2)	ALL
10	33926-06B	SWITCH, neutral indicator, with O-ring	ALL
11	60328-98B	PLUG, magnetic, with 11105 (2)	ALL
12	62372-09	VENT HOSE, transmission	ALL
13	66290-06	STUD, ground	ALL
14	74402-05B	SPEED SENSOR, with 11289A	ALL
15	24400180	OIL PAN ASSEMBLY, with 60328-98B (black)	ALL
16	25700452	GASKET, oil pan	ALL
17	25700453	GASKET, upper cover	ALL
18	34700084	TRANSMISSION CASE SUBASSEMBLY, with 3594, 8963, 8967A, 9701A, 11161, 12074, 16574-99A, 35082-07, 35122-06, 35186-06, 35241-06, 35242-06, 66290-06, 11000101 and 35000152 (black)	ALL
19	34800025	TRANSMISSION COVER, top, with 62372-09 (chrome)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
	34800038	TRANSMISSION COVER, top, with 62372-09 (black)	FLHX, FLHXS, FLTRX, FLTRXS
20	62700136	DIPSTICK ASSEMBLY, with 11120 (black cap)	ALL


TRANSMISSION GEARS



Index No.	Part No.	Description	Model(s)
1	5837A	SPACER	ALL
2	7340	NUT (2)	ALL

3	8026K	BEARING, needle (4)	ALL
4	8041	BEARING, needle	ALL
5	8042	BEARING, needle (2)	ALL
6	10991A	RETAINING RING (2)	ALL
7	11061A	RETAINING RING	ALL
8	11081A	RING, lock (3)	ALL
9	11082A	SECURING SEGMENT (6)	ALL
10	11201	O-RING	ALL
11	11207A	WASHER, internal spline	ALL
12	11599A	SPACER, bearing	ALL
13	12077	OIL SEAL	ALL
14	34091-08	BEARING, inner race	ALL
15	35122-06	GEAR ASSEMBLY, driven output, with 8042, 10991A, 11201, 11599A and 12077	ALL
16	35124-06	GUIDE HUB, dog ring	ALL
17	35126-06	DOG RING, lugged (2)	ALL
18	35201-10	GUIDE HUB, dog ring	ALL
19	35202-06	GUIDE HUB, dog ring	ALL
20	35204-06	DOG RING, pocketed	ALL
21	35467-06B	INPUT SHAFT KIT, with 11061A, 34091-08 and 35201-10	ALL
22	35470-10	COUNTERSHAFT ASSEMBLY	ALL
23	35801-10	GEAR, fifth input	ALL
24	35807-06	GEAR, countershaft-second	ALL
25	35811-06	GEAR, countershaft-third	ALL
26	35814-06	GEAR, countershaft-fourth	ALL
27	35600103	GEAR ASSEMBLY, countershaft-first	ALL
28	35000198	GEAR PACK, FORKS AND DRUM SUBASSEMBLY, with 1, 2, 3, 4, 7, 8, 9, 11, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 35260-06B, shifter camshaft and forks (black)	ALL


CLUTCH



Index No.	Part No.	Description	Model(s)
1	8885	BEARING	ALL
2	11143	RETAINING RING, external	ALL
3	36706-01K	BOLT (3)	ALL

4	36731-91	PLATE, release, with 8885	ALL
5	37496-90A	NUT, mainshaft	ALL
6	37904-90	RETAINING RING, external	ALL
7	37909-90	RING, retaining, internal	ALL
8	37000032A	PRESSURE PLATE, clutch	ALL
9	37000033	STOPPER PLATE	ALL
10	37000034	SPRING, damper	ALL
11	37000036	SEAT, damper-spring	ALL
12	37000083	HUB ASSEMBLY	ALL
13	37000168	BEARING, ball, double-row	ALL
14	37000169	RETAINING RING, internal	ALL
15	37000217	RELEASE ROD, clutch	ALL
16	37000219	SEAT (3)	ALL
17	37000218	PUSHROD, clutch release	ALL
18	37000254	CLUTCH ASSEMBLY, complete, with 3, 6, 8, 9, 10, 11, 12, 13, 14, 16, 19 and 20	ALL
19	37000258	CLUTCH DISKS KIT	ALL
20	37000270	COIL SPRING (3)	ALL


PRIMARY HOUSING



Index No.	Part No.	Description	Model(s)
1	786A	BOLT (5)	ALL
2	791A	SCREW (2)	ALL

3	1062	SCREW (5)	ALL
4	1775	SCREW (4)	ALL
5	4813A	SCREW (9)	ALL
6	4820A	SCREW	ALL
7	9231	BEARING	ALL
8	11105	O-RING	ALL
9	12052A	SEAL	ALL
10	16583-00A	BUSHING, dowel (2)	ALL
11	17369-06	GASKET SERVICE KIT, 1000 mi (1600 km), 5000 mi (8000 km), 10,000 mi (16,000 km), with 11105 and clutch cover seal	ALL
12	24754-75A	DOWEL BUSHING (4)	ALL
13	60328-98B	PLUG, magnetic drain, with 11105	ALL
14	60678-85	RETAINING RING	ALL
15	11000139	BUSHING	ALL
16	25700378	GASKET, primary cover	ALL
17	25700388	COVER, clutch (chrome)	ALL
18	25700418	COVER, primary (chrome)	ALL
19	25700455	GASKET, primary housing to case	ALL
20	25700650	SLEEVE, damper	ALL
21	25700746	GASKET KIT, inner primary	ALL
22	36500052	INNER PRIMARY HOUSING, with 9231, 12052A, 16583-00A, 60328-98B, 60678-85 and 11000139 (black)	ALL
23	36500075	CHAIN TENSIONER ASSEMBLY	ALL


BELT, CHAINS AND SPROCKETS



Index No.	Part No.	Description	Model(s)
1	3594	SCREW (2)	ALL
2	3892	SCREW (3)	ALL
3	9276A	BALL BEARING (2)	ALL

4	11843	SPACER, compensator	ALL
5	35241-06	NUT	ALL
6	35242-06	LOCKPLATE	ALL
7	40024-09A	REAR BELT, 140 teeth, 24 mm	ALL
8	40037-07	PRIMARY CHAIN	ALL
9	40217-09	SPROCKET AND BEARING ASSEMBLY, rear, 68 teeth, with 9276A and 11843 (black)	ALL
10	40278-09	ISOLATOR, rubber	ALL
11	60386-09	DEBRIS DEFLECTOR	ALL
12	83936-09A	SPRING PACK	ALL
13	10500031	SCREW, compensator	ALL
14	35000152	SPROCKET, transmission, 32 teeth	ALL
15	40100041	RETAINER, sprocket	ALL
16	40100064	THRUST WASHER	ALL
17	40100076	ENGINE SPROCKET KIT, compensator assembly	ALL


CLUTCH CONTROL



Index No.	Part No.	Description	Model(s)
1	4132	SCREW (2)	ALL
2	6101	WASHER (2)	ALL

3	10039	CABLE STRAP (3)	ALL
4	10264	CLIP, clutch line (2)	ALL
5	41750-06B	BOLT, BANJO	ALL
6	41751-06A	GASKET, banjo-bolt (2)	ALL
7	42856-06	DECAL, reservoir cover	ALL
8	42858-06A	SCREW KIT (set of 2)	ALL
9	42860-06B	PIVOT PIN KIT, with retaining ring	ALL
10	45138-08A	CLAMP, master cylinder and clutch (black)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	12100077	GROMMET	ALL
12	36700113	CLAMP, master cylinder and clutch (black)	FLTRU, FLTRX, FLTRXS
13	36700128	MASTER CYLINDER ASSEMBLY, clutch, with 36700130, 36700132, 36700133 and 41700367 (black)	ALL
14	36700130	MASTER CYLINDER COVER KIT, with 42856-06, 42858-06A and 36700131	ALL
15	36700131	GASKET, cover, master cylinder	ALL
16	36700132	REBUILD KIT, master cylinder	ALL
17	36700133	LEVER ASSEMBLY, hand, with 42860-06B and bushing (polished)	ALL
18	37200128	LINE ASSEMBLY, hydraulic clutch, with 12100077	FLTRX, FLTRXS
	37200129	LINE ASSEMBLY, hydraulic clutch, with 12100077	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
	37200146	LINE ASSEMBLY, hydraulic clutch, with 12100077	FLTRU
19	41600031	BRACKET, brake line	ALL
20	41700367	BUTTON, anti-bubble	ALL


BRAKE CONTROL, FRONT



Index No.	Part No.	Description	Model(s)
1	4132	SCREW (2)	ALL
2	6101	WASHER (2)	ALL

3	41750-06B	BOLT, BANJO, brake line	ALL
4	41751-06A	GASKET (2)	ALL
5	42854-06	KIT, SIGHT GLASS, reservoir	ALL
6	42855-06C	COVER KIT, master cylinder, with 42856-06, 42857-06B and 42858-06A (black)	ALL
7	42856-06	DECAL, reservoir cover	ALL
8	42857-06B	GASKET, reservoir cover	ALL
9	42858-06A	SCREW KIT, cover (set of 2)	ALL
10	42859-06B	BRAKE LEVER ASSEMBLY, front, with 42860-06B	ALL
11	42860-06B	PIVOT PIN KIT, with retaining ring	ALL
12	42861-06B	PUSHROD, master cylinder	ALL
13	42862-06B	PISTON SERVICE KIT, master cylinder	ALL
14	44551-08E	MASTER CYLINDER ASSEMBLY, front-dual, with 5, 6, 7, 8, 9, 10, 11, 12, 13 and 17 (black)	ALL
15	45138-08A	CLAMP, master cylinder and clutch (black)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
16	41700321	CLAMP, master cylinder, front brake (black)	FLTRU, FLTRX, FLTRXS
17	41700367	BUTTON, anti-bubble	ALL

MIRRORS




Index No.	Part No.	Description	Model(s)
1	7155	LOCKWASHER (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU

2	7331	ACORN NUT (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU
3	7687	NUT (2)	FLHX, FLHXS
4	8135B	PUSHNUT (2)	FLHX, FLHXS
5	91840-03B	MIRROR KIT, short, convex, with 7155 and 7331 (right) (chrome)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU
	91845-03B	MIRROR KIT, short, convex, with 7155 and 7331 (left) (chrome)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU
6	56000011	MIRROR ASSEMBLY, fairing-mounted (left) (black)	FLHX, FLHXS
	56000012	MIRROR ASSEMBLY, fairing-mounted (right) (black)	FLHX, FLHXS
7	56000015	BACKING PLATE, mirror, fairing-mounted (left)	FLHX, FLHXS
	56000016	BACKING PLATE, mirror, fairing-mounted (right)	FLHX, FLHXS
8	57300063	FAIRING PLUG KIT, with 8135B	FLHX, FLHXS

Note: For FLHX and FLHXS models order fairing plug kit 57300063 to install in the inner fairing when converting to handlebar mounted mirrors


BRAKE LINE, FRONT - NON-ABS



Index No.	Part No.	Description	Model(s)
1	4890	BLEEDER SCREW (2)	FLHR, FLHX, FLTRX
2	10006	CABLE STRAP (2)	FLHR, FLHX, FLTRX
3	41750-06B	BOLT, BANJO, brake line	FLHR, FLHX, FLTRX

4	41751-06A	GASKET (6)	FLHR, FLHX, FLTRX
5	41783-08	BOLT, BANJO, bleeder assembly, with 4890 (2)	FLHR, FLHX, FLTRX
6	42853-06	CAP, bleeder screw (2)	FLHR, FLHX, FLTRX
7	10200223	SCREW (2)	FLHR, FLHX, FLTRX
8	41600029A	BRACKET, brakeline, front	FLHR, FLHX, FLTRX
9	41800174	BRAKE LINE, front, NON-ABS	FLHR, FLHX
	41800340	BRAKE LINE, front, NON-ABS	FLTRX


BRAKE LINES, FRONT - ABS



Index No.	Part No.	Description	Model(s)
1	4890	BLEEDER SCREW (2)	ALL
2	10006	CABLE STRAP (2)	ALL

3	41750-06B	BOLT, BANJO, brake line	ALL
4	41751-06A	GASKET (10)	ALL
5	41783-08	BOLT, BANJO, bleeder assembly, with 4890 (2)	ALL
6	42853-06	CAP, bleeder screw (2)	ALL
7	10200223	SCREW (2)	ALL
8	10600007	GASKET (2)	ALL
9	11600001	BOLT, BANJO, brake line (2)	ALL
10	11600009	BOLT, BANJO, brake line	ALL
11	41600029A	BRACKET, brakeline, front	ALL
12	41600031	BRACKET, brake line	ALL
13	41600032	BRACKET, brake line	ALL
14	41800011	BRAKE LINE, front, ABS (upper)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
	41800314	BRAKE LINE, front, ABS (upper)	FLTRX, FLTRXS
	41800510	BRAKE LINE, front, ABS (upper)	FLTRU
15	41800542	BRAKE LINE, front, ABS (right)	FLTRU, FLTRX, FLTRXS
	41800543	BRAKE LINE, front, ABS (right)	FLHR, FLHRC
	41800544	BRAKE LINE, front, ABS (right)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
16	41800545	BRAKE LINE, front, ABS (left)	FLTRU, FLTRX, FLTRXS
	41800546	BRAKE LINE, front, ABS (left)	FLHR, FLHRC
	41800547	BRAKE LINE, front, ABS (left)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS

BRAKE CONTROL, REAR




Index No.	Part No.	Description	Model(s)
1	515	COTTER PIN	ALL
2	2479	SCREW (2)	ALL

3	3563	SCREW	ALL
4	6220W	WASHER	ALL
5	6416	WASHER	ALL
6	6421	WASHER	FLHX, FLHXS, FLTRX, FLTRXS
7	7549A	ACORN NUT	FLHX, FLHXS, FLTRX, FLTRXS
8	7825	LOCKNUT	ALL
9	9907	WIRE TERMINAL (2)	ALL
10	10065	CABLE STRAP	ALL
11	10076	CLAMP	ALL
12	10340B	CLAMP, brake hose, NON-ABS	FLHR, FLHX, FLTRX
13	11902	GASKET, master cylinder reservoir cover	ALL
14	12102	DUST BOOT	ALL
15	41750-06B	BOLT, BANJO, brake line, NON-ABS (2)	FLHR, FLHX, FLTRX
15	41750-06B	BOLT, BANJO, brake line, ABS	ALL
16	41751-06A	GASKET, NON-ABS (4)	FLHR, FLHX, FLTRX
16	41751-06A	GASKET, ABS (2)	ALL
17	42410-04	COVER, brake pedal	FLHX, FLHXS, FLTRX, FLTRXS
18	42416-06	PAD, brake pedal	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
19	42444-04	PAD, brake pedal	FLHX, FLHXS, FLTRX, FLTRXS
20	42460-80B	CLEVIS PIN	ALL
21	42854-06	KIT, SIGHT GLASS	ALL
22	42858-06A	SCREW KIT, cover (set of 2)	ALL
23	42889-06	SPRING RETENTION KIT, master cylinder pushrod	ALL
24	42932-08A	REBUILD KIT, master cylinder	ALL
25	42934-08	SPRING, pedal return	ALL
26	42937-08B	MASTER CYLINDER COVER KIT, rear, DOT4, with 11902 and 42858-06A	ALL
27	72023-51E	KIT SWITCH, rear stop lamp, with 9907	ALL
28	10600007	GASKET, ABS (2)	ALL
29	10800028	TUBE CLIP (lower)	ALL
30	11000050	BUSHING, brake lever (2)	ALL
31	11600009	BOLT, BANJO, brake line, ABS	ALL
32	11900021	O-RING (2)	ALL
33	41600091	TUBE CLIP (upper)	ALL
34	41700028	MASTER CYLINDER ASSEMBLY, with 13, 14, 21, 22, 23, 24, 25, 26 and 35	ALL
35	41700195	PUSHROD KIT, master cylinder	ALL
36	41800012	BRAKE LINE, right-rear, master cylinder to ABS UNIT, ABS, with 10065, 10076, 10800028 and 41600091	ALL
37	41800175	BRAKE LINE, right-rear, master cylinder to rear caliper, NON-ABS, with	FLHR, FLHX, FLTRX

		10065, 10076, 10800028 and 41600091	
38	50600067	LEVER ASSEMBLY, foot-brake, with 11000050	ALL


BRAKE LINES AND MODULE, REAR - ABS



Index No.	Part No.	Description	Model(s)
1	1062	SCREW	ALL
2	3563	SCREW	ALL

3	10065	CABLE STRAP	ALL
4	10076	CLAMP	ALL
5	10340B	CLAMP, brake hose (2)	ALL
6	41750-06B	BOLT, BANJO, brake line, ABS (2)	ALL
7	41751-06A	GASKET (6)	ALL
8	70631-08	CLIP, conduit	ALL
9	10600007	GASKET (2)	ALL
10	10800028	TUBE CLIP (lower)	ALL
11	11600001	BOLT, BANJO, brake line	ALL
12	11600009	BOLT, BANJO, brake line	ALL
13	12100007	GROMMET, ABS mounting	ALL
14	41100061	ABS MODULE (EHCU)	ALL
15	41600078	BRACKET, ABS brake line alignment	ALL
16	41600091	TUBE CLIP (upper)	ALL
17	41800012	BRAKE LINE, ABS module to master cylinder, with 10065, 10076, 10800028 and 41600091	ALL
18	41800541	BRAKE LINE, ABS module to caliper	ALL
19	69201417	CADDY, ABS module	ALL


BRAKE CALIPER, FRONT



Index No.	Part No.	Description	Model(s)
1	41854-08	PAD AND PIN KIT, with 42849-08 (2)	ALL
2	42849-08	PAD PIN KIT (2)	ALL
3	42851-06	COVER, caliper (2)	ALL

4	42852-06A	PAD SPRING, anti-rattle (2)	ALL
5	43027-08	CALIPER ASSEMBLY (left) (black)	ALL
	44023-08	CALIPER ASSEMBLY (right) (black)	ALL
6	44160-00	BOLT, caliper mounting (lower) (4)	ALL
7	44341-08	MEDALLION, brake caliper (2)	ALL


BRAKE CALIPER, REAR



Index No.	Part No.	Description	Model(s)
1	4597M	SCREW (2)	ALL
2	4890	BLEEDER SCREW	ALL

3	41852-08B	PAD AND PIN KIT	ALL
4	42853-06	CAP, bleeder screw	ALL
5	42863-06	BUMPER	ALL
6	42865-06B	PAD PIN KIT	ALL
7	42867-06A	SPRING KIT, anti-rattle	ALL
8	44080-08C	CALIPER ASSEMBLY, rear, with 4890, 41852-08B, 42853-06, 42865-06B and 42867-06A (black)	ALL
9	44089-08	BRACKET, reaction, rear brake, with 42863-06	ALL

WHEELS, FRONT




Index No.	Part No.	Description	Model(s)
1	3655A	SCREW (used with 40960-09) (10)	FLHRC
2	6594	WASHER	ALL

3	7813A	NUT	ALL
4	9252	BALL BEARING, with encoder, ABS	ALL
5	9276A	BALL BEARING, NON-ABS (2)	FLHR, FLHX, FLTRX
5	9276A	BALL BEARING, ABS	ALL
6	40558-82	INNER TUBE, 16 in, side valve, with 54321-85	FLHRC
7	40960-09	WHEEL ASSEMBLY, 16 in laced, without bearings and sleeve, with 43085-97 and 43241-05	FLHRC
8	40999-87	VALVE STEM, for cast wheels	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
9	41123-79	VALVE CAP	ALL
10	41547-07A	AXLE	ALL
11	41808-08A	BRAKE DISC (right) (used with 40960-09)	FLHRC
12	41809-08A	BRAKE DISC (left) (used with 40960-09)	FLHRC
13	41900-08	SLEEVE, bearing spacer	ALL
14	41901-08	SPACER, NON-ABS (right and left) (2)	FLHR, FLHX, FLTRX
14	41901-08	SPACER, ABS (right only)	ALL
15	43085-97	RIM, 16 in (chrome)	FLHRC
16	43109-09A	TIRE, black wall, 17 in	FLHR, FLHTCU, FLHTK, FLHTKL, FLTRU
	43118-92A	TIRE, wide white wall, 16 in	FLHRC
	43100013	TIRE, black wall, 19 in	FLHX, FLHXS, FLTRX, FLTRXS
17	43147-40	RIM STRIP, 16 in, side valve (used with 43085-97)	FLHRC
18	43241-05	SPOKE AND NIPPLE KIT, 16 in, set of 40	FLHRC
19	54321-85	NUT (2)	FLHRC
20	70493-08	BRACKET, wheel speed sensor, ABS	ALL
21	70494-08	CLIP, wheel speed sensor, ABS	ALL
22	72607-08	HOUSING, two-way pin (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
23	72608-08	TERMINAL, pin, 16-20 AWG (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
24	70631-08	CLIP, conduit, ABS (3)	ALL
25	72639-10	SECONDARY LOCK, two-way socket	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
26	74190-98	TERMINAL, pin, 16-20 AWG (2)	FLHR, FLHRC
27	95594-84B	WEIGHT, 5 g (black) (10)	FLHR, FLHTCU, FLHTK, FLHX, FLHXS, FLTRX, FLTRXS
	95595-84B	WEIGHT, 5 g (silver) (6)	FLHRC
28	32700015	SENSOR, wheel speed, ABS, with 72607-08, 72608-08 and 72639-10	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
29	32700017	SENSOR, wheel speed, ABS, with 74190-08	FLHR, FLHRC
30	41500017	BRAKE ROTOR, front (used with 43300019, 43300027 and 43300386) (2)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
31	41500018	BUSHING, front rotor (used with 43300019, 43300027 and 43300386) (10)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
32	41500019	SPRING, front rotor (used with 43300019, 43300027 and	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX,

		43300386) (10)	FLHXS, FLTRU, FLTRX, FLTRXS
33	41500020	SCREW (used with 43300019, 43300027 and 43300386) (10)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
34	43300019	WHEEL, cast, without bearings and sleeve, 10 spoke, 17 in (black)	FLHR, FLHTCU, FLTRU
35	43300027	WHEEL, cast, without bearings and sleeve, 5 spoke, 19 in (black)	FLHX, FLHXS, FLTRX, FLTRXS
36	43300386	WHEEL, cast, without bearings and sleeve, 10 spoke, 17 in (contrast chrome)	FLHTK, FLHTKL


WHEELS, REAR



Index No.	Part No.	Description	Model(s)
1	8020	NUT, slotted	ALL
2	9252	BALL BEARING, with encoder, ABS	ALL

3	9276A	BALL BEARING, ABS (3)	ALL
3	9276A	BALL BEARING, NON-ABS (4)	FLHR, FLHX, FLTRX
4	10147	CLIP, connector	ALL
5	11843	SPACER, compensator	ALL
6	11848	SPACER	ALL
7	40217-09	SPROCKET AND BEARING ASSEMBLY, rear, 68 teeth, with 9276A and 11843 (black)	ALL
8	40278-09	ISOLATOR, rubber	ALL
9	40592-09	INNER TUBE, 16 in, with 54321-85	FLHRC
10	40615-08	SENSOR, wheel speed, ABS, with 10147, 72607-08, 72608-08 and 72639-10	ALL
11	40999-87	VALVE STEM, cast wheels	FLHR, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
12	41052-09	WHEEL ASSEMBLY, 16 in laced, without bearings and sleeve, with 41445-09, 41746-09 and 42018-09	FLHRC
13	41123-79	VALVE CAP	ALL
14	41229-08	C-CLIP	ALL
15	41242-08	SPACER, wheel bearing, NON-ABS	FLHR, FLHX, FLTRX
16	41349-07	SLEEVE, bearing spacer	ALL
17	41445-09	RIM, 16 in (chrome)	FLHRC
18	41746-09	SPOKE AND NIPPLE KIT, 16 in, set of 20, short-head (used with 41052-09)	FLHRC
19	41810-08B	BRAKE DISC	ALL
20	41819-02	AXLE CAM	ALL
21	42018-09	SPOKE AND NIPPLE KIT, 16 in, set of 20, long-head (used with 41052-09)	FLHRC
22	43099-09	RIM STRIP, center valve	FLHRC
23	43230-09	TIRE, 16 in wide white wall	FLHRC
	43200027	TIRE, 16 in black wall	FLHR, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
24	43567-92	SCREW (5)	ALL
25	54321-85	NUT (2)	FLHRC
26	72607-08	HOUSING, two-way pin (black)	ALL
27	72608-08	TERMINAL, pin, 16-20 AWG (2)	ALL
28	72639-10	SECONDARY LOCK, two-way socket	ALL
29	95594-84B	WEIGHT, 5 g (black) (10)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	95595-84B	WEIGHT, 5 g (silver) (6)	FLHRC
30	40900026	WHEEL, 16 inch cast, without bearings and sleeve, 10 spoke (black)	FLHR, FLHTCU, FLTRU
31	40900033	WHEEL ASSEMBLY, 16 in cast, without bearings and sleeve, 5 spoke (black)	FLHX, FLHXS, FLTRX, FLTRXS
32	40900391	WHEEL, 16 in cast, without bearings and sleeve, 10 spoke (contrast chrome)	FLHTK, FLHTKL
33	43000002	REAR AXLE	ALL


FORK BRACKETS, FRONT



Index No.	Part No.	Description	Model(s)
1	4240	SCREW (2)	ALL
2	10200042	SCREW (4)	ALL
3	10200223	SCREW (2)	ALL

4	10500022	SCREW (6)	ALL
5	10500036	SCREW	ALL
6	41600029A	BRACKET, brakeline, front	ALL
7	45600003	COVER ASSEMBLY, fork tube (left)	ALL
8	45700009	BEARING KIT, steering head, with bearing cups, bearing cones and dirt guards	ALL
9	45700020A	STEM ASSEMBLY, upper steering, with bearing cone and dirt guard	ALL
10	45800023	COVER ASSEMBLY, fork tube (right)	ALL
11	45900024	BRACKET, upper fork stem	ALL
12	45900091A	BRACKET ASSEMBLY, lower fork, with bearing cone and dirt guard	ALL
13	69200224	WIRE HARNESS, triple clamp, ground jumper	ALL


FORK, FRONT, LEFT AND RIGHT - STANDARD



Index No.	Part No.	Description	Model(s)
1	46508-01	O-RING (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS

2	46509-01	WASHER (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
3	46513-01	RING, stopper (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
4	46514-01A	OIL SEAL (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
5	46515-01	SPACER, seal (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
6	46615-06	PACKING SEAL (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
7	59481-00	REFLECTOR (right) (amber)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
8	59482-00	REFLECTOR (left) (amber)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
9	22000031	PISTON RING (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
10	45400102	FORK ASSEMBLY, complete (left)	FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	45400181	FORK ASSEMBLY, complete (left)	FLHR, FLHRC
11	45400103	FORK ASSEMBLY, complete (right)	FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	45400182	FORK ASSEMBLY, complete (right)	FLHR, FLHRC
12	45500109	SLIDER, fork (left)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
13	45500111	SLIDER, fork (right)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
14	45500117	BOLT, fork (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
15	45500118	SCREW (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
16	45500132	SCREW (right)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
17	45500337	SPRING, fork (2)	FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	45500456	SPRING, fork (2)	FLHR, FLHRC
18	45500339	DAMPER TUBE, with 22000031 (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
19	45500341	FORK PIPE ASSEMBLY, with 45500424 (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
20	45500396	SPRING, rebound (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
21	45500397	OIL LOCK PIECE (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
22	45500398	COLLAR, spring (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
23	45500421	BUSHING GUIDE (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
24	45500424	BUSHING, slider (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
25	91700025A	FORK REBUILD KIT, with 1, 3, 4, 5, 6, 9, 15, 23 and 24 (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS


FORK, FRONT, LEFT AND RIGHT - LOW



Index No.	Part No.	Description	Model(s)
1	46508-01	O-RING (2)	FLHTKL
2	46509-01	WASHER (right)	FLHTKL
3	46513-01	RING, stopper (2)	FLHTKL

4	46514-01A	OIL SEAL (2)	FLHTKL
5	46515-01	SPACER, seal (2)	FLHTKL
6	46615-06	PACKING SEAL (2)	FLHTKL
7	59481-00	REFLECTOR (right) (amber)	FLHTKL
8	59482-00	REFLECTOR (left) (amber)	FLHTKL
9	22000031	PISTON RING (2)	FLHTKL
10	45400104	FORK ASSEMBLY, complete (right)	FLHTKL
11	45400105	FORK ASSEMBLY, complete (left)	FLHTKL
12	45500109	SLIDER, fork (left)	FLHTKL
13	45500111	SLIDER, fork (right)	FLHTKL
14	45500117	BOLT, fork (2)	FLHTKL
15	45500118	SCREW (2)	FLHTKL
16	45500132	SCREW (right)	FLHTKL
17	45500338	SPRING, fork (2)	FLHTKL
18	45500340	DAMPER TUBE, with 22000031	FLHTKL
19	45500341	FORK PIPE ASSEMBLY, with 45500424 (2)	FLHTKL
20	45500396	SPRING, rebound (2)	FLHTKL
21	45500397	OIL LOCK PIECE (2)	FLHTKL
22	45500398	COLLAR, spring (2)	FLHTKL
23	45500421	BUSHING GUIDE (2)	FLHTKL
24	45500424	BUSHING, slider (2)	FLHTKL
25	91700025A	FORK REBUILD KIT, with 1, 3, 4, 5, 6, 9, 15, 23 and 24 (2)	FLHTKL


SHOCK ABSORBERS, REAR



Index No.	Part No.	Description	Model(s)
1	3607	BOLT (4)	ALL
2	6590HW	WASHER (4)	ALL
3	90820-93D	LABEL, saddlebag load limits, inside right saddlebag	ALL

4	54000093	REAR SHOCK ABSORBER (right)	FLHR, FLHRC, FLHTCU, FLHTK, FLTRU
	54000114	REAR SHOCK ABSORBER (right)	FLHTKL, FLHX, FLHXS, FLTRX, FLTRXS
5	54000094	REAR SHOCK ABSORBER, with 54000141 (left)	FLHTCU, FLHTK, FLTRU
	54000095	REAR SHOCK ABSORBER, with 54000141 (left)	FLHR, FLHRC
	54000096	REAR SHOCK ABSORBER, with 54000141 (left)	FLHX, FLHXS, FLTRX, FLTRXS
	54000113	REAR SHOCK ABSORBER, with 54000141 (left)	FLHTKL
6	54000141	KNOB SERVICE KIT	ALL


FRAME AND JIFFY STAND



Index No.	Part No.	Description	Model(s)
1	2708A	SCREW	ALL
2	3594	SCREW (England, HDI, Brazil)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS,

			FLTRU, FLTRXS
3	3987	BOLT	ALL
4	4688	SCREW (2)	ALL
5	4924	SCREW (2)	ALL
6	6116	WASHER	ALL
7	6702	WASHER	ALL
8	7041	LOCKWASHER	ALL
9	7495	NUT (2)	ALL
10	10177	CABLE STRAP, anchored, jiffy stand (England, HDI)	ALL
11	10039	CABLE STRAP (9)	ALL
12	10264	CLIP, clutch line (2)	ALL
13	49184-09A	ENGINE GUARD, with 2708A, 6116 and 14148-86	ALL
14	49725-07A	SPRING, jiffy stand	ALL
15	50015-74A	LEG STOP	ALL
16	50075-07A	LEG, jiffy stand	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
17	50126-08A	SENSOR, jiffy stand, with 72169-07, 72511-07BK and 73213-07 (England, HDI, Brazil)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
18	50245-07	BUMPER, jiffy stand leg	ALL
19	72169-07	TERMINAL, pin, 16-20 AWG (England, HDI, Brazil) (3)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
20	72511-07BK	HOUSING, three-way pin (black) (England, HDI, Brazil)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
21	73213-07	RETAINER, anchored (England, HDI, Brazil)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
22	90520-07	HOLE PLUG, jiffy stand (except England, HDI, Brazil)	ALL
23	10200546	SCREW	ALL
24	10800025A	CLIP, conduit, anchored (2)	ALL
25	12200147A	CLIP, retaining	ALL
26	12600067	FASTENER, plastic (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
27	12600197	FASTENER, anchored (2)	ALL
28	14000827	CLEAR OVERLAY, VIN label (Japan)	FLHRC, FLHTK, FLHXS, FLTRU, FLTRXS
29	45700009	BEARING KIT, steering head, with bearing cups, bearing cones and dirt guards	ALL
30	47000088BHP	FRAME, main, with bearing cups (Also order 45700009)	ALL
31	50000083	LEG, jiffy stand	FLHTKL
32	50000097	BRACKET, jiffy stand leg	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	50000141A	BRACKET, jiffy stand leg	FLHTKL


COVERS AND AIR DEFLECTORS



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	3787	BOLT (4)	FLHTCU, FLHTK, FLHTKL,

			FLTRU
1	3787	BOLT (Brazil) (4)	FLHRC, FLHXS
2	6036	WASHER (4)	FLHTCU, FLHTK, FLHTKL, FLTRU
2	6036	WASHER (Brazil) (4)	FLHRC, FLHXS
3	8194	NUT, special (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
3	8194	NUT, special (Brazil) (2)	FLHRC, FLHXS
4	11650	GROMMET, side cover (6)	ALL
5	58167-09A	DEFLECTOR, air (right)	FLHTCU, FLHTK, FLHTKL, FLTRU
	58169-09	DEFLECTOR, air (left)	FLHTCU, FLHTK, FLHTKL, FLTRU
5	58167-09A	DEFLECTOR, air (right) (Brazil)	FLHRC, FLHXS
	58169-09	DEFLECTOR, air (left) (Brazil)	FLHRC, FLHXS
6	66048-09A	SIDE COVER (right) (unpainted)	ALL
	66250-09	SIDE COVER (left) (unpainted)	ALL
7	57200066	WIND DEFLECTOR (left)	FLTRU
	57200065	WIND DEFLECTOR (right) (not shown)	FLTRU
8	69200202A	WIRE TROUGH (main harness)	ALL
9	69200203A	COVER, wire trough, with 15368-01A and 69201459 (main harness)	ALL
10	69201459	BRACKET	ALL


FRAME AND FORK, REAR AND TOUR-PAK SUPPORT



Index No.	Part No.	Description	Model(s)
1	2731W	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
2	3057	SCREW (4)	ALL

3	3536	BOLT (6)	ALL
4	3684	SCREW (4)	ALL
5	6532	WASHER (6)	ALL
6	6982	WASHER, hex cup (2)	ALL
7	9208	BEARING (2)	ALL
8	11779	FASTENER, push-in (black)	ALL
9	47540-11	SHAFT, rear fork	ALL
10	47549-09A	REAR FORK, with 9208, 11779 and 48489-02	ALL
11	47584-09	RUBBER MOUNT (2)	ALL
12	48079-09BHP	FRAME, rear	ALL
13	48487-02	SPACER, outer (2)	ALL
14	48489-02	SPACER, inner (2)	ALL
15	59292-94	NUT, plastic (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
16	67875-11	CAP (2)	ALL
17	10200155	SCREW (8)	FLHTCU, FLHTK, FLHTKL, FLTRU
18	10200217	SCREW (2)	ALL
19	11100068	CUSHION (2)	ALL
20	16400005	BRACKET, rear fork (left)	ALL
21	47200080	COVER, Tour-Pak support (right) (chrome)	FLHTCU, FLHTK, FLHTKL, FLTRU
22	47200081	COVER, Tour-Pak support (left) (chrome)	FLHTCU, FLHTK, FLHTKL, FLTRU
23	53000125	TOUR-PAK SUPPORT (black)	FLHTCU, FLHTK, FLHTKL, FLTRU
24	90200499	SUPPORT, saddlebag, with 11100068 (right) (chrome)	ALL
	90200501	SUPPORT, saddlebag, with 11100068 (left) (chrome)	ALL
25	90200547	INSERT ASSEMBLY, saddlebag support (2)	FLHR, FLHRC, FLHX, FLHXS, FLTRX, FLTRXS


SEATS



Index No.	Part No.	Description	Model(s)
1	2952A	SCREW (3)	ALL
2	3901	SCREW (2)	ALL

3	4924	SCREW (2)	FLHX, FLHXS, FLTRX, FLTRXS
4	6026	WASHER (3)	FLHTCU, FLHTK, FLHTKL, FLTRU
5	6703	WASHER (2)	ALL
6	7531	LOCKNUT (3)	FLHTCU, FLHTK, FLHTKL, FLTRU
7	52320-11	SEAT	FLHX, FLHXS
	52000142	SEAT	FLTRX, FLTRXS
8	54395-10	SEAT BUMPER KIT, with 4924	FLHX, FLHXS, FLTRX, FLTRXS
9	59768-97	SEAT NUT KIT, with nut and retention washer	ALL
10	52000033	SEAT (except Asia-Pacific)	FLHTCU, FLHTK, FLTRU
	52000122	SEAT (Asia-Pacific)	FLHTK, FLTRU
	52000173	SEAT (except Asia-Pacific)	FLHTKL
	52000174	SEAT (Asia-Pacific)	FLHTKL
11	52000038	SEAT	FLHR
12	52000060	SEAT	FLHRC
13	52300053	BACKREST ASSEMBLY, with 6026, 7531, 52300121, 52300122, 52300123 and 52300127 (black)	FLHTCU, FLHTK, FLHTKL, FLTRU
14	52300121	SUPPORT BRACKET, center	FLHTCU, FLHTK, FLHTKL, FLTRU
15	52300122	SUPPORT BRACKET (right)	FLHTCU, FLHTK, FLHTKL, FLTRU
16	52300123	SUPPORT BRACKET (left)	FLHTCU, FLHTK, FLHTKL, FLTRU
17	52300127	KIT, BACKREST ISOLATION, passenger backrest (3)	FLHTCU, FLHTK, FLHTKL, FLTRU
18	52400015	PASSENGER STRAP	FLHTCU, FLHTK, FLTRU
	52400017	PASSENGER STRAP	FLHX, FLHXS, FLTRX, FLTRXS
	52400018	PASSENGER STRAP	FLHR
	52400099	PASSENGER STRAP (except Asia-Pacific)	FLHTKL
	52400116	PASSENGER STRAP (Asia-Pacific)	FLHTKL
19	52400054	PASSENGER STRAP, with 52400067	FLHRC
20	52400016	BRACKET, passenger strap (right)	ALL
21	52400021	BRACKET, passenger strap, (left)	ALL
22	52400067	BUCKLE, passenger strap (2)	FLHRC


FOOTBOARDS, OPERATOR



Index No.	Part No.	Description	Model(s)
1	4688	SCREW (2)	ALL
2	7038	LOCKWASHER (2)	ALL

3	7716	LOCKNUT (4)	ALL
4	50518-09	BRACKET, right rear	ALL
5	50614-06	PAD, footboard (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
6	50621-06	FOOTBOARD ASSEMBLY, operator, with 50614-06 (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLTRU
7	50622-09A	BRACKET, left rear	ALL
8	50674-05	SHOULDER BOLT, footboard (4)	ALL
9	50683-04	FOOTBOARD BOTTOM ASSEMBLY (right)	FLHX, FLHXS, FLTRX, FLTRXS
10	50684-11	RUBBER PAD, footboard (right)	FLHX, FLHXS, FLTRX, FLTRXS
11	50688-04	FOOTBOARD BOTTOM ASSEMBLY (left)	FLHX, FLHXS, FLTRX, FLTRXS
12	50689-11	RUBBER PAD, footboard (left)	FLHX, FLHXS, FLTRX, FLTRXS
13	10200429	SCREW (2)	ALL
14	10500053	SCREW (4)	FLHTKL
15	47200302A	BRACKET, front footboard (2)	ALL
16	50500339	FEELER, footboard (2)	FLHTKL
17	50500360	FOOTBOARD BOTTOM ASSEMBLY (2)	FLHTKL


FOOTBOARDS AND FOOTPEGS, PASSENGER



Index No.	Part No.	Description	Model(s)
1	2708A	SCREW (2)	FLHX, FLHXS, FLTRX, FLTRXS
2	3143	SCREW (2)	ALL

3	4916	SCREW (2)	ALL
4	7038	LOCKWASHER (4)	ALL
5	8860	BALL (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLTRU
6	11304	RING, retaining, passenger footpeg support (2)	FLHTKL, FLHX, FLHXS, FLTRX, FLTRXS
7	33085-74	SPRING (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLTRU
8	45041-01A	CLEVIS PIN, passenger footpeg support (2)	FLHTKL, FLHX, FLHXS, FLTRX, FLTRXS
9	50208-04	MOUNT, passenger footpeg (2)	FLHX, FLHXS, FLTRX, FLTRXS
10	50345-04	FOOTPEG, passenger (2)	FLHX, FLHXS, FLTRX, FLTRXS
11	50350-04	PAD, passenger footpeg (2)	FLHX, FLHXS, FLTRX, FLTRXS
12	50606-06	PAD, passenger footboard (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLTRU
13	50613-91A	FOOTBOARD, passenger (Domestic) (2)	FLHR, FLHTCU, FLHTK, FLTRU
	50899-99A	FOOTBOARD, passenger (HDI) (2)	FLHRC, FLHTK, FLTRU
14	50912-72	SPRING WASHER, passenger footpeg (2)	FLHTKL, FLHX, FLHXS, FLTRX, FLTRXS
15	50933-86A	PIVOT PIN (4)	FLHR, FLHRC, FLHTCU, FLHTK, FLTRU
16	52719-10	SUPPORT KIT, footboard (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLTRU
17	12600031	SCREW (2)	FLHTKL
18	50500143	TREAD, footboard (2)	FLHTKL
19	50500145	FOOTBOARD ASSEMBLY, with 12600031 and 50500143 (right)	FLHTKL
20	50500146	FOOTBOARD ASSEMBLY, with 12600031 and 50500143 (left)	FLHTKL
21	50500332A	SUPPORT, right passenger floorboard (black)	FLHTKL
22	50500334A	SUPPORT, left passenger floorboard (black)	FLHTKL
23	50500460A	SUPPORT, left passenger footpeg (chrome)	FLHX, FLHXS, FLTRX, FLTRXS
24	50500462A	SUPPORT, right passenger footpeg (chrome)	FLHX, FLHXS, FLTRX, FLTRXS


FENDERS, FRONT



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	755	HOLE PLUG	FLHR, FLHRC, FLHTCU

2	2531	SCREW (6)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL
3	3560WA	BOLT (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL
4	3561WC	BOLT (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL
5	3612	SCREW (2)	FLHR, FLHRC, FLHTCU
6	7600	NUT (6)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL
7	7624	LOCKNUT (4)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL
8	7629	NUT (2)	FLHTK, FLHTKL
9	10065	CABLE STRAP (3)	ALL
10	11437	GROMMET, wiring harness	FLHTK, FLHTKL
11	59211-74A	TRIM, front fender (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL
12	73191-96	TERMINAL, socket, 16-20 AWG (2)	FLHTK, FLHTKL
13	73152-96BK	HOUSING, two-way socket (black)	FLHTK, FLHTKL
	73152-96WE	SOCKET HOUSING, two-way (without fender tip light) (white)	FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
14	10500015	SCREW (4)	ALL
15	12200092	CLIP, retaining (6)	FLHR, FLHRC, FLHTCU
16	14100230	NAMEPLATE, Road King (2)	FLHR, FLHRC
17	14100231	NAMEPLATE, Ultra (2)	FLHTCU
18	14100232	NAMEPLATE, Limited (2)	FLHTK, FLHTKL
19	58900009	FENDER (prime)	FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	58900032	FENDER (prime)	FLHR, FLHRC, FLHTK, FLHTKL
20	59600003	FENDER LIGHT ASSEMBLY, with 73191-96 (Domestic) (amber)	FLHTK, FLHTKL
21	59600006	FENDER LIGHT ASSEMBLY, with 73191-96 (HDI) (white)	FLHTK, FLHTKL
22	59600009	FRONT FENDER TIP	FLHR, FLHRC
23	59600011	FRONT FENDER TIP	FLHTCU
24	61400057	TRIM SKIRT, front fender (lower)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL


FENDERS, REAR (1 OF 2)



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	2995	SCREW (2)	FLHX, FLHXS, FLTRX, FLTRXS
2	3684	SCREW (6)	ALL

3	6703	WASHER	ALL
4	7434	WASHER (2)	ALL
5	7499	NUT (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
5	7499	NUT (8)	FLHX, FLHXS, FLTRX, FLTRXS
6	7531	LOCKNUT (2)	ALL
7	7686	LOCKNUT	ALL
8	7880	NUT (4)	ALL
9	10006	CABLE STRAP	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
10	10053	CLAMP (Domestic, Brazil)	FLHTCU, FLHTK, FLHTKL, FLTRU
10	10053	CLAMP	FLHX, FLHXS, FLTRX, FLTRXS
11	10183	CLIP, T-stud (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
11	10183	CLIP, T-stud (Canada)	FLHX, FLHXS, FLTRX, FLTRXS
12	10184	CLIP, T-stud (Domestic)	FLHR
12	10184	CLIP, T-stud (Canada)	FLHX, FLHXS, FLTRX, FLTRXS
12	10184	CLIP, T-stud (HDI)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU
13	11687	GROMMET, right angle (except Canada)	FLHX, FLHXS, FLTRX, FLTRXS
14	11891	SPACER (2)	FLHX, FLHXS, FLTRX, FLTRXS
15	58702-09	FENDER, rear (prime)	FLHR, FLHRC
	58702-09	FENDER, rear (prime) (HDI)	FLHTK, FLHTKL, FLTRU
	59500046	FENDER, rear (prime) (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
	59731-09	FENDER, rear (prime) (Canada)	FLHX, FLHXS, FLTRX, FLTRXS
	60575-10	FENDER, rear (prime) (Not Canada)	FLHX, FLHXS, FLTRX, FLTRXS
16	59174-99	STUD PLATE	ALL
17	59581-05	BUMPER, rear fender (black) (Domestic)	FLHR, FLHX, FLHXS, FLTRX, FLTRXS
17	59581-05	BUMPER, rear fender (black) (HDI)	FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
17	59581-05	BUMPER, rear fender (black) (Brazil)	FLHRC, FLHTK, FLHXS
18	59739-09	FASCIA, rear fender (unpainted)	FLHX, FLHXS, FLTRX, FLTRXS
19	59749-06	PLUG	FLHX, FLHXS, FLTRX, FLTRXS
20	59778-06	GROMMET	FLHX, FLHXS, FLTRX, FLTRXS
21	59786-01	FENDER MOUNTING BOSS, inner (4)	ALL
22	59788-01	FENDER MOUNTING WASHER (4)	ALL
23	59818-09	STUD PLATE (2)	FLHX, FLHXS, FLTRX, FLTRXS
24	67266-94	BUSHING, nylon, turn signal (2)	FLHR
24	67266-94	BUSHING, nylon, turn signal (HDI) (2)	FLHRC, FLHTK, FLHTKL, FLTRU
24	67266-94	BUSHING, nylon, turn signal (Canada) (2)	FLHX, FLHXS, FLTRX, FLTRXS


FENDERS, REAR (2 OF 2)



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
25	69377-10	REAR FENDER LENS ASSEMBLY (Canada, HDI, Brazil)	FLHX, FLHXS, FLTRX, FLTRXS

	59600008	REAR FENDER LIGHT ASSEMBLY (Domestic, California)	FLHX, FLHXS, FLTRX, FLTRXS
26	69615-10	SPLASH GUARD, fender tip lamp	FLHX, FLHXS, FLTRX, FLTRXS
27	70522-06B	CONDUIT, self-adhesive	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
28	72130-04	HOUSING, 12-way socket (Domestic, California, HDI) (black)	FLHX, FLHXS, FLTRX, FLTRXS
28	72130-04	HOUSING, 12-way socket (Canada) (black) (2)	FLHX, FLHXS, FLTRX, FLTRXS
29	72168-07	TERMINAL, socket, 18-20 AWG (12)	ALL
30	72189-04	SEAL PIN (Domestic, California) (5)	FLHX, FLHXS, FLTRX, FLTRXS
30	72189-04	SEAL PIN (Canada) (10)	FLHX, FLHXS, FLTRX, FLTRXS
30	72189-04	SEAL PIN (HDI) (10)	FLHX, FLHXS, FLTRX, FLTRXS
31	72414-07BK	HOUSING, six-way socket (black)	ALL
32	73156-96BK	SOCKET HOUSING, six-way (black)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
32	73156-96BK	SOCKET HOUSING, six-way (Canada) (black)	FLHX, FLHXS, FLTRX, FLTRXS
33	73191-96	TERMINAL, socket, 16-20 AWG (6)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL
33	73191-96	TERMINAL, socket, 16-20 AWG (6)	FLHX, FLHXS, FLTRX, FLTRXS
33	73191-96	TERMINAL, socket, 16-20 AWG (Canada) (12)	FLHX, FLHXS, FLTRX, FLTRXS
34	74196-04	TERMINAL, socket, 20 AWG (7)	FLHX, FLHXS, FLTRX, FLTRXS
34	74196-04	TERMINAL, socket, 20 AWG (Canada) (14)	FLHX, FLHXS, FLTRX, FLTRXS
35	74197-04	SECONDARY LOCK, 12-way socket	FLHX, FLHXS, FLTRX, FLTRXS
35	74197-04	SECONDARY LOCK, 12-way socket (Canada) (2)	FLHX, FLHXS, FLTRX, FLTRXS
36	91140-09	BRACKET, saddlebag to fender support	ALL
37	10500017	SCREW (Domestic) (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
38	59600029	FENDER TIP, rear (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
39	69200128	HARNESS, rear lamps, with 10006, 70522-06B, 72168-07, 72414, 73156-96BK and 73191-96	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
40	69200129	HARNESS, rear lighting jumper, with 72130-04, 72168-07, 72189-04, 72414-07BK, 74196-04 and 74197-04	FLHX, FLHXS, FLTRX, FLTRXS
41	69200130	HARNESS, rear lighting, jumper, with 72130-04, 72189-04, 73191-96, 73156-96BK, 74196-04 and 74197-04 (Canada)	FLHX, FLHXS, FLTRX, FLTRXS


LICENSE PLATE BRACKETS



Index No.	Part No.	Description	Model(s)
1	2446	SCREW (except Canada) (2)	FLHX, FLHXS, FLTRX, FLTRXS
1	2446	SCREW (HDI) (2)	FLHTK, FLHTKL, FLTRU

2	3061	SCREW (2)	FLHR
2	3061	SCREW (Canada) (2)	FLHX, FLHXS, FLTRX, FLTRXS
2	3061	SCREW (HDI) (2)	FLHRC
3	7036	WASHER (2)	FLHR, FLHX, FLHXS, FLTRX, FLTRXS
3	7036	WASHER (HDI) (2)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU
4	59259-90	REFLECTOR (red) (Domestic, California)	FLHX, FLHXS, FLTRX, FLTRXS
4	59259-90	REFLECTOR (red) (HDI)	FLHR, FLHRC, FLHXS, FLTRXS
5	59988-72A	REFLECTOR (Domestic)	FLHR, FLHTCU, FLHTK, FLHTKL, FLTRU
5	59988-72A	REFLECTOR (HDI, Brazil)	FLHTK, FLHTKL
6	60907-09	BRACKET, reflector	FLHR
7	60909-09	BUMPER, license plate bracket	FLHR
7	60909-09	BUMPER, license plate bracket (Canada)	FLHX, FLHXS, FLTRX, FLTRXS
8	60918-10A	LICENSE PLATE BRACKET (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
8	60918-10A	LICENSE PLATE BRACKET (HDI)	FLHTK, FLHTKL, FLTRU
9	69380-09BHP	BRACKET, license plate (black)	FLHR
9	69380-09BHP	BRACKET, license plate (Canada) (black)	FLHX, FLHXS, FLTRX, FLTRXS
9	69380-09BHP	BRACKET, license plate (black) (HDI)	FLHR, FLHRC
10	73255-10	BRACKET, license plate (Domestic, California) (black)	FLHX, FLHXS, FLTRX, FLTRXS
10	73255-10	BRACKET, license plate (HDI) (black)	FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
11	11100195	CUSHION (HDI)	FLHR, FLHRC
12	12400100	SPACER (HDI)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU
13	67900213A	BRACKET, reflector (Domestic, California) (black)	FLHX, FLHXS, FLTRX, FLTRXS
13	67900213A	BRACKET, reflector (HDI) (black)	FLHXS, FLTRXS
14	67900445	LICENSE PLATE BRACKET, with 59259-90 and 11100195 (HDI)	FLHR, FLHRC


FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX
AND FLTRXS



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			

1	3634	SCREW (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
2	10039	CABLE STRAP (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
3	10396	RETAINER, fuel line, 3/8 in (natural)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
4	11323A	O-RING, check valve to tank	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
5	27291-09A	TUBE, evaporative line, tank	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
6	27440-09A	TUBE, evaporative line (except California, Asia-Pacific and Brazil)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
7	61356-08	FUEL TANK (prime)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
8	62228-08C	CHECK VALVE, assembly, with 10396 and 11323A	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
9	70901-09	BOOT, tank bracket (right)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
10	70999-09	BOOT, tank bracket (left)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
11	61200022	FUEL LINE, tank to intake	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS


FUEL TANK - FLHR AND FLHRC



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	3634	SCREW (4)	FLHR, FLHRC
2	10039	CABLE STRAP (2)	FLHR, FLHRC

3	10396	RETAINER, fuel line, 3/8 in (natural)	FLHR, FLHRC
4	11323A	O-RING, check valve to tank	FLHR, FLHRC
5	27291-09A	TUBE, evaporative line, tank	FLHR, FLHRC
6	27440-09A	TUBE, evaporative line (except California, Asia-Pacific and Brazil)	FLHR, FLHRC
7	61109-85D	GASKET, filler cap	FLHR, FLHRC
8	61268-08	FUEL TANK (prime)	FLHR, FLHRC
9	61272-92C	FILLER CAP ASSEMBLY, with 61109-85D (except Asia-Pacific)	FLHR, FLHRC
10	62228-08C	CHECK VALVE, assembly, with 10396 and 11323A	FLHR, FLHRC
11	70901-09	BOOT, tank bracket (right)	FLHR, FLHRC
12	70999-09	BOOT, tank bracket (left)	FLHR, FLHRC
13	61100055	FILLER CAP KIT, locking, with 61109-85D and 90300093 (Asia-Pacific)	FLHR
14	61200022	FUEL LINE, tank to intake	FLHR, FLHRC
15	90300093	KEY (set of 2) (Asia-Pacific)	FLHRC


CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)



Index No.	Part No.	Description	Model(s)
1	3588	SCREW	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU,

			FLTRX, FLTRXS
2	4194	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
3	4856	SCREW	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
4	8142	NUT, speed	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
5	10065	CABLE STRAP	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
6	10103	CLIP, adhesive backed (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
7	10334	CLIP, hinge mounting	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
8	53919-04A	PUSH BUTTON KIT, fuel tank, with 84850-92 (Domestic)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
9	61029-92A	LOCK, fuel tank, with 84850-92 (HDI)	FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
10	61081-92	COVER, key-head (set of 2) (HDI)	FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
11	61109-85D	GASKET, filler cap	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
12	61112-08	BOOT	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
13	61270-08	CONSOLE ASSEMBLY, with hinge pin	FLHTCU, FLHTK, FLHTKL, FLTRU
	69214-08	CONSOLE ASSEMBLY, with hinge pin	FLHX, FLHXS, FLTRX, FLTRXS
14	61274-92	FUEL FILLER CAP, vacuum vented, with 61109-85D	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
15	61278-08A	DOOR KIT, console, with 10200442	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
16	61313-88	BUMPER, cover (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
17	62775-08	TRIM COVER, fuel tank	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
18	67493-08	BRACKET, console mount	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
19	69241-08	DRAIN HOSE, console	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS

CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2)




Index No.	Part No.	Description	Model(s)
20	71294-08	MOLDING, rubber (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS,

			FLTRU, FLTRX, FLTRXS
21	72168-07	TERMINAL, socket, 18-20 AWG (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
22	72444-07GY	HOUSING, four-way, socket (gray)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
23	72485-07	HOUSING, four-way socket (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
24	72493-07	TERMINAL, socket, 16-18 AWG (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
25	72494-07	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
26	72557-07	SECONDARY LOCK, four-way socket	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
27	84850-92	NUT	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
28	10200442	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
29	14100279	INSERT, console panel (HDI)	FLHXS
30	14100615	INSERT, console panel	FLTRX, FLTRXS
31	14100855	INSERT, console panel (Domestic)	FLHX, FLHXS
32	69200125	WIRE HARNESS, console, with 72168-07, 72444-07GY, 72485-07, 72493-07, 72494-07 and 72557-07	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
33	90300043	KEY, with 61081-92 (set of 2) (specify key number) (HDI)	FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS

NOTE: See INTERCOM CONTROL POD for pod and console insert for FLHTCU, FLHTK, FLHTKL and FLTRU models.


INSTRUMENTS, FUEL TANK - FLHR AND FLHRC



Index No.	Part No.	Description	Model(s)
1	3622	SCREW (4)	FLHR, FLHRC
2	3588	SCREW	FLHR, FLHRC
3	4194	SCREW (2)	FLHR, FLHRC

4	4856	SCREW	FLHR, FLHRC
5	8142	NUT, speed	FLHR, FLHRC
6	10065	CABLE STRAP (2)	FLHR, FLHRC
7	10103	CLIP, under instrument panel (2)	FLHR, FLHRC
8	61081-92	COVER, key-head (set of 2)	FLHR, FLHRC
9	61192-96A	GASKET, fuel gauge	FLHR, FLHRC
10	62519-03	HOSE, shield 1/4 in ID, 5.00 in long, fuel gauge wires	FLHR, FLHRC
11	62775-08	TRIM COVER, fuel tank	FLHR, FLHRC
12	67208-08	SEAL, speedometer	FLHR, FLHRC
13	67341-04B	BACK CLAMP, 5 in speedo (red)	FLHR, FLHRC
14	67493-08	BRACKET, console mount	FLHR, FLHRC
15	68253-08A	INDICATOR BEZEL	FLHR, FLHRC
16	71294-08	MOLDING (2)	FLHR, FLHRC
17	71517-11	IGNITION SWITCH (keyed-to-match)	FLHR, FLHRC
18	72904-01BK	HOUSING, pin, four-way	FLHR, FLHRC
19	72990-01	PIN TERMINAL (3)	FLHR, FLHRC
20	75241-08	FUEL GAUGE, without LED, with 72990-01	FLHR, FLHRC
21	14100087	INSERT, console	FLHR, FLHRC
22	69200124	WIRE HARNESS, console	FLHR, FLHRC
23	70900117	INSTRUMENT PANEL (chrome)	FLHR, FLHRC
24	70900167B	SPEEDOMETER, mph (Domestic, California)	FLHR
	70900168A	SPEEDOMETER, km/h (Canada, HDI, Austrailia, Japan, Asia-Pacific)	FLHR
	70900168A	SPEEDOMETER, km/h (HDI, Brazil)	FLHRC
	70900169A	SPEEDOMETER, dual, mph/km/h, (England only)	FLHR, FLHRC
25	71400010A	LOCKSET, complete with keys, ignition switch, cover, fork lock and saddle bag lock	FLHR
	71400011A	LOCKSET, complete with keys, ignition switch, cover, and fork lock	FLHRC
26	90300043	KEY, with 61081-92 (set of 2) (specify key number)	FLHR, FLHRC


INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS



Index No.	Part No.	Description	Model(s)
1	2563	SCREW (6)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS

2	10200147	SCREW (3)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
3	12100020	GROMMET, instrument cluster mount (3)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
4	12400034	INSERT, instrument cluster mount (3)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
5	12600067	FASTENER, plastic (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
6	61400080	GAUGE TRIM BEZEL ASSEMBLY, large (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
7	61400081	GAUGE TRIM BEZEL ASSEMBLY, small (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
8	69200121	WIRING HARNESS, fairing	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
9	69200257	BACK CLAMP, gauge (right)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
10	69200258	BACK CLAMP, gauge (left)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	70900118B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California)	FLHTK, FLHTKL
	70900119A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Brazil, Canada, HDI, Australia, Japan, Asia-Pacific)	FLHTK, FLHTKL
	70900120A	INSTRUMENT CLUSTER, dual - mph/km/h, with 12100020 and 12400034 (England)	FLHTK, FLHTKL
	70900121B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California) (black)	FLHTCU
	70900122A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Canada, HDI, Australia, Japan, Asia-Pacific) (black)	FLHTCU
	70900124B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California) (silver)	FLHX, FLHXS
	70900125A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Brazil, Canada, HDI, Australia, Japan, Asia-Pacific) (silver)	FLHX, FLHXS
	70900126A	INSTRUMENT CLUSTER, dual - mph/km/h, with 12100020 and 12400034 (England) (silver)	FLHXS
12	70900161	FUEL GAUGE	FLHTK, FLHTKL
	70900162	FUEL GAUGE (black)	FLHTCU
	70900163	FUEL GAUGE (silver)	FLHX, FLHXS
13	70900164	VOLTMETER	FLHTK, FLHTKL
	70900165	VOLTMETER (black)	FLHTCU
	70900166	VOLTMETER (silver)	FLHX, FLHXS


INSTRUMENTS - FLTRU, FLTRX AND FLTRXS



Index No.	Part No.	Description	Model(s)
1	2563	SCREW (6)	FLTRU, FLTRX, FLTRXS

2	10200147	SCREW (3)	FLTRU, FLTRX, FLTRXS
3	12100020	GROMMET, instrument cluster mount (3)	FLTRU, FLTRX, FLTRXS
4	12400034	INSERT, instrument cluster mount (3)	FLTRU, FLTRX, FLTRXS
5	61400080	GAUGE TRIM BEZEL ASSEMBLY, large (2)	FLTRU, FLTRX, FLTRXS
6	61400081	GAUGE TRIM BEZEL ASSEMBLY, small (2)	FLTRU, FLTRX, FLTRXS
7	69200122	WIRING HARNESS - FAIRING	FLTRU, FLTRX, FLTRXS
8	69200257	BACK CLAMP, gauge (right)	FLTRU, FLTRX, FLTRXS
9	69200258	BACK CLAMP, gauge, (left)	FLTRU, FLTRX, FLTRXS
10	70900121B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California) (black)	FLTRU
	70900122A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Canada, HDI, Japan, Asia-Pacific) (black)	FLTRU
	70900123A	INSTRUMENT CLUSTER, dual - mph/km/h, with 12100020 and 12400034 (England) (black)	FLTRU
	70900124B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California) (silver)	FLTRX, FLTRXS
	70900125A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Canada, HDI, Australia, Japan, Asia-Pacific) (silver)	FLTRX, FLTRXS
	70900126A	INSTRUMENT CLUSTER, dual - mph/km/h, with 12100020 and 12400034 (England) (silver)	FLTRXS
11	70900162	FUEL GAUGE (black)	FLTRU
	70900163	FUEL GAUGE (silver)	FLTRX, FLTRXS
12	70900165	VOLTMETER (black)	FLTRU
	70900166	VOLTMETER (silver)	FLTRX, FLTRXS


INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS



Index No.	Part No.	Description	Model(s)
1	3152	SCREW (2)	FLTRU, FLTRX, FLTRXS
2	3676	SCREW (4)	FLTRU, FLTRX, FLTRXS
3	6333	WASHER (4)	FLTRU, FLTRX, FLTRXS

4	10200205	SCREW (4)	FLTRU, FLTRX, FLTRXS
5	11100152	FOAM PAD, ignition switch	FLTRU, FLTRX, FLTRXS
6	12200025	CLIP (2)	FLTRU, FLTRX, FLTRXS
7	25700489	COVER ASSEMBLY, ignition switch, with 11100152	FLTRU, FLTRX, FLTRXS
8	57000412	SKIRT, front (chrome)	FLTRU, FLTRX
	57000302	SKIRT, front (unpainted) (used with vivid black and black denim paint)	FLTRXS
	57000508	SKIRT, front (unpainted)	FLTRXS
9	70900138	HOLE PLUG (2)	FLTRU, FLTRX, FLTRXS
10	70900372	HOUSING ASSEMBLY (right) (prime)	FLTRU, FLTRX, FLTRXS
11	70900373	HOUSING ASSEMBLY (left) (prime)	FLTRU, FLTRX, FLTRXS
12	70900374	HOUSING COVER (prime)	FLTRU, FLTRX, FLTRXS


FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS



Index No.	Part No.	Description	Model(s)
1	10395	RETAINER, fuel line, 5/16 in (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS,

			FLTRU, FLTRX, FLTRXS
2	11686	O-RING	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
3	61011-04A	FUEL FILTER KIT, with 11686	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
4	61012-04A	CLIP, filter retainer	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
5	61015-04A	FUEL REGULATOR ASSEMBLY KIT, with O-rings, spacer and screen	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
6	61213-04A	CLIP, regulator retainer	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
7	61402-08	GASKET, top plate	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
8	62229-08B	FILTER SHELL	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
9	62908-08	PUMP ASSEMBLY, fuel, with 10395, 75229-08 and 75254-04A	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
10	72168-07	TERMINAL, socket, 18-20 AWG (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
11	72444-07GY	HOUSING, four-way, socket (gray)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
12	72485-07	HOUSING, four-way socket (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
13	72493-07	TERMINAL, socket, 16-18 AWG (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
14	72494-07	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
15	72557-07	SECONDARY LOCK, four-way socket	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
16	75069-08C	TOP PLATE ASSEMBLY, with 3, 4, 5, 6, 8, 18 and 23	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
17	75089-08	RING, fuel tank, cam	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
18	75147-08B	TOP PLATE	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
19	75205-08A	FUEL LEVEL SENDER	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
20	75229-08	HARNESS, fuel pump module	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
21	75254-04A	STRAINER, fuel pump inlet	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
22	75269-08	TRANSFER TUBE, fuel pump	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
23	75322-09	GROUND HARNESS	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
24	69200125	WIRE HARNESS, console, with 72168-07, 72444-07GY, 72485-07, 72493-07, 72494-07 and 72557-07	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS


FUEL PUMP - FLHR AND FLHRC



Index No.	Part No.	Description	Model(s)
1	10395	RETAINER, fuel line, 5/16 in (black)	FLHR, FLHRC
2	11686	O-RING	FLHR, FLHRC
3	61011-04A	FUEL FILTER KIT, with 11686	FLHR, FLHRC

4	61012-04A	CLIP, filter retainer	FLHR, FLHRC
5	61015-04A	FUEL REGULATOR ASSEMBLY KIT, with O-rings, spacer and screen	FLHR, FLHRC
6	61213-04A	CLIP, regulator retainer	FLHR, FLHRC
7	61402-08	GASKET, top plate	FLHR, FLHRC
8	62229-08B	FILTER SHELL	FLHR, FLHRC
9	62908-08	PUMP ASSEMBLY, fuel, with 10395, 75229-08 and 75254-04A	FLHR, FLHRC
10	75076-08B	TOP PLATE ASSEMBLY, with 3, 4, 5, 6, 8, 16 and 17	FLHR, FLHRC
11	75089-08	RING, fuel tank, cam	FLHR, FLHRC
12	75205-08A	FUEL LEVEL SENDER	FLHR, FLHRC
13	75229-08	HARNESS, fuel pump module	FLHR, FLHRC
14	75254-04A	STRAINER, fuel pump inlet	FLHR, FLHRC
15	75269-08	TRANSFER TUBE, fuel pump	FLHR, FLHRC
16	75291-08A	TOP PLATE	FLHR, FLHRC
17	75322-09	GROUND HARNESS	FLHR, FLHRC

EVAPORATIVE EMISSIONS COMPONENTS




Index No.	Part No.	Description	Model(s)
1	4612	SCREW (2)	ALL
2	27291-09A	LINE, evaporative (EVAP), tank to canister	ALL
3	27297-09A	LINE, evaporative (EVAP), canister	ALL

4	27298-09A	LINE, evaporative (EVAP), purge to canister	ALL
5	27715-07	SOLENOID, purge valve	ALL
6	70681-09	RETAINER (2)	ALL
7	60800006	CARBON CANISTER	ALL
8	60800026	TUBE, solenoid to induction module	ALL

NOTE: These parts are required for motorcycles sold in California, HDI, England, Asia-Pacific and Brazil markets.


FUEL TANK TRIM



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	62435-11	MEDALLION (left) (for vivid black, amber whiskey, black denim, crushed ice pearl, olive gold,	FLHX,

		deep jade pearl, charcoal denim, velocity red sunglo tanks)	FLHXS
	62437-11	MEDALLION (right) (for vivid black, amber whiskey, black denim, crushed ice pearl, olive gold, deep jade pearl, charcoal denim, velocity red sunglo tanks)	FLHX, FLHXS
2	62152-08	MEDALLION, fuel tank (left) **RESTRICTED SALES PART**	FLHTK, FLHTKL
	62153-08	MEDALLION, fuel tank (right) **RESTRICTED SALES PART**	FLHTK, FLHTKL
3	62241-08	INSERT, PEACE OFFICER (2) **RESTRICTED SALES PART**	FLHTK, FLHTKL
4	62242-08	INSERT, FIREFIGHTER (2) **RESTRICTED SALES PART**	FLHTK, FLHTKL
5	62243-08	INSERT, SPECIAL EDITION (2) **RESTRICTED SALES PART**	FLHTK, FLHTKL
6	14100073	MEDALLION (right) (for vivid black, superior blue, billet silver, 2-tone amber whiskey/charcoal pearl, 2-tone mysterious red sunglo/velocity red sunglo tanks)	FLHTCU
	14100074	MEDALLION (left) (for vivid black, superior blue, billet silver, 2-tone amber whiskey/charcoal pearl, 2-tone mysterious red sunglo/velocity red sunglo tanks)	FLHTCU
7	14100075	MEDALLION (right) (for vivid black, black quartz, 2-tone amber whiskey/vivid black, 2-tone deep jade pearl/vivid black, 2-tone billet silver/vivid black, 2-tone mysterious red sunglo/velocity red sunglo tanks)	FLHTK, FLHTKL
	14100076	MEDALLION (left) (for vivid black, black quartz, 2-tone amber whiskey/vivid black, 2-tone deep jade pearl/vivid black, 2-tone billet silver/vivid black, 2-tone mysterious red sunglo/velocity red sunglo tanks)	FLHTK, FLHTKL
8	14100079	MEDALLION (right) (for vivid black, billet silver, velocity red sunglo, olive gold, 2-tone deep jade pearl/vivid black, 2-tone crushed ice pearl/frosted teal pearl tanks)	FLHR, FLHRC
	14100080	MEDALLION (left) (for vivid black, billet silver, velocity red sunglo, olive gold, 2-tone deep jade pearl/vivid black, 2-tone crushed ice pearl/frosted teal pearl tanks)	FLHR, FLHRC
9	14100587	MEDALLION (right) (for vivid black, amber whiskey, charcoal pearl, black denim, superior blue, black quartz, velocity red sunglo tanks)	FLTRX, FLTRXS
	14100588	MEDALLION (left) (for vivid black, amber whiskey, charcoal pearl, black denim, superior blue, black quartz, velocity red sunglo tanks)	FLTRX, FLTRXS
10	14100765	MEDALLION (left) (for vivid black, superior blue, 2-tone billet silver/vivid black, 2-tone mysterious red sunglo/velocity red sunglo tanks)	FLTRU
	14100766	MEDALLION (right) (for vivid black, superior blue, 2-tone billet silver/vivid black, 2-tone mysterious red sunglo/velocity red sunglo tanks)	FLTRU

NACELLE AND HEADLAMP - FLHR AND FLHRC




Index No.	Part No.	Description	Model(s)
1	787	SCREW (8)	FLHR, FLHRC

2	2647B	SCREW (2)	FLHR, FLHRC
3	2933	SCREW (2)	FLHR, FLHRC
4	3088	SCREW (3)	FLHR, FLHRC
5	3225	BOLT	FLHR, FLHRC
6	3265A	STUD (4)	FLHR, FLHRC
7	5210	WELL NUT (8)	FLHR, FLHRC
8	6150W	WASHER (2)	FLHR, FLHRC
9	6789	WASHER	FLHR, FLHRC
10	7888A	NUT	FLHR, FLHRC
11	7889	NUT	FLHR, FLHRC
12	15346-98A	LABEL, fog lamp (left)	FLHR, FLHRC
13	53436-97	BULB, position lamp (HDI)	FLHR, FLHRC
14	61081-92	COVER, key-head (set of 2)	FLHR, FLHRC
15	67712-83B	TRIM RING, headlamp	FLHR, FLHRC
16	67716-60C	GASKET, headlamp door	FLHR, FLHRC
17	67717-01	BULB, high beam halogen	FLHR, FLHRC
18	67721-48	SCREW (3)	FLHR, FLHRC
19	67726-08	RETAINING RING	FLHR, FLHRC
20	67778-60A	SPRING, trim ring, headlamp, top	FLHR, FLHRC
21	67780-60A	SPRING, trim ring, headlamp, bottom	FLHR, FLHRC
22	68881-01	BULB, low beam halogen	FLHR, FLHRC
23	70292-89	SOCKET HOUSING, four-way	FLHR, FLHRC
24	71310-94	TRIM ASSEMBLY, fork lock	FLHR, FLHRC
25	71455-11	HOLE PLUG (black)	FLHR, FLHRC
26	71522-08	SWITCH, auxiliary lamp and accessories, with 70292-89 and 72038-71A (except Japan)	FLHR, FLHRC
	71565-08	SWITCH, illuminated, with 70292-89 and 72038-71A (Japan)	FLHR
27	71540-94B	FORK LOCK (specify key number)	FLHR,

			FLHRC
28	72038-71A	TERMINAL, socket (except Japan) (4)	FLHR, FLHRC
	72038-71A	TERMINAL SOCKET (Japan) (3)	FLHR, FLHRC
29	74408-08A	DRESS NUT (chrome)	FLHR, FLHRC
30	10200156	SCREW	FLHR, FLHRC
31	55800091	COVER, handlebar (chrome)	FLHR, FLHRC
32	61300095	NACELLE (left) (chrome)	FLHR, FLHRC
33	61300096	NACELLE (right) (chrome)	FLHR, FLHRC
34	61400077	TRIM, nacelle (chrome)	FLHR, FLHRC
35	61400159	INSERT, handlebar cover	FLHR, FLHRC
36	67700062	HEADLAMP ASSEMBLY, dual halogen, with 67717-01 and 68881-01(Domestic)	FLHR
	67700065	HEADLAMP ASSEMBLY, dual halogen, with 54346-97, 67717-01, 68881-01 and 68000038 (HDI)	FLHR, FLHRC
37	67700105	TRIM (2)	FLHR, FLHRC
38	67700204	MOUNTING RING ASSEMBLY, with 3088 and 67700205	FLHR, FLHRC
39	67700205	MOUNTING RING, headlamp	FLHR, FLHRC
40	68000038	CONNECTOR, position bulb (HDI)	FLHRC
41	71400010A	LOCKSET, complete, with keys, ignition switch, fork lock and saddle bag lock	FLHR
	71400011A	LOCKSET, complete with keys, ignition switch, cover, and fork lock (HDI)	FLHRC
42	90300043	KEY, with 61081-92 (set of 2) (specify key number)	FLHR, FLHRC

AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC




Index No.	Part No.	Description	Model(s)
1	2647B	SCREW (4)	FLHR,

			FLHRC
2	3514	SCREW (2)	FLHR, FLHRC
3	3265A	STUD (4)	FLHR, FLHRC
4	6072	WASHER (2)	FLHR, FLHRC
5	7601	LOCKNUT (2)	FLHR, FLHRC
6	7606	LOCKNUT (2)	FLHR, FLHRC
7	7992	ACORN NUT (4)	FLHR, FLHRC
8	10039	CABLE STRAP (2)	FLHR, FLHRC
9	10065	CABLE STRAP	FLHR, FLHRC
10	67621-94	BUSHING (4)	FLHR, FLHRC
11	68168-89A	BULB, turn signal (Domestic) (2)	FLHR
	68163-84	BULB, turn signal (2) (HDI)	FLHR, FLHRC
12	68331-02	RING, auxiliary lamps (2)	FLHR, FLHRC
13	68414-05A	LAMP, auxiliary, with 68000056 (Domestic) (2)	FLHR
14	68440-86	LENS, turn signal (Domestic) (amber) (2)	FLHR
	68505-90	LENS, turn signal (HDI) (amber) (2)	FLHR, FLHRC
15	68452-86	SCREW (4)	FLHR, FLHRC
16	68519-68A	MOUNTING BRACKET (2)	FLHR, FLHRC
17	68712-94A	BRACKET, auxiliary/fog lamps	FLHR, FLHRC
18	68720-62	CLAMP BLOCK, auxiliary/fog lamps (2)	FLHR, FLHRC
19	68721-62	SWIVEL BLOCK, auxiliary/fog lamps (2)	FLHR, FLHRC
20	68725-62A	BEZEL RING, auxiliary/fog lamps (2)	FLHR, FLHRC
21	68766-94	TURN SIGNAL ASSEMBLY, with 68168-89A, 68440-86 and 68452-86 (Domestic) (2)	FLHR
	68767-94	TURN SIGNAL, with 68163-84, 68452-86 and 68505-90 (2) (HDI)	FLHR, FLHRC
22	68846-09	FOG LAMP ASSEMBLY, with 3514, 7606, 68331-02, 68725-62A, 68847-09 and 72160-06 (HDI) (2)	FLHR, FLHRC
23	68847-09	BULB ASSEMBLY, fog lamp, with 68000056 (HDI) (2)	FLHR, FLHRC
24	72160-06	HOUSING, auxiliary/fog lamp, with 72161-06, 72298-95 and 72356-95 (2)	FLHR, FLHRC
25	72161-06	SOCKET HOUSING, two-way (2)	FLHR, FLHRC
26	72298-95	WIRE SEAL, 14-18 AWG (green) (4)	FLHR,

			FLHRC
27	72356-95	TERMINAL, socket, 18-20 AWG (4)	FLHR, FLHRC
28	73154-96BK	SOCKET HOUSING, four-way (black)	FLHR, FLHRC
29	73156-96BK	SOCKET HOUSING, six-way (black)	FLHR, FLHRC
30	73191-96	TERMINAL, socket, 16-20 AWG (Domestic) (8)	FLHR
30	73191-96	TERMINAL, socket, 16-20 AWG (HDI) (6)	FLHR, FLHRC
31	68000056	BULB, auxiliary/fog lamp (2)	FLHR, FLHRC
NOTE: Hose or insulator is sold in bulk length under the following part numbers. Cut to length.			
32	70554-69	CONDUIT (10-ft length) (black)	FLHR, FLHRC

AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK
AND FLHTKL




Index No.	Part No.	Description	Model(s)
1	1332	SCREW (2)	FLHTCU, FLHTK,

			FLHTKL
2	3514	SCREW (2)	FLHTCU, FLHTK, FLHTKL
3	5118	SEAL PIN (HDI) (2)	FLHTK, FLHTKL
4	7041	LOCKWASHER (2)	FLHTCU, FLHTK, FLHTKL
5	7130W	LOCKWASHER (2)	FLHTCU, FLHTK, FLHTKL
6	7606	LOCKNUT (2)	FLHTCU, FLHTK, FLHTKL
7	7667	NUT (2)	FLHTCU, FLHTK, FLHTKL
8	7992	ACORN NUT (4)	FLHTCU, FLHTK, FLHTKL
9	40901-05	ISOLATOR, rubber (2)	FLHTCU, FLHTK, FLHTKL
10	68168-89A	BULB, turn signal (Domestic) (2)	FLHTCU, FLHTK, FLHTKL
11	68163-84	BULB, turn signal (2) (HDI)	FLHTK, FLHTKL
12	68331-02	RING, auxiliary lamps (2)	FLHTCU, FLHTK, FLHTKL
13	68725-62A	BEZEL RING, auxiliary/fog lamps (2)	FLHTCU, FLHTK, FLHTKL
14	68821-00	TURN SIGNAL MOUNT, directional (2)	FLHTCU, FLHTK, FLHTKL
15	68904-00	SOCKET ASSEMBLY, turn signal (Domestic) (2)	FLHTCU, FLHTK, FLHTKL
16	68973-00	LENS (2)	FLHTCU, FLHTK, FLHTKL
17	69563-06	CLAMP BLOCK, auxiliary/fog lamps (2)	FLHTCU, FLHTK, FLHTKL
18	72298-95	WIRE SEAL, 14-18 AWG (green) (2)	FLHTCU, FLHTK, FLHTKL
19	72356-95	TERMINAL, socket, 18-20 AWG (4)	FLHTCU, FLHTK, FLHTKL
20	72908-11	HOUSING, four-way socket (black) (2)	FLHTCU, FLHTK, FLHTKL
21	72910-11	TERMINAL, socket, 20-22 AWG (Domestic) (8)	FLHTCU, FLHTK, FLHTKL
21	72910-11	TERMINAL, socket, 20-22 AWG (HDI) (6)	FLHTK, FLHTKL
22	67800103	TURN SIGNAL ASSEMBLY, with 68168-89A, 68904-00, 68973-00 and 67800109 (Domestic) (2)	FLHTCU, FLHTK, FLHTKL
23	67800104	TURN SIGNAL ASSEMBLY, with 68163-84, 68973-00, 67800109 and socket assembly (HDI) (2)	FLHTK, FLHTKL
24	67800109	HOUSING, turn signal (chrome) (2)	FLHTCU, FLHTK, FLHTKL
25	67800254	HOUSING, auxiliary/fog lamp, with 72298-95, 72356-95, 72910-11, 69200199 and 69200259 (2)	FLHTCU, FLHTK, FLHTKL
26	68000020	AUXILIARY/FOG LAMP, LED (2)	FLHTCU, FLHTK, FLHTKL
27	68000021	BRACKET, auxiliary/fog lamp (left)	FLHTCU, FLHTK, FLHTKL

28	68000022	BRACKET, auxiliary/fog lamp (right)	FLHTCU, FLHTK, FLHTKL
29	69200199	WIRE SEAL, 18-20 AWG (purple) (2)	FLHTCU, FLHTK, FLHTKL
30	69200529	HOUSING, two-way socket (2)	FLHTCU, FLHTK, FLHTKL


TURN SIGNALS, FRONT - FLHX AND FLHXS



Index No.	Part No.	Description	Model(s)
1	3987	BOLT (2)	FLHX, FLHXS
2	5118	SEAL PIN (Domestic) (2)	FLHX, FLHXS
2	5118	SEAL PIN (HDI) (4)	FLHXS

3	7992	ACORN NUT (4)	FLHX, FLHXS
4	68168-89A	BULB, turn signal (Domestic) (2)	FLHX, FLHXS
5	68163-84	BULB, turn signal (2) (HDI)	FLHXS
6	68904-00	SOCKET ASSEMBLY, turn signal (Domestic) (2)	FLHX, FLHXS
7	68973-00	LENS (2)	FLHX, FLHXS
8	69292-06	TURN SIGNAL ASSEMBLY, with 68168-89A, 68904-00 and 68973-00 (Domestic) (2)	FLHX, FLHXS
9	69293-06	TURN SIGNAL ASSEMBLY, with 68163-84, 68973-00 and socket housing (HDI) (2)	FLHXS
10	72908-11	HOUSING, four-way socket (black) (2)	FLHX, FLHXS
11	72910-11	TERMINAL, socket, 20-22 AWG (Domestic) (6)	FLHX, FLHXS
11	72910-11	TERMINAL, socket, 20-22 AWG (HDI) (4)	FLHXS
12	68000036	BAR, right upright	FLHX, FLHXS
13	68000037	BAR, left upright	FLHX, FLHXS


WINDSHIELD - FLHR AND FLHRC



Index No.	Part No.	Description	Model(s)
1	2452	SCREW (2)	FLHR, FLHRC

2	2921	SCREW (11)	FLHR, FLHRC
3	3265A	STUD (4)	FLHR, FLHRC
4	6119	WASHER (8)	FLHR, FLHRC
5	7651A	ACORN NUT (13)	FLHR, FLHRC
6	7992	ACORN NUT (4)	FLHR, FLHRC
7	38722-94	SPRING LATCH (2)	FLHR, FLHRC
8	57668-10	WINDSHIELD ASSEMBLY, complete, low (clear) (Asia-Pacific)	FLHR
	57994-94	WINDSHIELD ASSEMBLY, complete (Domestic, Canada, California)	FLHR
	57994-94	WINDSHIELD ASSEMBLY, complete (Australia, Brazil)	FLHR, FLHRC
	58325-06	WINDSHIELD ASSEMBLY, complete (HDI, England, Japan)	FLHR, FLHRC
9	58084-94	ADJUSTING BRACKET (right)	FLHR, FLHRC
	58088-94	ADJUSTING BRACKET (left)	FLHR, FLHRC
10	58193-94	WINDSHIELD REPLACEMENT KIT, with 58416-77A and 58417-77 (Domestic, Canada, California)	FLHR
	58193-94	WINDSHIELD REPLACEMENT KIT, with 58416-77A and 58417-77 (Australia, Brazil)	FLHR, FLHRC
	58327-06	WINDSHIELD REPLACEMENT KIT, with 58416-77A and 58417-77 (HDI, England, Japan)	FLHR, FLHRC
	57400005	WINDSHIELD REPLACEMENT KIT, with 58416-77A and 58417-77 (Asia-Pacific)	FLHR
11	58406-75A	BRACE (right)	FLHR, FLHRC
	58408-75A	BRACE (left)	FLHR, FLHRC
12	58416-77A	TAPE (2)	FLHR, FLHRC
13	58417-77	TAPE (2)	FLHR, FLHRC
14	58428-94	BRACE, outer	FLHR, FLHRC
15	58431-94	BRACE, inner	FLHR, FLHRC
16	67621-94	BUSHING (4)	FLHR, FLHRC


WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	2445	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS

2	3088	SCREW (3)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
3	4790	SCREW (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
4	7900	CLIP NUT (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
5	10147	CLIP, connector	FLHX, FLHXS
6	53436-97	BULB, position lamp (HDI)	FLHXS
7	67712-83B	TRIM RING, headlamp	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
8	67716-60C	GASKET, headlamp door	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
9	67717-01	BULB, high beam halogen	FLHX, FLHXS
10	67721-48	SCREW (3)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	67726-08	RETAINING RING, headlamp	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
12	67778-60A	SPRING, trim ring, headlamp, top	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
13	67780-60A	SPRING, trim ring, headlamp, bottom (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
14	68881-01	BULB, low beam halogen	FLHX, FLHXS
15	72214-94	WIRE SEAL, 14-16 AWG (dark red) (3)	FLHX, FLHXS
16	72449-01	HOUSING, two-way socket (black)	FLHX, FLHXS
17	72450-01	HOUSING, two-way socket (gray)	FLHX, FLHXS
18	72527-01	TERMINAL, socket, 18-20 AWG (4)	FLHX, FLHXS
19	72608-08	TERMINAL, pin, 16-20 AWG (3)	FLHX, FLHXS
20	72633-02	WIRE SEAL, 14-16 AWG (white) (4)	FLHX, FLHXS
21	10200059	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
22	10200060	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
23	10200112	SCREW	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
24	10200156	SCREW	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
25	29200007	BEZEL, air duct, outer fairing	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
26	57000377	KIT, HARDWARE, fairing, with 7900 and 29200007	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
27	57000383	FAIRING, outer, with 57000377 (unfinished)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
28	57400001	WINDSHIELD (clear) (Domestic)	FLHTCU, FLHTK
	57400001	WINDSHIELD (clear) (Brazil, Australia)	FLHTK
	57400002	WINDSHIELD (clear) (HDI, England, Japan)	FLHTK
	57400250	WINDSHIELD (clear) (Domestic, HDI, England, Japan)	FLHTKL
29	57400003	WIND DEFLECTOR (smoked) (Domestic)	FLHX, FLHXS
	57400003	WIND DEFLECTOR (smoked) (Brazil, Australia)	FLHXS
	57400004	WIND DEFLECTOR (smoked) (HDI, England, Japan)	FLHXS
	57400058	WIND DEFLECTOR (clear) (Asia-Pacific)	FLHTK, FLHTKL, FLHXS


WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			

30	61400135	TRIM, headlamp	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
31	67700060	HEADLAMP, LED, with 67721-48, 67726-08 and 67700204	FLHTCU, FLHTK, FLHTKL
32	67700062	HEADLAMP ASSEMBLY, dual halogen, with 67717-01 and 68881-01 (Domestic)	FLHX, FLHXS
	67700065	HEADLAMP ASSEMBLY, dual halogen, with 53436-97, 67717-01, 68881-01 and 68000038 (HDI)	FLHXS
33	67700204	MOUNTING RING ASSEMBLY, headlamp, with 3088 and 67700205	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
34	67700205	MOUNTING RING, headlamp	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
35	68000038	CONNECTOR, position lamp, 90 degree (HDI)	FLHXS
36	69200220	HOUSING, two-way socket (black) (HDI)	FLHXS
37	69200221	TERMINAL, socket, 18-20 AWG (HDI) (2)	FLHXS
38	69200222	WIRE SEAL, 16 AWG (green) (HDI) (2)	FLHXS
39	69200223	WIRE HARNESS, dual halogen headlamp, with 5, 15, 16, 17, 18, 19, 20, 36, 37, 38, 40 and 41 (HDI)	FLHXS
40	69200255	HOUSING, four-way pin	FLHXS
41	69200256	SECONDARY LOCK, four-way socket	FLHXS
42	69200298	WIRE HARNESS, dual halogen headlamp, with 5, 15, 16, 17, 18, 19, 20, 40 and 41 (Domestic)	FLHX, FLHXS

WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)




Index No.	Part No.	Description	Model(s)
1	933	SCREW (4)	FLTRX, FLTRXS

2	2563	SCREW (6)	FLTRU, FLTRX, FLTRXS
3	4741A	SCREW (4)	FLTRU, FLTRX, FLTRXS
4	4816A	SCREW (2)	FLTRU, FLTRX, FLTRXS
5	5118	SEAL PIN (2)	FLTRU, FLTRX, FLTRXS
6	6054	WASHER (4)	FLTRX, FLTRXS
7	7900	CLIP NUT (2)	FLTRU, FLTRX, FLTRXS
8	10065	CABLE STRAP (2)	FLTRU, FLTRX, FLTRXS
9	68168-89A	BULB (Domestic) (2)	FLTRU, FLTRX, FLTRXS
	68163-84	BULB (HDI) (2)	FLTRU, FLTRXS
10	68973-00	LENS, turnsignal (amber) (2)	FLTRU, FLTRX, FLTRXS
11	72908-11	HOUSING, four-way socket (black) (2)	FLTRU, FLTRX, FLTRXS
12	72910-11	TERMINAL, socket, 20-22 AWG (Domestic) (6)	FLTRU, FLTRX, FLTRXS
	72910-11	TERMINAL, socket, 20-22 AWG (HDI) (4)	FLTRU, FLTRXS
13	10200257	SCREW (6)	FLTRU, FLTRX, FLTRXS
14	10200350	SCREW (2)	FLTRU, FLTRX, FLTRXS
15	10200365	SCREW (2)	FLTRU, FLTRX, FLTRXS
16	10200400	SCREW (4)	FLTRU
17	11100066	PAD (6)	FLTRU, FLTRX, FLTRXS
18	29200073	MECHANISM HOUSING	FLTRU, FLTRX, FLTRXS
19	29200075	BUTTON	FLTRU, FLTRX, FLTRXS
20	29200078	SPRING	FLTRU, FLTRX, FLTRXS
21	29200080	CLIP	FLTRU, FLTRX, FLTRXS
22	29200041BYM	TOP DUCT ASSEMBLY, with 13, 18, 19, 20, 21, 26 and 27 (black denim)	FLTRU, FLTRX
	29200041DH	TOP DUCT ASSEMBLY, with 13, 18, 19, 20, 21, 26 and 27 (vivid black)	FLTRXS
23	29200081	FOAM PAD, top duct	FLTRU, FLTRX, FLTRXS
24	57000501	HARDWARE KIT, fairing, with 7900, 10065, 11100066 and 29200081	FLTRU, FLTRX, FLTRXS
25	57000504	FAIRING KIT, front, with 57000501 (unpainted)	FLTRU, FLTRX, FLTRXS
26	57100167	DOOR LATCH	FLTRU, FLTRX, FLTRXS
27	57400187	GASKET	FLTRU, FLTRX, FLTRXS

28	57400191	WINDSHIELD KIT, with 933 and 6054 (dark smoke) (HDI, England, Japan, Asia-Pacific)	FLTRXS
	57400302	WINDSHIELD (dark smoke) (Domestic, Australia)	FLTRX, FLTRXS
29	57400260	WINDSHIELD (clear) (Asia-Pacific)	FLTRU
	57400262	WINDSHIELD (clear) (HDI, England, Japan)	FLTRU
	57400305	WINDSHIELD (clear) (Domestic)	FLTRU
30	57400308	TRIM, right (black)	FLTRU
31	57400309	TRIM, left (black)	FLTRU
32	61400173	BEZEL (right) (prime)	FLTRU, FLTRX, FLTRXS
33	61400198	BEZEL (left) (prime)	FLTRU, FLTRX, FLTRXS
34	67700199	HEADLAMP	FLTRU, FLTRX, FLTRXS
35	67800147	SOCKET ASSEMBLY, turn signal (Domestic) (2)	FLTRU, FLTRX, FLTRXS
	67800148	SOCKET ASSEMBLY, turn signal (HDI) (2)	FLTRU, FLTRXS
36	67800299	TURN SIGNAL MOUNT (right)	FLTRU, FLTRX, FLTRXS
37	67800300	TURN SIGNAL MOUNT (left)	FLTRU, FLTRX, FLTRXS


WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (2 OF 2)



Index No.	Part No.	Description	Model(s)
38	67800301	MOUNT, turn signal (right)	FLTRU, FLTRX, FLTRXS

39	67800302	MOUNT, turn signal (left)	FLTRU, FLTRX, FLTRXS
40	67800303	GASKET (left)	FLTRU, FLTRX, FLTRXS
41	67800471	GASKET (right)	FLTRU, FLTRX, FLTRXS
42	67800512	TURN SIGNAL, front, with 68168-89A, 68973-00 and 67800147 (Domestic) (2)	FLTRU, FLTRX, FLTRXS
	67800513	TURN SIGNAL, front, with 68163-84, 68973-00 and 67800148 (HDI) (2)	FLTRU, FLTRXS

FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)




Index No.	Part No.	Description	Model(s)
1	2445	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLHX,

			FLHXS
2	2478	SCREW (5)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
3	2563	SCREW	FLHX, FLHXS
3	2563	SCREW (7)	FLHTCU, FLHTK, FLHTKL
4	57638-08	SNAP HINGE, air deflector (2)	FLHTCU, FLHTK, FLHTKL
5	10200141	SCREW (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
6	10900005	STUD, double sided (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
7	11100038	FOAM TAPE	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
8	11100050	FOAM TAPE	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
9	11100051	FOAM TAPE	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
10	11100057	FOAM TAPE (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	12100034	PLUG, air deflector hole (6)	FLHX, FLHXS
12	12200064	CLIP, panel (10)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
13	29200003	AIR DUCT, inner fairing, with 7, 12, 14, 15, 16 and 28	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
14	29200034	DOOR, top duct	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
15	29200035	BUTTON ASSEMBLY, top duct, with 76000127	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
16	29200039	BEZEL, air duct, inner fairing, with 12200064	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
17	57000064BYM	INNER FAIRING ASSEMBLY, with 11100050, 11100051, 11100057, 61400063, 61400064 and 76000234 (satin black)	FLHTCU
	57000064DH	INNER FAIRING ASSEMBLY, with 11100050, 11100051, 11100057, 61400063, 61400064 and 76000234 (gloss black)	FLHTK, FLHTKL
	57000065BYM	INNER FAIRING ASSEMBLY, with 11100050, 11100051, 11100057, 61400063, 61400064 and 76000234 (FLHXS black denim only) (satin black)	FLHX, FLHXS
	57000065DH	INNER FAIRING ASSEMBLY, with 11100050, 11100051, 11100057, 61400063, 61400064 and 76000234 (except FLHXS black denim) (gloss black)	FLHXS
18	57000186	BRACKET, support, inner fairing	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS

19	57000299	FOAM INSERT, media compartment	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
20	57200012	AIR DEFLECTOR, with 57638-08 (left)	FLHTCU, FLHTK, FLHTKL


FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)



Index No.	Part No.	Description	Model(s)
21	57200017	AIR DEFLECTOR, with 57638-08 (right)	FLHTCU, FLHTK, FLHTKL
22	61400063	TRIM, inner fairing (left)	FLHTCU, FLHTK, FLHTKL, FLHX,

			FLHXS
23	61400064	TRIM, inner fairing (right)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
24	69200031	WIRE HARNESS, USB jumper	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
25	69200170	POWER OUTLET, fairing, with 69200171	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
26	69200171	CAP, power outlet	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
27	76000107	MEDIA COMPARTMENT ASSEMBLY, with 57000299, 69200031 and 76000127	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
28	76000127	LATCH (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
29	76000234	GASKET, media storage	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
30	76000409BYM	DOOR, media compartment, outer (FLHXS black denim only) (black denim)	FLHTCU, FLHX, FLHXS
	76000409DH	DOOR, media compartment, outer (except FLHXS black denim) (gloss black)	FLHTK, FLHTKL, FLHXS


FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)



Index No.	Part No.	Description	Model(s)
1	10200134	SCREW (6)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS

2	10200141	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
3	10200142	SCREW (6)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
4	10200205	SCREW (12)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
5	10900005	STUD, double sided (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
6	57000017	SKIRT, outer fairing (chrome)	FLHTCU, FLHTK, FLHTKL, FLHX
	57100227	SKIRT, outer fairing (gloss black)	FLHXS
7	57000169	BRACKET, fairing support (left)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
8	57000170	BRACKET, fairing support (right)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
9	57000172	SPEAKER ENCLOSURE ASSEMBLY (left)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
10	57000175	SPEAKER ENCLOSURE ASSEMBLY (right)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	69200172	SWITCH ASSEMBLY, auxiliary/fog lamps, with 69200173, 71400031 and 71400044	FLHTCU, FLHTK, FLHTKL
12	69200173	SWITCH	FLHTCU, FLHTK, FLHTKL
13	70900138	HOLE PLUG, fairing cap	FLHTCU, FLHTK, FLHTKL
13	70900138	HOLE PLUG, fairing cap (2)	FLHX, FLHXS
14	70900392BYM	DASH PANEL, fairing (FLHXS black denim only) (black denim)	FLHTCU, FLHX, FLHXS
	70900392DH	DASH PANEL, fairing (except FLHXS black denim) (gloss black)	FLHTK, FLHTKL, FLHXS
15	71400031	SWITCH BUTTON, blank (2)	FLHTCU, FLHTK, FLHTKL
16	71400044	SWITCH, auxiliary/fog lamps	FLHTCU, FLHTK, FLHTKL


FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)



Index No.	Part No.	Description	Model(s)
1	1062	SCREW (4)	FLTRU, FLTRX, FLTRXS
2	2563	SCREW (14)	FLTRU, FLTRX, FLTRXS
3	2647B	SCREW (4)	FLTRU, FLTRX, FLTRXS

4	3787	BOLT (2)	FLTRU, FLTRX, FLTRXS
5	4612	SCREW (10)	FLTRU, FLTRX, FLTRXS
6	4694	SCREW (8)	FLTRU, FLTRX, FLTRXS
7	4706	SCREW (2)	FLTRU, FLTRX, FLTRXS
8	5118	SEAL PIN (2)	FLTRU, FLTRX, FLTRXS
9	6703	WASHER (2)	FLTRU, FLTRX, FLTRXS
10	7601	LOCKNUT (2)	FLTRU, FLTRX, FLTRXS
11	10065	CABLE STRAP	FLTRU, FLTRX, FLTRXS
12	10177	CABLE STRAP (4)	FLTRU, FLTRX, FLTRXS
13	11036	RETAINING RING (2)	FLTRU, FLTRX, FLTRXS
14	11668	FOAM PAD (10)	FLTRU, FLTRX, FLTRXS
15	58888-98A	BUMPER, fairing door (4)	FLTRU, FLTRX, FLTRXS
16	61313-88	BUMPER (4)	FLTRU, FLTRX, FLTRXS
17	72066-06A	HOUSING, four-way socket (black) (2)	FLTRU, FLTRX, FLTRXS
18	72097-06	SEAL PIN, orange (2)	FLTRU, FLTRX, FLTRXS
19	72135-06	SECONDARY LOCK, four-way socket (2)	FLTRU, FLTRX, FLTRXS
20	72264-94	TERMINAL, 18-20 AWG (2)	FLTRU, FLTRX, FLTRXS
21	72484-08	TERMINAL, socket, 20 AWG (6)	FLTRU, FLTRX, FLTRXS
22	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLTRU, FLTRX, FLTRXS
23	72908-11	HOUSING, four-way socket (black) (2)	FLTRU, FLTRX, FLTRXS
24	72910-11	TERMINAL, socket, 20-22 AWG (6)	FLTRU, FLTRX, FLTRXS
25	73152-96BK	HOUSING, two-way socket (black)	FLTRU, FLTRX, FLTRXS
26	73191-96	TERMINAL, socket, 16-20 AWG (2)	FLTRU, FLTRX, FLTRXS
27	10200120	SCREW (4)	FLTRU, FLTRX, FLTRXS
28	10200134	SCREW (14)	FLTRU, FLTRX, FLTRXS
29	10500017	SCREW (6)	FLTRU, FLTRX, FLTRXS
30	29200061	BUTTON ASSEMBLY, with 57100167 (right)	FLTRU, FLTRX, FLTRXS
	29200062	BUTTON ASSEMBLY, with 57100167 (left) (not shown)	FLTRU, FLTRX, FLTRXS
31	29200063	ROD, linkage (2)	FLTRU, FLTRX, FLTRXS
32	29200071	AIR DUCT ASSEMBLY, with 5, 13, 29, 30 and 31 (right)	FLTRU, FLTRX, FLTRXS
	29200072	AIR DUCT ASSEMBLY, with 5, 13, 29, 30 and 31 (left) (not shown)	FLTRU, FLTRX, FLTRXS
33	47200262	BRACKET (right)	FLTRU, FLTRX, FLTRXS
	47200261	BRACKET (left) (not shown)	FLTRU, FLTRX, FLTRXS
34	47200266	BRACKET, inner fairing mount	FLTRU, FLTRX, FLTRXS


FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)



Index No.	Part No.	Description	Model(s)
35	57000305	INNER FAIRING (unpainted)	FLTRU, FLTRX, FLTRXS

	57000374BYM	INNER FAIRING (prime)	FLTRU, FLTRX, FLTRXS
36	57100167	DOOR LATCH (2)	FLTRU, FLTRX, FLTRXS
37	57100247	CLAMP (2)	FLTRU, FLTRX, FLTRXS
38	57200063	WILLIE WING (right)	FLTRU, FLTRX, FLTRXS
	57200064	WILLIE WING (left)	FLTRU, FLTRX, FLTRXS
39	69200170	POWER OUTLET, with 69200171	FLTRU, FLTRX, FLTRXS
40	69200171	CAP	FLTRU, FLTRX, FLTRXS
41	69200248	WIRE HARNESS, power outlet jumper, with 12, 20, 25, 26 and 42	FLTRU, FLTRX, FLTRXS
42	69200337	HOUSING, two-way socket (gray)	FLTRU, FLTRX, FLTRXS
43	69200701	GUIDE, wire harness (right)	FLTRU, FLTRX, FLTRXS
44	69200702	GUIDE, wire harness (left)	FLTRU, FLTRX, FLTRXS
45	69200753	WIRE HARNESS, gauge jumper, with 8, 12, 17, 18, 19, 21, 22, 23 and 24 (2)	FLTRU, FLTRX, FLTRXS
46	76000370	MEDIA STORAGE COMPARTMENT, with 16, 47 and 48 (right)	FLTRU, FLTRX, FLTRXS
	76000422	MEDIA STORAGE COMPARTMENT, with 16 and 47 (left) (not shown)	FLTRU, FLTRX, FLTRXS
47	76000373	LINER, media (right)	FLTRU, FLTRX, FLTRXS
	76000425	LINER, media (left) (not shown)	FLTRU, FLTRX, FLTRXS
48	76000374	USB CABLE ASSEMBLY	FLTRU, FLTRX, FLTRXS
49	76000376BYM	MEDIA DOOR ASSEMBLY, storage, with 15 (black denim) (right)	FLTRU, FLTRX
	76000376DH	MEDIA DOOR ASSEMBLY, storage, with 15 (right) (vivid black)	FLTRXS
	76000426BYM	MEDIA DOOR ASSEMBLY, storage, with 15 (left) (not shown) (black denim)	FLTRU, FLTRX
	76000426DH	MEDIA DOOR ASSEMBLY, storage, with 15 (left) (not shown) (vivid black)	FLTRXS
50	76000398	HINGE ASSEMBLY, media storage (right)	FLTRU, FLTRX, FLTRXS
	76000436	HINGE ASSEMBLY, media storage (left) (not shown)	FLTRU, FLTRX, FLTRXS
51	76000458	SPEAKER ENCLOSURE, with 11668 (right)	FLTRU, FLTRX, FLTRXS
	76000460	SPEAKER ENCLOSURE, with 11668 (left) (not shown)	FLTRU, FLTRX, FLTRXS


FAIRING LOWERS, AIR COOLED - FLHTCU



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	2995	SCREW (6)	FLHTCU

2	3655A	SCREW (2)	FLHTCU
3	6235	WASHER (2)	FLHTCU
4	7415A	WASHER (2)	FLHTCU
5	7576	NUT (2)	FLHTCU
6	7716	LOCKNUT (6)	FLHTCU
7	8175	CLIP (2)	FLHTCU
8	10100033	PUSH NUT (4)	FLHTCU
9	10200052	SCREW (4)	FLHTCU
10	11700005	SPRING, torsion, door (2)	FLHTCU
11	12000005	PIN, door hinge (4)	FLHTCU
12	12600049	SCREW (8)	FLHTCU
13	47200275	CLAMP (2)	FLHTCU
14	57100098	FRAME, glove box (right)	FLHTCU
15	57100101	FRAME, glove box (left)	FLHTCU
16	57100102	DOOR, glove box (2)	FLHTCU
17	57100103	TRAY, glove box (right)	FLHTCU
18	57100104	TRAY, glove box (left)	FLHTCU
19	57100108	GLOVE BOX ASSEMBLY, with 2995, 10100033, 11700005, 12000005, 12600049, 57100101, 57100102, 57100104, 57100164, 57100165, 57100166, 57100167, 57100188 and 57100225 (left)	FLHTCU
20	57100110	GLOVE BOX ASSEMBLY, with 2995, 10100033, 11700005, 12000005, 12600049, 57100098, 57100102, 57100103, 57100164, 57100165, 57100166, 57100167, 57100188 and 57100225 (right)	FLHTCU
21	57100111	CAP, fairing lower (left) (unpainted)	FLHTCU
22	57100112	FAIRING (lower) (left) (unpainted)	FLHTCU
23	57100113	CAP, fairing (lower) (right) (unpainted)	FLHTCU
24	57100114	FAIRING (lower) (right) (unpainted)	FLHTCU
25	57100149	COVER, lower fairing (left)	FLHTCU
26	57100150	COVER, lower fairing (right)	FLHTCU
27	57100154	HINGE (2)	FLHTCU
28	57100155	DOOR, vent (2)	FLHTCU
29	57100161	PLATE (lower) (left)	FLHTCU
30	57100162	PLATE (lower) (right)	FLHTCU
31	57100164	LINK, door vent (2)	FLHTCU
32	57100165	KNOB, door vent (2)	FLHTCU
33	57100166	DAMPER, door (2)	FLHTCU
34	57100167	LATCH, door (2)	FLHTCU
35	57100170	FASCIA ASSEMBLY (lower) (left)	FLHTCU
36	57100171	FASCIA ASSEMBLY (lower) (right)	FLHTCU
37	57100187	RETAINER, U-bolt (2)	FLHTCU
38	57100188	BUMPER, glove box door (4)	FLHTCU
39	57100200	PIN, door, vent (2)	FLHTCU
40	57100208	CLAMP, lower fairing (2)	FLHTCU
41	57100225	SLIDER, door, vent (2)	FLHTCU

FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU




Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	3655A	SCREW (2)	FLHTK, FLHTKL,

			FLTRU
2	6235	WASHER (2)	FLHTK, FLHTKL, FLTRU
3	7415A	WASHER (2)	FLHTK, FLHTKL, FLTRU
4	7576	NUT (2)	FLHTK, FLHTKL, FLTRU
5	7716	LOCKNUT (8)	FLHTK, FLHTKL, FLTRU
6	8175	BOLT, retainer (2)	FLHTK, FLHTKL, FLTRU
7	11519	MOUNT, rubber (right)	FLHTK, FLHTKL, FLTRU
8	10200052	SCREW (4)	FLHTK, FLHTKL, FLTRU
9	12200025	CLIP (10)	FLHTK, FLHTKL, FLTRU
10	12600049	SCREW (8)	FLHTK, FLHTKL, FLTRU
11	26800008	DUCT, radiator (left)	FLHTK, FLHTKL, FLTRU
12	26800009	DUCT, radiator (right)	FLHTK, FLHTKL, FLTRU
13	47200275	CLAMP (2)	FLHTK, FLHTKL, FLTRU
14	57100099	PANEL ASSEMBLY, glove box, with 12200025 (2)	FLHTK, FLHTKL, FLTRU
15	57100107	GLOVE BOX ASSEMBLY, with 12600049, 57100148, 57100164, 57100165 and 57100225 (left)	FLHTK, FLHTKL, FLTRU
16	57100109	GLOVE BOX ASSEMBLY, with 12600049, 57100147, 57100164, 57100165 and 57100225 (right)	FLHTK, FLHTKL, FLTRU
17	57100111	CAP, fairing (lower) (left) (unpainted)	FLHTK, FLHTKL, FLTRU
18	57100112	FAIRING (lower) (left) (unpainted)	FLHTK, FLHTKL, FLTRU
19	57100113	CAP, fairing (lower) (right) (unpainted)	FLHTK, FLHTKL, FLTRU
20	57100114	FAIRING (lower) (right) (unpainted)	FLHTK, FLHTKL, FLTRU
21	57100147	FRAME, glove box, with 12200025 (right)	FLHTK, FLHTKL, FLTRU
22	57100148	FRAME, glove box, with 12200025 (left)	FLHTK, FLHTKL, FLTRU
23	57100151	SCREEN, radiator (left)	FLHTK, FLHTKL, FLTRU
24	57100152	SCREEN, radiator (right)	FLHTK, FLHTKL, FLTRU
25	57100153	GASKET, radiator (2)	FLHTK, FLHTKL, FLTRU
26	57100154	HINGE (2)	FLHTK, FLHTKL, FLTRU
27	57100155	DOOR, vent (2)	FLHTK, FLHTKL,

			FLTRU
28	57100164	LINK, door, vent (2)	FLHTK, FLHTKL, FLTRU
29	57100165	KNOB, door, vent (2)	FLHTK, FLHTKL, FLTRU
30	57100170	FASCIA ASSEMBLY (lower) (left)	FLHTK, FLHTKL, FLTRU
31	57100171	FASCIA ASSEMBLY (lower) (right)	FLHTK, FLHTKL, FLTRU
32	57100172	CLAMP, lower fairing	FLHTK, FLHTKL, FLTRU
33	57100187	RETAINER, U-bolt (2)	FLHTK, FLHTKL, FLTRU
34	57100200	PIN, door, vent (2)	FLHTK, FLHTKL, FLTRU
35	57100225	SLIDER, door, vent (2)	FLHTK, FLHTKL, FLTRU
36	57100256	CLAMP, lower fairing	FLHTK, FLHTKL, FLTRU


SWITCHES, HANDLEBAR, LEFT



Index No.	Part No.	Description	Model(s)
1	72908-11	HOUSING, four-way socket (black)	ALL
2	69200178	WIRE HARNESS, left hand control jumper, with 72908-11,	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL,

		69200306, 69200307 and 69200308	FLHX, FLHXS, FLTRX, FLTRXS
	69200630	WIRE HARNESS, left hand control jumper, with 72908-11, 69200306, 69200307 and 69200308	FLTRU
3	69200306	SOCKET HOUSING, four-way	ALL
4	69200307	TERMINAL, socket, 22 AWG (4)	ALL
5	69200308	TERMINAL, socket, 22 AWG (4)	ALL
6	71500044	SWITCH CAP, cruise	ALL
7	71500045	SWITCH CAP, audio home	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
8	71500047	SWITCH CAP, horn	ALL
9	71500048	SWITCH CAP, lights, high beam, low beam and flash to pass	ALL
10	71500053	SWITCH CAP, left turn signal	FLHR, FLHRC
11	71500055	SWITCH CAP, left turn signal and voice recognition	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
12	71500094	SWITCH CAP, trigger switch	ALL
13	71500128A	SWITCH PACK, left hand control, with 71500044, 71500045, 71500047, 71500048 and 71500055	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
14	71500338	COVER, front, left hand control	ALL
15	71500342	COVER, rear, left hand control, with screws	ALL
16	71500419	SWITCH PACK, left hand control, with 71500044, 71500047, 71500048 and 71500053	FLHR, FLHRC


SWITCHES, HANDLEBAR, RIGHT



Index No.	Part No.	Description	Model(s)
1	5118	SEAL PIN	ALL
2	72906-11	HOUSING, two-way socket (black)	ALL

3	72908-11	HOUSING, four-way socket (black)	ALL
4	69200179	WIRE HARNESS, right hand control jumper, with 5118,, 72906-11, 72908-11, 69200305, 69200306, 69200307 and 69200308	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRX, FLTRXS
	69200631	WIRE HARNESS, right hand control jumper, with 5118, 72906-11, 72908-11, 69200305, 69200306, 69200307 and 69200308	FLTRU
5	69200305	HOUSING, two-way socket (white)	ALL
6	69200306	HOUSING, four-way socket (white)	ALL
7	69200307	TERMINAL, socket, 22 AWG (5)	ALL
8	69200308	TERMINAL, socket, 22 AWG (5)	ALL
9	71500046	SWITCH CAP, audio select	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
10	71500049	SWITCH CAP, start/hazard	ALL
11	71500050	SWITCH CAP, stop and run	ALL
12	71500057	SWITCH CAP, right turn signal	FLHR, FLHRC
13	71500063	SWITCH CAP, right turn signal and info	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
14	71500127B	SWITCH PACK, right hand control, with 71500049, 71500050 and 71500057	FLHR, FLHRC
15	71500129B	SWITCH PACK, right hand control, with 71500046, 71500049, 71500050 and 71500063	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
16	71500340	COVER, front, right hand control	ALL
17	71500348	COVER, rear, right hand control, with screws	ALL


HANDLEBAR



Index No.	Part No.	Description	Model(s)
1	2708A	SCREW (4)	ALL
2	4240	SCREW (2)	ALL

3	9853	TAB, fastening	ALL
4	10006	CABLE STRAP (6)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
4	10006	CABLE STRAP (5)	FLTRU, FLTRX, FLTRXS
5	55918-08	CLAMP (upper)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
6	55924-14	HANDLEBAR	FLHTCU, FLHTK, FLHX, FLHXS
7	56159-73	CUP WASHER (4)	ALL
8	56161-83A	BUSHING, rubber (4)	ALL
9	56163-93	SPACER (2)	ALL
10	57450-14	RISER (lower) (left)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	57451-14	RISER (lower) (right)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
12	70345-84	RETAINER (4)	FLHR, FLHRC
13	72053-92	HOUSING, one-way pin	ALL
14	72241-94A	TERMINAL, 10 ring, 14-18 AWG	ALL
15	12600032	SCREW (2)	ALL
16	55900071	CLAMP (upper)	FLTRU, FLTRX, FLTRXS
17	55900078	RISER, handlebar	FLTRX, FLTRXS
	55900079	RISER, handlebar	FLTRU
18	55800099	HANDLEBAR	FLHR, FLHRC
19	55800305	HANDLEBAR	FLHTKL
20	55800332	HANDLEBAR	FLTRX, FLTRXS
21	55800436	HANDLEBAR	FLTRU
22	69200224	WIRE HARNESS, triple clamp, ground jumper, with 9853, 72053-92, 72241-94A and 69200536	ALL
23	69200536	TERMINAL, ring, 12-14 AWG	ALL


THROTTLE CONTROL



Index No.	Part No.	Description	Model(s)
1	10006	CABLE STRAP	ALL
2	32306-08	SEAL CAP, throttle sensor	ALL

3	56209-10	GRIP, heated, with 72902-01BK and 72912-01BK (left)	FLHTK
4	56248-08	GRIP (left)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	56667-04	GRIP (left)	FLHTKL
5	56249-10	GRIP, heated (right)	FLHTK
6	56250-10	END CAP (right)	FLHTK
7	56304-08	GRIP AND SLEEVE, throttle (right)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	56100075	GRIP AND SLEEVE, throttle (right)	FLHTKL
8	72902-01BK	HOUSING, two-way pin (black)	FLHR, FLHRC, FLHTCU, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
8	72902-01BK	HOUSING, two-way pin (black) (2)	FLHTK
9	72912-01BK	HOUSING, two-way socket (black)	FLHTK
10	72990-01	PIN TERMINAL (2)	ALL
11	32700050	SENSOR, twist grip, with 32306-08, 72902-01BK, 72990-01, 69200307 and 69201162	ALL
12	69200307	TERMINAL, socket, 22 AWG (6)	ALL
13	69201162	HOUSING, six-way socket (black)	ALL

TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)




Index No.	Part No.	Description	Model(s)
1	2482	SCREW (Domestic) (2)	FLHR, FLHX, FLHXS, FLTRX, FLTRXS

1	2482	SCREW (HDI) (2)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
2	2692WB	SCREW (4)	FLHR, FLHRC
3	3576	SCREW (Domestic) (2)	FLHR, FLHX, FLHXS, FLTRX, FLTRXS
3	3576	SCREW (HDI) (2)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
4	10006	CABLE STRAP	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
5	10183	CLIP, T-stud (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
5	10183	CLIP, T-stud (Canada)	FLHX, FLHXS, FLTRX, FLTRXS
6	10184	CLIP, T-stud	FLHR
6	10184	CLIP, T-stud (Canada)	FLHX, FLHXS, FLTRX, FLTRXS
7	52441-95	BULB, backlite (Canada only) (2)	FLHX, FLHXS, FLTRX, FLTRXS
8	67266-94	BUSHING, nylon (2)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
8	67266-94	BUSHING, nylon (Canada only) (2)	FLHX, FLHXS, FLTRX, FLTRXS
9	68163-84	BULB, turn signal (HDI) (2)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU
10	68168-89A	BULB, turn signal (Domestic, California) (2)	FLHX, FLHXS, FLTRX, FLTRXS
11	68440-86	LENS, turn signal (amber) (Domestic, California) (2)	FLHR
12	68452-86	SCREW (4)	FLHR, FLHRC
13	68497-07	SOCKET ASSEMBLY, with mount (Domestic, California) (2)	FLHX, FLHXS, FLTRX, FLTRXS
14	68506-92	LENS, turn signal (2) (HDI) (amber)	FLHR, FLHRC
15	68550-09	BRACKET, rear turn signal bar (HDI)	FLHTK, FLHTKL, FLTRU
16	68559-07	LENS, red (Domestic, California) (2)	FLHX, FLHXS, FLTRX, FLTRXS
17	68572-64B	BULB, rear turn signal (2)	FLHR
17	68572-64B	BULB, rear turn signal (Canada only) (2)	FLHX, FLHXS, FLTRX, FLTRXS
18	68629-05	LIGHTBAR, turn signal (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
19	68713-94A	LAMP ASSEMBLY, rear, with 68440-86, 68452-86 and 68572-64B (Domestic) (2)	FLHR
20	68742-09	BRACKET, rear turn signal	FLHR, FLHRC
21	68765-94A	LAMP ASSEMBLY, rear, with 68163-84, 68452-86 and 68506-92 (2) (HDI)	FLHR, FLHRC
22	68905-00	SOCKET ASSEMBLY, rear turn signal (Canada only) (2)	FLHX, FLHXS, FLTRX, FLTRXS
23	68973-00	LENS, rear turn signal (Canada only) (2)	FLHX, FLHXS, FLTRX, FLTRXS
23	68973-	LENS, rear turn signal (HDI) (2)	FLHTK, FLHTKL, FLTRU

	00		
24	68997-09	LAMP ASSEMBLY, rear turn signal, with 2482, 68163-84, 68550-09, 68973-00, 69378-09, 73152-96BK and 73191-96 (HDI)	FLHTK, FLHTKL, FLTRU
25	69353-05	LAMP ASSEMBLY, with 52441-95 and 73191-96 (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
26	69378-09	LIGHT ASSEMBLY, with 73191-96 and lens	FLHR
26	69378-09	LIGHT ASSEMBLY, with 73191-96 and lens (HDI)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU
27	70522-06B	CONDUIT, self-adhesive	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
28	72130-04	HOUSING, 12-way socket (Domestic, California, HDI) (black) (3)	FLHX, FLHXS, FLTRX, FLTRXS
29	72168-07	TERMINAL, socket, 18-20 AWG (6)	ALL
30	72189-04	SEAL PIN (Domestic, California) (9)	FLHX, FLHXS, FLTRX, FLTRXS
30	72189-04	SEAL PIN (HDI) (7)	FLHX, FLHXS, FLTRX, FLTRXS


TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)



Index No.	Part No.	Description	Model(s)
31	72414-07BK	HOUSING, six-way socket (black)	ALL

32	73152-96BK	HOUSING, two-way socket (HDI) (black) (2)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU
32	73152-96BK	HOUSING, two-way socket (Canada only) (black) (2)	FLHX, FLHXS, FLTRX, FLTRXS
33	73153-96BK	SOCKET HOUSING, three-way	FLHR
33	73153-96BK	SOCKET HOUSING, three-way (HDI)	FLHRC, FLHTK, FLHTKL, FLTRU
33	73153-96BK	SOCKET HOUSING, three-way (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
34	73156-96BK	SOCKET HOUSING, six-way (black)	ALL
35	73191-96	TERMINAL, socket, 16-20 AWG (12)	ALL
36	73254-10	LIGHT ASSEMBLY, with 74196-04 and lens (Except Canada)	FLHX, FLHXS, FLTRX, FLTRXS
37	73309-10	BRACKET, rear turn signal bar (Domestic, Not Canada)	FLHX, FLHXS, FLTRX, FLTRXS
38	73314-10	DIRECTIONAL LAMP ASSEMBLY, rear, with 2482, 68168-89A, 68497-07, 68559-07, 72130-04, 72189-04, 73309-10, 73254-10, 74196-04 and 74197-04 (Domestic, Not Canada)	FLHX, FLHXS, FLTRX, FLTRXS
39	74196-04	TERMINAL, socket, 20 AWG (24)	FLHX, FLHXS, FLTRX, FLTRXS
40	74197-04	SECONDARY LOCK, 12-way socket	FLHX, FLHXS, FLTRX, FLTRXS
41	67800132	DIRECTIONAL LAMP ASSEMBLY, rear, with 2482, 72130-04, 72189-04, 73254-10, 74196-04 and 74197-04 (HDI)	FLHXS, FLTRXS
42	69200128	HARNESS, rear lamps, with 10006, 70522-06B, 72168-07, 72414-07BK, 73156-96BK and 73191-96	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
43	69200129	HARNESS, rear lighting jumper, with 72130-04, 72168-07, 72189-04, 72414-07BK, 74196-04 and 74197-04	FLHX, FLHXS, FLTRX, FLTRXS
44	69200130	HARNESS, rear lighting, jumper, with 72130-04, 72189-04, 73191-96, 73156-96BK, 74196-04 and 74197-04 (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS

TAIL LAMP (1 OF 2)




Index No.	Part No.	Description	Model(s)
1	3022A	SCREW	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU

1	3022A	SCREW (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
2	7964	J-NUT	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
2	7964	J-NUT (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
3	10006	CABLE STRAP	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
4	10183	CLIP, T-stud (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
4	10183	CLIP, T-stud (Canada)	FLHX, FLHXS, FLTRX, FLTRXS
5	10184	CLIP, T-stud	FLHR
5	10184	CLIP, T-stud (Canada)	FLHX, FLHXS, FLTRX, FLTRXS
5	10184	CLIP, T-stud (HDI)	FLHRC, FLHTK, FLHTKL, FLTRU
6	68026-99	SCREW (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
6	68026-99	SCREW (Canada only) (2)	FLHX, FLHXS, FLTRX, FLTRXS
7	68066-99A	TAIL LAMP BASE ASSEMBLY, with 68296-99A and 68830-99A	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
7	68066-99A	TAIL LAMP BASE ASSEMBLY, with 68296-99A and 68830-99A (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
8	68140-04	LAMP ASSEMBLY, tail lamp, with 68369-03 and 68370-03A (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
9	68142-04	LAMP ASSEMBLY, tail lamp, with 68558-03 and 69187-03A (HDI)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU
10	68167-04	BULB, tail lamp, wedge mount	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
10	68167-04	BULB, tail lamp, wedge mount (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
11	68245-03	LENS, tail lamp (red), with 68026-99 (Domestic)	FLHR
11	68245-03	LENS, tail lamp (red), with 68026-99 (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
12	68296-99A	TAIL LIGHT BASE (chrome)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
12	68296-99A	TAIL LIGHT BASE (chrome) (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
13	68369-03	LENS, tail lamp, with 68026-99	FLHTCU, FLHTK, FLHTKL, FLTRU
14	68370-03A	SOCKET ASSEMBLY, tail lamp, with 68167-04, 73154-96BK and 73191-96 (Domestic)	FLHR
14	68370-03A	SOCKET ASSEMBLY, tail lamp, with 68167-04, 73154-96BK and 73191-96	FLHTCU, FLHTK, FLHTKL, FLTRU
14	68370-03A	SOCKET ASSEMBLY, tail lamp, with 68167-04, 73154-96BK and 73191-96 (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
15	68558-03	LENS, tail lamp, with 68026-99 (HDI)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU
16	68830-99A	CIRCUIT BOARD AND COVER	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
16	68830-99A	CIRCUIT BOARD AND COVER (Canada only)	FLHX, FLHXS, FLTRX, FLTRXS
17	69187-03A	BULB SOCKET ASSEMBLY, tail lamp, with 68167-04, 73154-96BK and 73191-96 (HDI)	FLHR, FLHRC, FLHTK, FLHTKL, FLTRU

18	70522-06B	CONDUIT, self-adhesive	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
19	72168-07	TERMINAL, socket, 18-20 AWG (6)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
20	72414-07BK	HOUSING, six-way socket (black)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU


TAIL LAMP (2 OF 2)



Index No.	Part No.	Description	Model(s)
21	73154-96BK	SOCKET HOUSING, four-way	ALL

22	73156-96BK	SOCKET HOUSING, six-way	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
23	73191-96	TERMINAL, socket, 16-20 AWG (3)	FLHX, FLHXS, FLTRX, FLTRXS
23	73191-96	TERMINAL, socket, 16-20 AWG (9)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
24	69200128	HARNESS, rear lamps, with 10006, 70522-06B, 72168-07, 72414-07BK, 73156-96BK and 73191-96	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU

EXHAUST SYSTEM




Index No.	Part No.	Description	Model(s)
1	3929	SCREW (4)	ALL
2	4705	SCREW (2)	ALL

3	7041	LOCKWASHER (4)	ALL
4	7593	NUT (5)	ALL
5	9955	CLAMP, worm drive #24 (6)	ALL
6	9956	CLAMP, worm drive #40 (2)	ALL
7	10039	CABLE STRAP	ALL
8	10177	CABLE STRAP, anchored	ALL
9	11936	GASKET, oxygen (O2) sensor (2)	ALL
10	27809-10	SENSOR, oxygen (O2), rear, with 11936, 72177-07BK, 72344-10 and 73307-10	ALL
11	65324-83B	GASKET, exhaust port (2)	ALL
12	65325-83A	RETAINING RING, exhaust gasket (2)	ALL
13	65328-83A	CLAMP, exhaust manifold (2)	ALL
14	65723-85	MOUNTING BRACKET (2)	ALL
15	65724-85A	MOUNT, rubber (2)	ALL
16	66861-09A	CLAMP, exhaust pipe, hinged	ALL
17	66881-09	BRACKET, exhaust pipe hanger	ALL
18	72177-07BK	HOUSING, four-way socket (black)	ALL
19	72344-10	TERMINAL, socket, 22 AWG (gold) (4)	ALL
20	72444-07GY	HOUSING, four-way, socket (gray)	ALL
21	73307-10	TERMINAL, socket, 22 AWG (4)	ALL
22	10200569	SCREW	ALL
23	10900015	STUD, exhaust	ALL
24	32700046	SENSOR, oxygen (O2), front, with 10177, 11936, 72344-10, 72444-07GY and 73307-10	ALL
25	64900235	MUFFLER (left) (chrome) (Domestic, Canada, California)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	64900237	MUFFLER (left) (chrome) (Asia-Pacific, Brazil)	FLHR, FLHTK, FLHXS, FLTRU, FLTRXS
	64900239	MUFFLER (left) (chrome) (Australia, England, HDI, Japan)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
26	64900236	MUFFLER (right) (chrome) (Domestic, Canada, California)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	64900238	MUFFLER (right) (chrome) (Asia-Pacific, Brazil)	FLHR, FLHTK, FLHXS, FLTRU, FLTRXS
	64900240	MUFFLER (right) (chrome) (Australia, England, HDI, Japan)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
27	65400176	SHIELD, exhaust pipe, front	ALL
28	65400177	EXHAUST SHIELD ASSEMBLY, rear header pipe	ALL
29	65400178	EXHAUST SHIELD ASSEMBLY, catalytic converter	ALL
30	65400179	SHIELD, left exhaust pipe, rear	ALL
31	65500042	BRACKET, muffler strap, male	ALL
32	65500043	BRACKET, muffler strap, female	ALL
33	65600176	HEADER ASSEMBLY, catalytic (Domestic, Canada, California) (chrome)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	65600177	HEADER ASSEMBLY, catalytic (Australia, England, Japan,	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS,

		HDI, Asia-Pacific, Brazil) (chrome)	FLTRU, FLTRXS
34	65600178	CROSSOVER PIPE ASSEMBLY (chrome)	ALL
35	65900012	CLAMP, muffler (2)	ALL
36	65900015	CLAMP, muffler	ALL


WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (7)	FLHX

2	72168-07	TERMINAL, socket, 18-20 AWG (7)	FLHX
3	72272-07	TERMINAL, socket, 14-16 AWG (4)	FLHX
4	72364-06	TERMINAL, insulated	FLHX
5	72414-07BK	HOUSING, six-way socket (black)	FLHX
6	72473-07	SEAL PIN, natural (7)	FLHX
7	72489-07GY	HOUSING, 12-way socket (gray)	FLHX
8	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHX
9	69200201	HOUSING, two-way socket (black)	FLHX
10	69200202	WIRE TROUGH	FLHX
11	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHX
12	69200214	CADDY, left steer head	FLHX
13	69200294	CABLE, AM/FM antenna	FLHX
14	69201287	BRACKET, mounting, electrical connector	FLHX
15	69201459	BRACKET	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
NOTE: Includes the following parts.			
1	10006	CABLE STRAP (2)	FLHX

2	10065	CABLE STRAP (6)	FLHX
3	10177	CABLE STRAP, anchored (2)	FLHX
4	72062-06	HOUSING, two-way socket (gray)	FLHX
5	72166-07BK	HOUSING, 16-way socket (black)	FLHX
6	72168-07	TERMINAL, socket, 18-20 AWG (16)	FLHX
7	72169-07	TERMINAL, pin, 16-20 AWG (27)	FLHX
8	72175-07BK	HOUSING, four-way pin (black)	FLHX
9	72209-11	COVER, wire	FLHX
10	72222-11	TERMINAL, socket, 18-20 AWG (26)	FLHX
11	72226-11	TERMINAL, socket, 14-16 AWG (8)	FLHX
12	72256-11	SEAL PIN (13)	FLHX
13	72414-07BK	HOUSING, six-way socket (black)	FLHX
14	72473-07	SEAL PIN, natural (7)	FLHX
15	72484-08	TERMINAL, socket, 20 AWG (2)	FLHX
16	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLHX
17	72488-07BK	HOUSING, 12-way pin (black)	FLHX
18	72490-07GY	HOUSING, 12-way pin (gray)	FLHX
19	72632-10	PLUG, weather, four-way pin	FLHX
20	73213-07	RETAINER, anchored (2)	FLHX
21	69200193	HOUSING, 48-way socket	FLHX
22	69200205	WEATHER PLUG, 12-way pin (2)	FLHX
23	69200215	CADDY, right steer head	FLHX
24	69201163	HOUSING, six-way pin (black)	FLHX
25	69201164	TERMINAL, pin, 22 AWG (6)	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHX

2	10177	CABLE STRAP, anchored (2)	FLHX
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHX
4	72009-05	HOUSING, two-way pin (black) (2)	FLHX
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLHX
6	72098-06	HOUSING, two-way socket (gray)	FLHX
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHX
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHX
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHX
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLHX
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHX
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHX
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHX
14	69201390	HOUSING, two-way socket (2)	FLHX
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHX
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHX
17	69201393	HOUSING, two-way socket (black)	FLHX
18	69201394	HOUSING, six-way socket	FLHX
19	69201395	SECONDARY LOCK, six-way socket	FLHX
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHX
21	69201397	HOUSING, two-way pin	FLHX
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHX
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHX
24	69201416	CPA, six-way socket	FLHX
25	69201441	HOUSING, four-way socket	FLHX
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHX

2	10147	CLIP, connector	FLHX
3	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHX
4	72518-01	HOUSING, two-way socket (red)	FLHX
5	72533-06	PLUG, weather, two-way pin	FLHX
6	72609-08	SECONDARY LOCK, two-way socket	FLHX
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHX
8	72664-12A	HOUSING, 18-way socket (black)	FLHX
9	72666-12	TERMINAL, socket, 18-20 AWG (43)	FLHX
10	72720-07	HOUSING, two-way socket (black)	FLHX
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHX
12	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLHX
13	69201415	HOUSING, 18-way socket (brown)	FLHX
14	69201440	HOUSING, 18-way socket (gray)	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLHX

2	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLHX
3	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLHX
4	72415-07GY	HOUSING, four-way pin (gray)	FLHX
5	73213-07	RETAINER, anchored	FLHX
6	69200294	CABLE, AM/FM antenna	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLHX

2	10065	CABLE STRAP (4)	FLHX
3	11779	FASTENER, push-in (black) (2)	FLHX
4	72291-94	TERMINAL, socket, 14-16 AWG	FLHX
5	72295-94	CONNECTOR, starter housing	FLHX
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (2)	FLHX
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLHX
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHX
9	72543-07BK	HOUSING, three-way socket (black)	FLHX
10	72544-07	SECONDARY LOCK, three-way socket	FLHX
11	69200175	CADDY, fuse block, electrical panel	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
NOTE: Includes the following parts.			
1	10065	CABLE STRAP	FLHX

2	10147	CLIP, connector (2)	FLHX
3	10177	CABLE STRAP, anchored (3)	FLHX
4	72065-06A	HOUSING, three-way socket	FLHX
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHX
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLHX
7	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLHX
8	72175-07BK	HOUSING, four-way pin (black)	FLHX
9	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHX
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLHX
11	72415-07GY	HOUSING, four-way pin (gray)	FLHX
12	72473-07	SEAL PIN, natural	FLHX
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLHX
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLHX
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHX
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLHX
17	72519-09BK	PLUG, weather, three-way socket (2)	FLHX
18	72533-06	PLUG, weather, two-way pin	FLHX
19	72544-07	SECONDARY LOCK, three-way socket	FLHX
20	72589-09	HOUSING, three-way socket	FLHX
21	72606-08	HOUSING, two-way socket (black) (2)	FLHX
22	72607-08	HOUSING, two-way pin (black)	FLHX
23	72608-08	TERMINAL, pin, 16-20 AWG (2)	FLHX
24	72609-08	SECONDARY LOCK, two-way socket (2)	FLHX
25	72610-08	WIRE SEAL, 18-20 AWG (white) (4)	FLHX
26	73213-07	RETAINER, anchored (4)	FLHX
27	74112-98BK	HOUSING, two-way socket (black)	FLHX
28	74152-98	SECONDARY LOCK, two-way socket	FLHX
29	74191-98	TERMINAL, socket (2)	FLHX
30	12500014	CABLE STRAP (2)	FLHX
31	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLHX
32	69201396	TERMINAL, socket, 20 AWG (2)	FLHX
33	69201400	HOUSING, two-way socket, CPA (black)	FLHX
34	69201401	SECONDARY LOCK, two-way socket	FLHX
35	69201404	RETAINER, anchored	FLHX
36	69201405	RESISTOR PACK	FLHX
37	69201423	DC LEAD ASSEMBLY, two-way socket	FLHX
38	72232-96	SEAL PIN (2)	FLHX
39	12500018	CABLE STRAP	FLHX

WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8)




Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
NOTE: Includes the following parts.			
1	6990	WEATHER PLUG, six-way pin	FLHX

2	10006	CABLE STRAP (2)	FLHX
3	10065	CABLE STRAP (2)	FLHX
4	31586-07	RELAY (2)	FLHX
5	72064-06	HOUSING, three-way socket (black)	FLHX
6	72081-11	HOUSING, 48-way socket	FLHX
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLHX
8	72146-94	SECONDARY LOCK, six-way pin	FLHX
9	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLHX
10	72175-07BK	HOUSING, four-way pin (black)	FLHX
11	72188-07BK	HOUSING, six-way pin (black)	FLHX
12	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLHX
13	72194-94	TERMINAL, pin, 20 AWG (3)	FLHX
14	72195-94	SEAL PIN	FLHX
15	72209-11	COVER, wire	FLHX
16	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLHX
17	72226-11	TERMINAL, socket, 14-16 AWG	FLHX
18	72227-11	TERMINAL, socket, 18-20 AWG (5)	FLHX
19	72256-11	SEAL PIN (9)	FLHX
20	72296-95	TERMINAL, socket, 14-16 AWG (3)	FLHX
21	72298-95	WIRE SEAL, 14-18 AWG (green) (3)	FLHX
22	72299-95	SEAL PIN, green (2)	FLHX
23	72308-97	TERMINAL, socket, 12-14 AWG (5)	FLHX
24	72330-95	FUSE, 15 A (blue)	FLHX
25	72331-95	FUSE, 5 A (tan) (2)	FLHX
26	72345-02	FUSE, 20 A (yellow) (3)	FLHX
27	72350-11	HOUSING, one-way socket (black)	FLHX
28	72356-95	TERMINAL, socket, 18-20 AWG (14)	FLHX
29	72412-97	WIRE SEAL, 12-14 AWG (gray) (5)	FLHX
30	72484-08	TERMINAL, socket, 20 AWG (3)	FLHX
31	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHX
32	72575-11	SECONDARY LOCK, one-way socket	FLHX
33	72632-10	PLUG, weather, four-way pin	FLHX
34	73213-07	RETAINER, anchored	FLHX
35	73301-04	HOUSING, two-way pin	FLHX
36	73303-04	SECONDARY LOCK, two-way socket	FLHX
37	73304-04	TERMINAL, socket, 10 AWG (3)	FLHX
38	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLHX
39	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLHX
40	69200194	FUSE BLOCK, 24-way	FLHX
41	69200199	WIRE SEAL, 18-20 AWG (purple) (14)	FLHX
42	69200212	HARNESS, battery tender	FLHX
43	69200293	FUSE, 7.5 A (brown) (2)	FLHX
44	69200312	SECONDARY LOCK, fuse block (3)	FLHX
45	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLHX
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHX
47	69201307	BOOT, battery positive	FLHX

48	69201411	COVER, fuse block	FLHX


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (7)	FLHX, FLHXS

2	72168-07	TERMINAL, socket, 18-20 AWG (7)	FLHX, FLHXS
3	72272-07	TERMINAL, socket, 14-16 AWG (4)	FLHX, FLHXS
4	72364-06	TERMINAL, insulated	FLHX, FLHXS
5	72414-07BK	HOUSING, six-way socket (black)	FLHX, FLHXS
6	72473-07	SEAL PIN, natural (7)	FLHX, FLHXS
7	72489-07GY	HOUSING, 12-way socket (gray)	FLHX, FLHXS
8	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHX, FLHXS
9	69200201	HOUSING, two-way socket (black)	FLHX, FLHXS
10	69200202	WIRE TROUGH	FLHX, FLHXS
11	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHX, FLHXS
12	69200214	CADDY, left steer head	FLHX, FLHXS
13	69200294	CABLE, AM/FM antenna	FLHX, FLHXS
14	69201287	BRACKET, mounting, electrical connector	FLHX, FLHXS
15	69201459	BRACKET	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
NOTE: Includes the following parts.			
1	10006	CABLE STRAP (2)	FLHX, FLHXS

2	10065	CABLE STRAP (6)	FLHX, FLHXS
3	10177	CABLE STRAP, anchored (2)	FLHX, FLHXS
4	72062-06	HOUSING, two-way socket (gray)	FLHX, FLHXS
5	72166-07BK	HOUSING, 16-way socket (black)	FLHX, FLHXS
6	72168-07	TERMINAL, socket, 18-20 AWG (16)	FLHX, FLHXS
7	72169-07	TERMINAL, pin, 16-20 AWG (27)	FLHX, FLHXS
8	72175-07BK	HOUSING, four-way pin (black)	FLHX, FLHXS
9	72209-11	COVER, wire	FLHX, FLHXS
10	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHX, FLHXS
11	72222-11	TERMINAL, socket, 18-20 AWG (26)	FLHX, FLHXS
12	72226-11	TERMINAL, socket, 14-16 AWG (8)	FLHX, FLHXS
13	72256-11	SEAL PIN (13)	FLHX, FLHXS
14	72414-07BK	HOUSING, six-way socket (black)	FLHX, FLHXS
15	72473-07	SEAL PIN, natural (6)	FLHX, FLHXS
16	72484-08	TERMINAL, socket, 20 AWG (2)	FLHX, FLHXS
17	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLHX, FLHXS
18	72488-07BK	HOUSING, 12-way pin (black)	FLHX, FLHXS
19	72490-07GY	HOUSING, 12-way pin (gray)	FLHX, FLHXS
20	72606-08	HOUSING, two-way socket (black)	FLHX, FLHXS
21	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHX, FLHXS
22	72632-10	PLUG, weather, four-way pin	FLHX, FLHXS
23	72609-08	SECONDARY LOCK, two-way socket	FLHX, FLHXS
24	73213-07	RETAINER, anchored (2)	FLHX, FLHXS
25	69200193	HOUSING, 48-way socket	FLHX, FLHXS
26	69200205	WEATHER PLUG, 12-way pin (2)	FLHX, FLHXS
27	69200215	CADDY, right steer head	FLHX, FLHXS
28	69201163	HOUSING, six-way pin (black)	FLHX, FLHXS
29	69201164	TERMINAL, pin, 22 AWG (6)	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHX, FLHXS

2	10177	CABLE STRAP, anchored (2)	FLHX, FLHXS
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHX, FLHXS
4	72009-05	HOUSING, two-way pin (black) (2)	FLHX, FLHXS
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLHX, FLHXS
6	72098-06	HOUSING, two-way socket (gray)	FLHX, FLHXS
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHX, FLHXS
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHX, FLHXS
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHX, FLHXS
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLHX, FLHXS
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHX, FLHXS
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHX, FLHXS
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHX, FLHXS
14	69201390	HOUSING, two-way socket (2)	FLHX, FLHXS
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHX, FLHXS
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHX, FLHXS
17	69201393	HOUSING, two-way socket (black)	FLHX, FLHXS
18	69201394	HOUSING, six-way socket	FLHX, FLHXS
19	69201395	SECONDARY LOCK, six-way socket	FLHX, FLHXS
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHX, FLHXS
21	69201397	HOUSING, two-way pin	FLHX, FLHXS
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHX, FLHXS
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHX, FLHXS
24	69201416	CPA, six-way socket	FLHX, FLHXS
25	69201441	HOUSING, four-way socket	FLHX, FLHXS
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHX, FLHXS

2	10147	CLIP, connector	FLHX, FLHXS
3	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHX, FLHXS
4	72518-01	HOUSING, two-way socket (red)	FLHX, FLHXS
5	72533-06	PLUG, weather, two-way pin	FLHX, FLHXS
6	72609-08	SECONDARY LOCK, two-way socket	FLHX, FLHXS
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHX, FLHXS
8	72664-12A	HOUSING, 18-way socket (black)	FLHX, FLHXS
9	72666-12	TERMINAL, socket, 18-20 AWG (43)	FLHX, FLHXS
10	72720-07	HOUSING, two-way socket (black)	FLHX, FLHXS
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHX, FLHXS
12	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLHX, FLHXS
13	69201415	HOUSING, 18-way socket (brown)	FLHX, FLHXS
14	69201440	HOUSING, 18-way socket (gray)	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLHX, FLHXS

2	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLHX, FLHXS
3	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLHX, FLHXS
4	72415-07GY	HOUSING, four-way pin (gray)	FLHX, FLHXS
5	73213-07	RETAINER, anchored	FLHX, FLHXS
6	69200294	CABLE, AM/FM antenna	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLHX, FLHXS

2	10065	CABLE STRAP (4)	FLHX, FLHXS
3	11779	FASTENER, push-in (black) (2)	FLHX, FLHXS
4	72291-94	TERMINAL, socket, 14-16 AWG	FLHX, FLHXS
5	72295-94	CONNECTOR, starter housing	FLHX, FLHXS
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (2)	FLHX, FLHXS
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLHX, FLHXS
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHX, FLHXS
9	72543-07BK	HOUSING, three-way socket (black)	FLHX, FLHXS
10	72544-07	SECONDARY LOCK, three-way socket	FLHX, FLHXS
11	69200175	CADDY, fuse block, electrical panel	FLHX, FLHXS

WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8)




Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHX, FLHXS

2	10147	CLIP, connector (2)	FLHX, FLHXS
3	10177	CABLE STRAP, anchored (3)	FLHX, FLHXS
4	72065-06A	HOUSING, three-way socket	FLHX, FLHXS
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHX, FLHXS
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLHX, FLHXS
7	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLHX, FLHXS
8	72175-07BK	HOUSING, four-way pin (black)	FLHX, FLHXS
9	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLHX, FLHXS
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLHX, FLHXS
11	72415-07GY	HOUSING, four-way pin (gray)	FLHX, FLHXS
12	72473-07	SEAL PIN, natural	FLHX, FLHXS
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLHX, FLHXS
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLHX, FLHXS
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHX, FLHXS
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLHX, FLHXS
17	72519-09BK	PLUG, weather, three-way socket (2)	FLHX, FLHXS
18	72533-06	PLUG, weather, two-way pin	FLHX, FLHXS
19	72544-07	SECONDARY LOCK, three-way socket	FLHX, FLHXS
20	72589-09	HOUSING, three-way socket	FLHX, FLHXS
21	72606-08	HOUSING, two-way socket (black) (3)	FLHX, FLHXS
22	72607-08	HOUSING, two-way pin (black)	FLHX, FLHXS
23	72608-08	TERMINAL, pin, 16-20 AWG (2)	FLHX, FLHXS
24	72609-08	SECONDARY LOCK, two-way socket (3)	FLHX, FLHXS
25	72610-08	WIRE SEAL, 18-20 AWG (white) (6)	FLHX, FLHXS
26	73213-07	RETAINER, anchored (4)	FLHX, FLHXS
27	74112-98BK	HOUSING, two-way socket (black)	FLHX, FLHXS
28	74152-98	SECONDARY LOCK, two-way socket	FLHX, FLHXS
29	74191-98	TERMINAL, socket (2)	FLHX, FLHXS
30	12500014	CABLE STRAP (2)	FLHX, FLHXS
31	69200183	HOUSING, 26-way socket	FLHX, FLHXS
32	69200184	COVER, wire	FLHX, FLHXS
33	69200185	TERMINAL, socket, 20 AWG (6)	FLHX, FLHXS
34	69200186	TERMINAL, socket, 14-16 AWG (2)	FLHX, FLHXS
35	69200187	TERMINAL, socket, 12 AWG (2)	FLHX, FLHXS
36	69200188	WIRE SEAL, 20 AWG (6)	FLHX, FLHXS
37	69200189	WIRE SEAL, 14-16 AWG (2)	FLHX, FLHXS
38	69200190	WIRE SEAL, 12 AWG (2)	FLHX, FLHXS
39	69200191	SEAL PIN (16)	FLHX, FLHXS
40	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLHX, FLHXS
41	69201396	TERMINAL, socket, 20 AWG (2)	FLHX, FLHXS
42	69201400	HOUSING, two-way socket, CPA (black)	FLHX, FLHXS
43	69201401	SECONDARY LOCK, two-way socket	FLHX, FLHXS
44	69201404	RETAINER, anchored	FLHX, FLHXS
45	69201405	RESISTOR PACK	FLHX, FLHXS
46	69201423	DC LEAD ASSEMBLY, two-way socket	FLHX, FLHXS
47	72232-96	SEAL PIN (2)	FLHX, FLHXS

48	12500018	CABLE STRAP	FLHX, FLHXS

WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8)




Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
NOTE: Includes the following parts.			
1	6990	WEATHER PLUG, six-way pin	FLHX, FLHXS

2	10006	CABLE STRAP (2)	FLHX, FLHXS
3	10065	CABLE STRAP (2)	FLHX, FLHXS
4	31586-07	RELAY (2)	FLHX, FLHXS
5	72064-06	HOUSING, three-way socket (black)	FLHX, FLHXS
6	72081-11	HOUSING, 48-way socket	FLHX, FLHXS
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLHX, FLHXS
8	72146-94	SECONDARY LOCK, six-way pin	FLHX, FLHXS
9	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLHX, FLHXS
10	72175-07BK	HOUSING, four-way pin (black)	FLHX, FLHXS
11	72188-07BK	HOUSING, six-way pin (black)	FLHX, FLHXS
12	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLHX, FLHXS
13	72194-94	TERMINAL, pin, 20 AWG (3)	FLHX, FLHXS
14	72195-94	SEAL PIN	FLHX, FLHXS
15	72209-11	COVER, wire	FLHX, FLHXS
16	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLHX, FLHXS
17	72226-11	TERMINAL, socket, 14-16 AWG	FLHX, FLHXS
18	72227-11	TERMINAL, socket, 18-20 AWG (5)	FLHX, FLHXS
19	72256-11	SEAL PIN (9)	FLHX, FLHXS
20	72296-95	TERMINAL, socket, 14-16 AWG (3)	FLHX, FLHXS
21	72298-95	WIRE SEAL, 14-18 AWG (green) (3)	FLHX, FLHXS
22	72299-95	SEAL PIN, green (2)	FLHX, FLHXS
23	72308-97	TERMINAL, socket, 12-14 AWG (5)	FLHX, FLHXS
24	72330-95	FUSE, 15 A (blue)	FLHX, FLHXS
25	72331-95	FUSE, 5 A (tan) (2)	FLHX, FLHXS
26	72345-02	FUSE, 20 A (yellow) (3)	FLHX, FLHXS
27	72350-11	HOUSING, one-way socket (black)	FLHX, FLHXS
28	72356-95	TERMINAL, socket, 18-20 AWG (14)	FLHX, FLHXS
29	72412-97	WIRE SEAL, 12-14 AWG (gray) (5)	FLHX, FLHXS
30	72484-08	TERMINAL, socket, 20 AWG (3)	FLHX, FLHXS
31	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHX, FLHXS
32	72575-11	SECONDARY LOCK, one-way socket	FLHX, FLHXS
33	72632-10	PLUG, weather, four-way pin	FLHX, FLHXS
34	73213-07	RETAINER, anchored	FLHX, FLHXS
35	73301-04	HOUSING, two-way pin	FLHX, FLHXS
36	73303-04	SECONDARY LOCK, two-way socket	FLHX, FLHXS
37	73304-04	TERMINAL, socket, 10 AWG (3)	FLHX, FLHXS
38	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLHX, FLHXS
39	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLHX, FLHXS
40	69200194	FUSE BLOCK, 24-way	FLHX, FLHXS
41	69200199	WIRE SEAL, 18-20 AWG (purple) (14)	FLHX, FLHXS
42	69200212	HARNESS, battery tender	FLHX, FLHXS
43	69200293	FUSE, 7.5 A (brown) (2)	FLHX, FLHXS
44	69200312	SECONDARY LOCK, fuse block (3)	FLHX, FLHXS
45	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLHX, FLHXS
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHX, FLHXS
47	69201307	BOOT, battery positive	FLHX, FLHXS

48	69201411	COVER, fuse block	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (7)	FLHTCU

2	10177	CABLE STRAP, anchored	FLHTCU
3	72168-07	TERMINAL, socket, 18-20 AWG (7)	FLHTCU
4	72272-07	TERMINAL, socket, 14-16 AWG (4)	FLHTCU
5	72364-06	TERMINAL, insulated	FLHTCU
6	72414-07BK	HOUSING, six-way socket (black)	FLHTCU
7	72473-07	SEAL PIN, natural (7)	FLHTCU
8	72489-07GY	HOUSING, 12-way socket (gray)	FLHTCU
9	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHTCU
10	69200032	WIRE HARNESS, AM/FM antenna	FLHTCU
11	69200136	WIRE HARNESS, CB antenna	FLHTCU
12	69200201	HOUSING, two-way socket (black)	FLHTCU
13	69200202	WIRE TROUGH	FLHTCU
14	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHTCU
15	69200214	CADDY, left steer head	FLHTCU
16	69201287	BRACKET, mounting, electrical connector	FLHTCU
17	69201459	BRACKET	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLHTCU

2	10065	CABLE STRAP (5)	FLHTCU
3	10177	CABLE STRAP, anchored (2)	FLHTCU
4	72062-06	HOUSING, two-way socket (gray)	FLHTCU
5	72166-07BK	HOUSING, 16-way socket (black)	FLHTCU
6	72168-07	TERMINAL, socket, 18-20 AWG (16)	FLHTCU
7	72169-07	TERMINAL, pin, 16-20 AWG (23)	FLHTCU
8	72209-11	COVER, wire	FLHTCU
9	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHTCU
10	72222-11	TERMINAL, socket, 18-20 AWG (28)	FLHTCU
11	72226-11	TERMINAL, socket, 14-16 AWG (8)	FLHTCU
12	72256-11	SEAL PIN (12)	FLHTCU
13	72414-07BK	HOUSING, six-way socket (black)	FLHTCU
14	72473-07	SEAL PIN, natural (7)	FLHTCU
15	72484-08	TERMINAL, socket, 20 AWG (2)	FLHTCU
16	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLHTCU
17	72488-07BK	HOUSING, 12-way pin (black)	FLHTCU
18	72490-07GY	HOUSING, 12-way pin (gray)	FLHTCU
19	72606-08	HOUSING, two-way socket (black)	FLHTCU
20	72609-08	SECONDARY LOCK, two-way socket	FLHTCU
21	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHTCU
22	73213-07	RETAINER, anchored (2)	FLHTCU
23	69200193	HOUSING, 48-way socket	FLHTCU
24	69200205	WEATHER PLUG, 12-way pin (2)	FLHTCU
25	69200215	CADDY, right steer head	FLHTCU
26	69201163	HOUSING, six-way pin (black)	FLHTCU
27	69201164	TERMINAL, pin, 22 AWG (6)	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHTCU

2	10177	CABLE STRAP, anchored (2)	FLHTCU
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHTCU
4	72009-05	HOUSING, two-way pin (black) (2)	FLHTCU
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLHTCU
6	72098-06	HOUSING, two-way socket (gray)	FLHTCU
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHTCU
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHTCU
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHTCU
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLHTCU
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHTCU
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHTCU
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHTCU
14	69201390	HOUSING, two-way socket (2)	FLHTCU
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHTCU
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHTCU
17	69201393	HOUSING, two-way socket (black)	FLHTCU
18	69201394	HOUSING, six-way socket	FLHTCU
19	69201395	SECONDARY LOCK, six-way socket	FLHTCU
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHTCU
21	69201397	HOUSING, two-way pin	FLHTCU
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHTCU
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHTCU
24	69201416	CPA, six-way socket	FLHTCU
25	69201441	HOUSING, four-way socket	FLHTCU
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHTCU

2	10147	CLIP, connector	FLHTCU
3	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHTCU
4	72518-01	HOUSING, two-way socket (red)	FLHTCU
5	72533-06	PLUG, weather, two-way pin	FLHTCU
6	72609-08	SECONDARY LOCK, two-way socket	FLHTCU
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHTCU
8	72664-12A	HOUSING, 18-way socket (black)	FLHTCU
9	72666-12	TERMINAL, socket, 18-20 AWG (43)	FLHTCU
10	72720-07	HOUSING, two-way socket (black)	FLHTCU
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHTCU
12	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLHTCU
13	69201415	HOUSING, 18-way socket (brown)	FLHTCU
14	69201440	HOUSING, 18-way socket (gray)	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLHTCU

2	10065	CABLE STRAP	FLHTCU
3	72167-07BK	HOUSING, 16-way pin (black)	FLHTCU
4	72168-07	TERMINAL, socket, 18-20 AWG (6)	FLHTCU
5	72169-07	TERMINAL, pin, 16-20 AWG (23)	FLHTCU
6	72188-07BK	HOUSING, six-way pin (black)	FLHTCU
7	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLHTCU
8	72414-07BK	HOUSING, six-way socket (black)	FLHTCU
9	72415-07GY	HOUSING, four-way pin (gray)	FLHTCU
10	72473-07	SEAL PIN, natural (3)	FLHTCU
11	73213-07	RETAINER, anchored (3)	FLHTCU
12	69200032	WIRE HARNESS, AM/FM antenna	FLHTCU
13	69200136	WIRE HARNESS, CB antenna	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLHTCU

2	10065	CABLE STRAP (4)	FLHTCU
3	11779	FASTENER, push-in (black) (2)	FLHTCU
4	72291-94	TERMINAL, socket, 14-16 AWG	FLHTCU
5	72295-94	CONNECTOR, starter housing	FLHTCU
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (2)	FLHTCU
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLHTCU
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHTCU
9	72543-07BK	HOUSING, three-way socket (black)	FLHTCU
10	72544-07	SECONDARY LOCK, three-way socket	FLHTCU
11	69200175	CADDY, fuse block, electrical panel	FLHTCU

WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8)




Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHTCU

2	10147	CLIP, connector (2)	FLHTCU
3	10177	CABLE STRAP, anchored (3)	FLHTCU
4	72065-06A	HOUSING, three-way socket	FLHTCU
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHTCU
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLHTCU
7	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLHTCU
8	72175-07BK	HOUSING, four-way pin (black)	FLHTCU
9	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLHTCU
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLHTCU
11	72415-07GY	HOUSING, four-way pin (gray)	FLHTCU
12	72473-07	SEAL PIN, natural	FLHTCU
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLHTCU
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLHTCU
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHTCU
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLHTCU
17	72519-09BK	PLUG, weather, three-way socket (2)	FLHTCU
18	72533-06	PLUG, weather, two-way pin	FLHTCU
19	72544-07	SECONDARY LOCK, three-way socket	FLHTCU
20	72589-09	HOUSING, three-way socket	FLHTCU
21	72606-08	HOUSING, two-way socket (black) (3)	FLHTCU
22	72607-08	HOUSING, two-way pin (black)	FLHTCU
23	72608-08	TERMINAL, pin, 16-20 AWG (2)	FLHTCU
24	72609-08	SECONDARY LOCK, two-way socket (3)	FLHTCU
25	72610-08	WIRE SEAL, 18-20 AWG (white) (6)	FLHTCU
26	73213-07	RETAINER, anchored (4)	FLHTCU
27	74112-98BK	HOUSING, two-way socket (black)	FLHTCU
28	74152-98	SECONDARY LOCK, two-way socket	FLHTCU
29	74191-98	TERMINAL, socket (2)	FLHTCU
30	12500014	CABLE STRAP (2)	FLHTCU
31	69200183	HOUSING, 26-way socket	FLHTCU
32	69200184	COVER, wire	FLHTCU
33	69200185	TERMINAL, socket, 20 AWG (6)	FLHTCU
34	69200186	TERMINAL, socket, 14-16 AWG (2)	FLHTCU
35	69200187	TERMINAL, socket, 12 AWG (2)	FLHTCU
36	69200188	WIRE SEAL, 20 AWG (6)	FLHTCU
37	69200189	WIRE SEAL, 14-16 AWG (2)	FLHTCU
38	69200190	WIRE SEAL, 12 AWG (2)	FLHTCU
39	69200191	SEAL PIN (16)	FLHTCU
40	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLHTCU
41	69201396	TERMINAL, socket, 20 AWG (2)	FLHTCU
42	69201400	HOUSING, two-way socket, CPA (black)	FLHTCU
43	69201401	SECONDARY LOCK, two-way socket	FLHTCU
44	69201404	RETAINER, anchored	FLHTCU
45	69201405	RESISTOR PACK	FLHTCU
46	69201423	DC LEAD ASSEMBLY, two-way socket	FLHTCU
47	72232-96	SEAL PIN (2)	FLHTCU

48	12500018	CABLE STRAP	FLHTCU

WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8)




Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
NOTE: Includes the following parts.			
1	6990	WEATHER PLUG, six-way pin	FLHTCU

2	10006	CABLE STRAP (2)	FLHTCU
3	10065	CABLE STRAP (2)	FLHTCU
4	31586-07	RELAY (2)	FLHTCU
5	72064-06	HOUSING, three-way socket (black)	FLHTCU
6	72081-11	HOUSING, 48-way socket	FLHTCU
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLHTCU
8	72146-94	SECONDARY LOCK, six-way pin	FLHTCU
9	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLHTCU
10	72175-07BK	HOUSING, four-way pin (black)	FLHTCU
11	72188-07BK	HOUSING, six-way pin (black)	FLHTCU
12	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLHTCU
13	72194-94	TERMINAL, pin, 20 AWG (3)	FLHTCU
14	72195-94	SEAL PIN	FLHTCU
15	72209-11	COVER, wire	FLHTCU
16	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLHTCU
17	72226-11	TERMINAL, socket, 14-16 AWG	FLHTCU
18	72227-11	TERMINAL, socket, 18-20 AWG (5)	FLHTCU
19	72256-11	SEAL PIN (9)	FLHTCU
20	72296-95	TERMINAL, socket, 14-16 AWG (3)	FLHTCU
21	72298-95	WIRE SEAL, 14-18 AWG (green) (3)	FLHTCU
22	72299-95	SEAL PIN, green (2)	FLHTCU
23	72308-97	TERMINAL, socket, 12-14 AWG (5)	FLHTCU
24	72330-95	FUSE, 15 A (blue)	FLHTCU
25	72331-95	FUSE, 5 A (tan) (2)	FLHTCU
26	72345-02	FUSE, 20 A (yellow) (3)	FLHTCU
27	72350-11	HOUSING, one-way socket (black)	FLHTCU
28	72356-95	TERMINAL, socket, 18-20 AWG (14)	FLHTCU
29	72412-97	WIRE SEAL, 12-14 AWG (gray) (5)	FLHTCU
30	72484-08	TERMINAL, socket, 20 AWG (3)	FLHTCU
31	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHTCU
32	72575-11	SECONDARY LOCK, one-way socket	FLHTCU
33	72632-10	PLUG, weather, four-way pin	FLHTCU
34	73213-07	RETAINER, anchored	FLHTCU
35	73301-04	HOUSING, two-way pin	FLHTCU
36	73303-04	SECONDARY LOCK, two-way socket	FLHTCU
37	73304-04	TERMINAL, socket, 10 AWG (3)	FLHTCU
38	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLHTCU
39	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLHTCU
40	69200194	FUSE BLOCK, 24-way	FLHTCU
41	69200199	WIRE SEAL, 18-20 AWG (purple) (14)	FLHTCU
42	69200212	HARNESS, battery tender	FLHTCU
43	69200293	FUSE, 7.5 A (brown) (2)	FLHTCU
44	69200312	SECONDARY LOCK, fuse block (3)	FLHTCU
45	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLHTCU
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHTCU
47	69201307	BOOT, battery positive	FLHTCU

48	69201411	COVER, fuse block	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (7)	FLHTK, FLHTKL

2	10177	CABLE STRAP, anchored	FLHTK, FLHTKL
3	72168-07	TERMINAL, socket, 18-20 AWG (7)	FLHTK, FLHTKL
4	72272-07	TERMINAL, socket, 14-16 AWG (4)	FLHTK, FLHTKL
5	72364-06	TERMINAL, insulated	FLHTK, FLHTKL
6	72414-07BK	HOUSING, six-way socket (black)	FLHTK, FLHTKL
7	72473-07	SEAL PIN, natural (7)	FLHTK, FLHTKL
8	72489-07GY	HOUSING, 12-way socket (gray)	FLHTK, FLHTKL
9	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHTK, FLHTKL
10	69200032	WIRE HARNESS, AM/FM antenna	FLHTK, FLHTKL
11	69200136	WIRE HARNESS, CB antenna	FLHTK, FLHTKL
12	69200201	HOUSING, two-way socket (black)	FLHTK, FLHTKL
13	69200202	WIRE TROUGH	FLHTK, FLHTKL
14	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHTK, FLHTKL
15	69200214	CADDY, left steer head	FLHTK, FLHTKL
16	69201287	BRACKET, mounting, electrical connector	FLHTK, FLHTKL
17	69201459	BRACKET	FLHTK, FLHTKL


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLHTK, FLHTKL

2	10065	CABLE STRAP (5)	FLHTK, FLHTKL
3	10177	CABLE STRAP, anchored (2)	FLHTK, FLHTKL
4	72062-06	HOUSING, two-way socket (gray)	FLHTK, FLHTKL
5	72166-07BK	HOUSING, 16-way socket (black)	FLHTK, FLHTKL
6	72168-07	TERMINAL, socket, 18-20 AWG (16)	FLHTK, FLHTKL
7	72169-07	TERMINAL, pin, 16-20 AWG (23)	FLHTK, FLHTKL
8	72209-11	COVER, wire	FLHTK, FLHTKL
9	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHTK, FLHTKL
10	72222-11	TERMINAL, socket, 18-20 AWG (28)	FLHTK, FLHTKL
11	72226-11	TERMINAL, socket, 14-16 AWG (8)	FLHTK, FLHTKL
12	72256-11	SEAL PIN (12)	FLHTK, FLHTKL
13	72414-07BK	HOUSING, six-way socket (black)	FLHTK, FLHTKL
14	72473-07	SEAL PIN, natural (7)	FLHTK, FLHTKL
15	72484-08	TERMINAL, socket, 20 AWG (2)	FLHTK, FLHTKL
16	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLHTK, FLHTKL
17	72488-07BK	HOUSING, 12-way pin (black)	FLHTK, FLHTKL
18	72490-07GY	HOUSING, 12-way pin (gray)	FLHTK, FLHTKL
19	72606-08	HOUSING, two-way socket (black)	FLHTK, FLHTKL
20	72609-08	SECONDARY LOCK, two-way socket	FLHTK, FLHTKL
21	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHTK, FLHTKL
22	73213-07	RETAINER, anchored (2)	FLHTK, FLHTKL
23	69200193	HOUSING, 48-way socket	FLHTK, FLHTKL
24	69200205	WEATHER PLUG, 12-way pin (2)	FLHTK, FLHTKL
25	69200215	CADDY, right steer head	FLHTK, FLHTKL
26	69201163	HOUSING, six-way pin (black)	FLHTK, FLHTKL
27	69201164	TERMINAL, pin, 22 AWG (6)	FLHTK, FLHTKL


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHTK, FLHTKL

2	10177	CABLE STRAP, anchored (2)	FLHTK, FLHTKL
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHTK, FLHTKL
4	72009-05	HOUSING, two-way pin (black) (2)	FLHTK, FLHTKL
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLHTK, FLHTKL
6	72098-06	HOUSING, two-way socket (gray)	FLHTK, FLHTKL
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHTK, FLHTKL
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHTK, FLHTKL
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHTK, FLHTKL
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLHTK, FLHTKL
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHTK, FLHTKL
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHTK, FLHTKL
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHTK, FLHTKL
14	69201390	HOUSING, two-way socket (2)	FLHTK, FLHTKL
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHTK, FLHTKL
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHTK, FLHTKL
17	69201393	HOUSING, two-way socket (black)	FLHTK, FLHTKL
18	69201394	HOUSING, six-way socket	FLHTK, FLHTKL
19	69201395	SECONDARY LOCK, six-way socket	FLHTK, FLHTKL
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHTK, FLHTKL
21	69201397	HOUSING, two-way pin	FLHTK, FLHTKL
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHTK, FLHTKL
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHTK, FLHTKL
24	69201416	CPA, six-way socket	FLHTK, FLHTKL
25	69201441	HOUSING, four-way socket	FLHTK, FLHTKL
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHTK, FLHTKL


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHTK, FLHTKL

2	10147	CLIP, connector	FLHTK, FLHTKL
3	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHTK, FLHTKL
4	72518-01	HOUSING, two-way socket (red)	FLHTK, FLHTKL
5	72533-06	PLUG, weather, two-way pin	FLHTK, FLHTKL
6	72609-08	SECONDARY LOCK, two-way socket	FLHTK, FLHTKL
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHTK, FLHTKL
8	72664-12A	HOUSING, 18-way socket (black)	FLHTK, FLHTKL
9	72666-12	TERMINAL, socket, 18-20 AWG (46)	FLHTK, FLHTKL
10	72720-07	HOUSING, two-way socket (black)	FLHTK, FLHTKL
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHTK, FLHTKL
12	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLHTK, FLHTKL
13	69201410	HOUSING, 18-way socket (brown)	FLHTK, FLHTKL
14	69201414	HOUSING, 18-way socket (gray)	FLHTK, FLHTKL


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLHTK, FLHTKL

2	10065	CABLE STRAP	FLHTK, FLHTKL
3	72167-07BK	HOUSING, 16-way pin (black)	FLHTK, FLHTKL
4	72168-07	TERMINAL, socket, 18-20 AWG (6)	FLHTK, FLHTKL
5	72169-07	TERMINAL, pin, 16-20 AWG (23)	FLHTK, FLHTKL
6	72188-07BK	HOUSING, six-way pin (black)	FLHTK, FLHTKL
7	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLHTK, FLHTKL
8	72414-07BK	HOUSING, six-way socket (black)	FLHTK, FLHTKL
9	72415-07GY	HOUSING, four-way pin (gray)	FLHTK, FLHTKL
10	72473-07	SEAL PIN, natural (3)	FLHTK, FLHTKL
11	73213-07	RETAINER, anchored (3)	FLHTK, FLHTKL
12	69200032	WIRE HARNESS, AM/FM antenna	FLHTK, FLHTKL
13	69200136	WIRE HARNESS, CB antenna	FLHTK, FLHTKL


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLHTK, FLHTKL

2	10065	CABLE STRAP (4)	FLHTK, FLHTKL
3	11779	FASTENER, push-in (black) (2)	FLHTK, FLHTKL
4	72291-94	TERMINAL, socket, 14-16 AWG	FLHTK, FLHTKL
5	72295-94	CONNECTOR, starter housing	FLHTK, FLHTKL
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (2)	FLHTK, FLHTKL
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLHTK, FLHTKL
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHTK, FLHTKL
9	72543-07BK	HOUSING, three-way socket (black)	FLHTK, FLHTKL
10	72544-07	SECONDARY LOCK, three-way socket	FLHTK, FLHTKL
11	69200175	CADDY, fuse block, electrical panel	FLHTK, FLHTKL

WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8)




Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHTK, FLHTKL

2	10147	CLIP, connector	FLHTK, FLHTKL
3	10177	CABLE STRAP, anchored (3)	FLHTK, FLHTKL
4	72065-06A	HOUSING, three-way socket	FLHTK, FLHTKL
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHTK, FLHTKL
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLHTK, FLHTKL
7	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLHTK, FLHTKL
8	72175-07BK	HOUSING, four-way pin (black) (2)	FLHTK, FLHTKL
9	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLHTK, FLHTKL
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLHTK, FLHTKL
11	72415-07GY	HOUSING, four-way pin (gray)	FLHTK, FLHTKL
12	72473-07	SEAL PIN, natural	FLHTK, FLHTKL
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLHTK, FLHTKL
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLHTK, FLHTKL
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHTK, FLHTKL
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLHTK, FLHTKL
17	72519-09BK	PLUG, weather, three-way socket (2)	FLHTK, FLHTKL
18	72533-06	PLUG, weather, two-way pin	FLHTK, FLHTKL
19	72544-07	SECONDARY LOCK, three-way socket	FLHTK, FLHTKL
20	72589-09	HOUSING, three-way socket	FLHTK, FLHTKL
21	72606-08	HOUSING, two-way socket (black) (2)	FLHTK, FLHTKL
22	72609-08	SECONDARY LOCK, two-way socket (2)	FLHTK, FLHTKL
23	72610-08	WIRE SEAL, 18-20 AWG (white) (4)	FLHTK, FLHTKL
24	73213-07	RETAINER, anchored (6)	FLHTK, FLHTKL
25	74112-98BK	HOUSING, two-way socket (black)	FLHTK, FLHTKL
26	74152-98	SECONDARY LOCK, two-way socket	FLHTK, FLHTKL
27	74191-98	TERMINAL, socket (2)	FLHTK, FLHTKL
28	12500014	CABLE STRAP (2)	FLHTK, FLHTKL
29	69200183	HOUSING, 26-way socket	FLHTK, FLHTKL
30	69200184	COVER, wire	FLHTK, FLHTKL
31	69200185	TERMINAL, socket, 20 AWG (6)	FLHTK, FLHTKL
32	69200186	TERMINAL, socket, 14-16 AWG (2)	FLHTK, FLHTKL
33	69200187	TERMINAL, socket, 12 AWG (2)	FLHTK, FLHTKL
34	69200188	WIRE SEAL, 20 AWG (6)	FLHTK, FLHTKL
35	69200189	WIRE SEAL, 14-16 AWG (2)	FLHTK, FLHTKL
36	69200190	WIRE SEAL, 12 AWG (2)	FLHTK, FLHTKL
37	69200191	SEAL PIN (16)	FLHTK, FLHTKL
38	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLHTK, FLHTKL
39	69200272	HOUSING, two-way pin (black)	FLHTK, FLHTKL
40	69201301	WIRE SEAL, 20-22 AWG (green) (3)	FLHTK, FLHTKL
41	69201396	TERMINAL, socket, 20 AWG (2)	FLHTK, FLHTKL
42	69201400	HOUSING, two-way socket, CPA (black)	FLHTK, FLHTKL
43	69201401	SECONDARY LOCK, two-way socket	FLHTK, FLHTKL
44	69201404	RETAINER, anchored	FLHTK, FLHTKL
45	69201405	RESISTOR PACK	FLHTK, FLHTKL
46	69201406	HOUSING, three-way socket	FLHTK, FLHTKL
47	69201407	TERMINAL, socket, 20 AWG (3)	FLHTK, FLHTKL

48	69201423	DC LEAD ASSEMBLY, two-way socket	FLHTK, FLHTKL
49	12500018	CABLE STRAP	FLHTK, FLHTKL

WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8)




Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
NOTE: Includes the following parts.			

1	6990	WEATHER PLUG, six-way pin	FLHTK, FLHTKL
2	10006	CABLE STRAP (2)	FLHTK, FLHTKL
3	10065	CABLE STRAP (2)	FLHTK, FLHTKL
4	31586-07	RELAY (2)	FLHTK, FLHTKL
5	72064-06	HOUSING, three-way socket (black)	FLHTK, FLHTKL
6	72081-11	HOUSING, 48-way socket	FLHTK, FLHTKL
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLHTK, FLHTKL
8	72146-94	SECONDARY LOCK, six-way pin	FLHTK, FLHTKL
9	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLHTK, FLHTKL
10	72175-07BK	HOUSING, four-way pin (black)	FLHTK, FLHTKL
11	72188-07BK	HOUSING, six-way pin (black)	FLHTK, FLHTKL
12	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLHTK, FLHTKL
13	72194-94	TERMINAL, pin, 20 AWG (3)	FLHTK, FLHTKL
14	72195-94	SEAL PIN	FLHTK, FLHTKL
15	72209-11	COVER, wire	FLHTK, FLHTKL
16	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLHTK, FLHTKL
17	72226-11	TERMINAL, socket, 14-16 AWG	FLHTK, FLHTKL
18	72227-11	TERMINAL, socket, 18-20 AWG (5)	FLHTK, FLHTKL
19	72256-11	SEAL PIN (9)	FLHTK, FLHTKL
20	72296-95	TERMINAL, socket, 14-16 AWG (3)	FLHTK, FLHTKL
21	72298-95	WIRE SEAL, 14-18 AWG (green) (3)	FLHTK, FLHTKL
22	72299-95	SEAL PIN, green (2)	FLHTK, FLHTKL
23	72308-97	TERMINAL, socket, 12-14 AWG (5)	FLHTK, FLHTKL
24	72330-95	FUSE, 15 A (blue)	FLHTK, FLHTKL
25	72331-95	FUSE, 5 A (tan) (2)	FLHTK, FLHTKL
26	72345-02	FUSE, 20 A (yellow) (3)	FLHTK, FLHTKL
27	72350-11	HOUSING, one-way socket (black)	FLHTK, FLHTKL
28	72356-95	TERMINAL, socket, 18-20 AWG (14)	FLHTK, FLHTKL
29	72412-97	WIRE SEAL, 12-14 AWG (gray) (5)	FLHTK, FLHTKL
30	72484-08	TERMINAL, socket, 20 AWG (3)	FLHTK, FLHTKL
31	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHTK, FLHTKL
32	72575-11	SECONDARY LOCK, one-way socket	FLHTK, FLHTKL
33	72632-10	PLUG, weather, four-way pin	FLHTK, FLHTKL
34	73213-07	RETAINER, anchored	FLHTK, FLHTKL
35	73301-04	HOUSING, two-way pin	FLHTK, FLHTKL
36	73303-04	SECONDARY LOCK, two-way socket	FLHTK, FLHTKL
37	73304-04	TERMINAL, socket, 10 AWG (3)	FLHTK, FLHTKL
38	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLHTK, FLHTKL
39	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLHTK, FLHTKL
40	69200194	FUSE BLOCK, 24-way	FLHTK, FLHTKL
41	69200199	WIRE SEAL, 18-20 AWG (purple) (14)	FLHTK, FLHTKL
42	69200212	HARNESS, battery tender	FLHTK, FLHTKL
43	69200293	FUSE, 7.5 A (brown) (2)	FLHTK, FLHTKL
44	69200312	SECONDARY LOCK, fuse block (3)	FLHTK, FLHTKL

45	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLHTK, FLHTKL
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHTK, FLHTKL
47	69201307	BOOT, battery positive	FLHTK, FLHTKL
48	69201411	COVER, fuse block	FLHTK, FLHTKL


WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (6)	FLHR

2	70291-89	HOUSING, four-way pin	FLHR
3	72039-71A	TERMINAL, pin (3)	FLHR
4	72364-06	TERMINAL, insulated	FLHR
5	72907-11	HOUSING, four-way pin (black)	FLHR
6	72909-11	TERMINAL, pin, 20-22 AWG (4)	FLHR
7	72914-01BK	HOUSING, four-way socket (black)	FLHR
8	72991-01	TERMINAL, socket 18-22 AWG (3)	FLHR
9	73104-96BK	HOUSING, four-way pin (black)	FLHR
10	73106-96BK	HOUSING, six-way pin (black)	FLHR
11	73190-96	TERMINAL, pin, 16-20 AWG (8)	FLHR
12	69200202	WIRE TROUGH	FLHR
13	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHR
14	69200284A	BRACKET, mounting	FLHR
15	69201163	HOUSING, six-way pin (black)	FLHR
16	69201164	TERMINAL, pin, 22 AWG (6)	FLHR
17	69201287	BRACKET, mounting, electrical connector	FLHR
18	69201459	BRACKET	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
NOTE: Includes the following parts.			
1	5118	SEAL PIN	FLHR

2	10065	CABLE STRAP (2)	FLHR
3	70291-89	HOUSING, four-way pin	FLHR
4	70292-89	HOUSING, four-way socket	FLHR
5	72039-71A	TERMINAL, pin (2)	FLHR
6	72449-01	HOUSING, two-way socket (black)	FLHR
7	72450-01	HOUSING, two-way socket (gray)	FLHR
8	72527-01	TERMINAL, socket, 18-20 AWG (4)	FLHR
9	72633-02	WIRE SEAL, 14-16 AWG (white) (4)	FLHR
10	72905-11	HOUSING, two-way pin (black)	FLHR
11	72907-11	HOUSING, four-way pin (black)	FLHR
12	72909-11	TERMINAL, pin, 20-22 AWG (5)	FLHR
13	69200220	HOUSING, two-way socket (black)	FLHR
14	69200221	TERMINAL, socket, 18-20 AWG (2)	FLHR
15	69200222	WIRE SEAL, 16 AWG (green) (2)	FLHR
16	69200285	BRACKET, mounting	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHR

2	10177	CABLE STRAP, anchored (2)	FLHR
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHR
4	72009-05	HOUSING, two-way pin (black) (2)	FLHR
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLHR
6	72098-06	HOUSING, two-way socket (gray)	FLHR
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHR
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHR
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHR
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLHR
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHR
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHR
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHR
14	69201390	HOUSING, two-way socket (2)	FLHR
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHR
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHR
17	69201393	HOUSING, two-way socket (black)	FLHR
18	69201394	HOUSING, six-way socket	FLHR
19	69201395	SECONDARY LOCK, six-way socket	FLHR
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHR
21	69201397	HOUSING, two-way pin	FLHR
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHR
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHR
24	69201416	CPA, six-way socket	FLHR
25	69201441	HOUSING, four-way socket	FLHR
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHR

2	10147	CLIP, connector	FLHR
3	72213-94	TERMINAL, socket,16-20 AWG (2)	FLHR
4	72518-01	HOUSING, two-way socket (red)	FLHR
5	72533-06	PLUG, weather, two-way pin	FLHR
6	72609-08	SECONDARY LOCK, two-way socket	FLHR
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHR
8	72664-12A	HOUSING, 18-way socket (black)	FLHR
9	72666-12	TERMINAL, socket, 18-20 AWG (43)	FLHR
10	72720-07	HOUSING, two-way socket (black)	FLHR
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHR
12	69201415	HOUSING, 18-way socket (brown)	FLHR
13	69201440	HOUSING, 18-way socket (gray)	FLHR
14	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLHR

2	72169-07	TERMINAL, pin, 16-20 AWG (8)	FLHR
3	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLHR
4	72478-07BK	HOUSING, eight-way pin (black)	FLHR
5	73213-07	RETAINER, anchored	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLHR

2	10065	CABLE STRAP (4)	FLHR
3	11779	FASTENER, push-in (black) (2)	FLHR
4	72291-94	TERMINAL, socket, 14-16 AWG	FLHR
5	72295-94	CONNECTOR, starter housing	FLHR
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (2)	FLHR
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLHR
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHR
9	72543-07BK	HOUSING, three-way socket (black)	FLHR
10	72544-07	SECONDARY LOCK, three-way socket	FLHR
11	69200175	CADDY, fuse block, electrical panel	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
NOTE: Includes the following parts.			
1	10065	CABLE STRAP	FLHR

2	10147	CLIP, connector (2)	FLHR
3	10177	CABLE STRAP, anchored (3)	FLHR
4	72065-06A	HOUSING, three-way socket	FLHR
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHR
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLHR
7	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLHR
8	72175-07BK	HOUSING, four-way pin (black)	FLHR
9	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHR
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLHR
11	72415-07GY	HOUSING, four-way pin (gray)	FLHR
12	72473-07	SEAL PIN, natural	FLHR
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLHR
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLHR
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHR
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLHR
17	72519-09BK	PLUG, weather, three-way socket (2)	FLHR
18	72533-06	PLUG, weather, two-way pin	FLHR
19	72544-07	SECONDARY LOCK, three-way socket	FLHR
20	72589-09	HOUSING, three-way socket	FLHR
21	72606-08	HOUSING, two-way socket (black) (2)	FLHR
22	72607-08	HOUSING, two-way pin (black)	FLHR
23	72608-08	TERMINAL, pin, 16-20 AWG (2)	FLHR
24	72609-08	SECONDARY LOCK, two-way socket (2)	FLHR
25	72610-08	WIRE SEAL, 18-20 AWG (white) (4)	FLHR
26	73213-07	RETAINER, anchored (4)	FLHR
27	74112-98BK	HOUSING, two-way socket (black)	FLHR
28	74152-98	SECONDARY LOCK, two-way socket	FLHR
29	74191-98	TERMINAL, socket (2)	FLHR
30	12500014	CABLE STRAP (2)	FLHR
31	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLHR
32	69201396	TERMINAL, socket, 20 AWG (2)	FLHR
33	69201400	HOUSING, two-way socket, CPA (black)	FLHR
34	69201401	SECONDARY LOCK, two-way socket	FLHR
35	69201404	RETAINER, anchored	FLHR
36	69201405	RESISTOR PACK	FLHR
37	69201423	DC LEAD ASSEMBLY, two-way socket	FLHR
38	72232-96	SEAL PIN (2)	FLHR
39	12500018	CABLE STRAP	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
NOTE: Includes the following parts.			
1	6990	WEATHER PLUG, six-way pin	FLHR

2	10006	CABLE STRAP (2)	FLHR
3	10065	CABLE STRAP (2)	FLHR
4	31586-07	RELAY (2)	FLHR
5	72064-06	HOUSING, three-way socket (black)	FLHR
6	72081-11	HOUSING, 48-way socket	FLHR
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLHR
8	72146-94	SECONDARY LOCK, six-way pin	FLHR
9	72169-07	TERMINAL, pin, 16-20 AWG (6)	FLHR
10	72188-07BK	HOUSING, six-way pin (black)	FLHR
11	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLHR
12	72194-94	TERMINAL, pin, 20 AWG (3)	FLHR
13	72195-94	SEAL PIN	FLHR
14	72209-11	COVER, wire	FLHR
15	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLHR
16	72226-11	TERMINAL, socket, 14-16 AWG (3)	FLHR
17	72227-11	TERMINAL, socket, 18-20 AWG (3)	FLHR
18	72256-11	SEAL PIN (9)	FLHR
19	72296-95	TERMINAL, socket, 14-16 AWG (2)	FLHR
20	72298-95	WIRE SEAL, 14-18 AWG (green) (2)	FLHR
21	72299-95	SEAL PIN, green (4)	FLHR
22	72308-97	TERMINAL, socket, 12-14 AWG (3)	FLHR
23	72330-95	FUSE, 15 A (blue)	FLHR
24	72331-95	FUSE, 5 A (tan) (2)	FLHR
25	72345-02	FUSE, 20 A (yellow) (2)	FLHR
26	72350-11	HOUSING, one-way socket (black)	FLHR
27	72356-95	TERMINAL, socket, 18-20 AWG (15)	FLHR
28	72412-97	WIRE SEAL, 12-14 AWG (gray) (3)	FLHR
29	72484-08	TERMINAL, socket, 20 AWG (3)	FLHR
30	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHR
31	72575-11	SECONDARY LOCK, one-way socket	FLHR
32	73213-07	RETAINER, anchored	FLHR
33	73301-04	HOUSING, two-way pin	FLHR
34	73303-04	SECONDARY LOCK, two-way socket	FLHR
35	73304-04	TERMINAL, socket, 10 AWG (3)	FLHR
36	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLHR
37	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLHR
38	69200194	FUSE BLOCK, 24-way	FLHR
39	69200199	WIRE SEAL, 18-20 AWG (purple) (15)	FLHR
40	69200212	HARNESS, battery tender	FLHR
41	69200293	FUSE, 7.5 A (brown) (2)	FLHR
42	69200312	SECONDARY LOCK, fuse block (3)	FLHR
43	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLHR
44	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHR
45	69201307	BOOT, battery positive	FLHR
46	69201411	COVER, fuse block	FLHR


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (6)	FLHR, FLHRC

2	70291-89	HOUSING, four-way pin	FLHR, FLHRC
3	72039-71A	TERMINAL, pin (3)	FLHR, FLHRC
4	72364-06	TERMINAL, insulated	FLHR, FLHRC
5	72907-11	HOUSING, four-way pin (black)	FLHR, FLHRC
6	72909-11	TERMINAL, pin, 20-22 AWG (4)	FLHR, FLHRC
7	72914-01BK	HOUSING, four-way socket (black)	FLHR, FLHRC
8	72991-01	TERMINAL, socket 18-22 AWG (3)	FLHR, FLHRC
9	73104-96BK	HOUSING, four-way pin (black)	FLHR, FLHRC
10	73106-96BK	HOUSING, six-way pin (black)	FLHR, FLHRC
11	73190-96	TERMINAL, pin, 16-20 AWG (8)	FLHR, FLHRC
12	69200202	WIRE TROUGH	FLHR, FLHRC
13	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHR, FLHRC
14	69200284A	BRACKET, mounting	FLHR, FLHRC
15	69201163	HOUSING, six-way pin (black)	FLHR, FLHRC
16	69201164	TERMINAL, pin, 22 AWG (6)	FLHR, FLHRC
17	69201287	BRACKET, mounting, electrical connector	FLHR, FLHRC
18	69201459	BRACKET	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
NOTE: Includes the following parts.			
1	5118	SEAL PIN	FLHR, FLHRC

2	10065	CABLE STRAP (3)	FLHR, FLHRC
3	70291-89	HOUSING, four-way pin	FLHR, FLHRC
4	70292-89	SOCKET HOUSING, four-way	FLHR, FLHRC
5	72039-71A	TERMINAL, pin (2)	FLHR, FLHRC
6	72449-01	HOUSING, two-way socket (black)	FLHR, FLHRC
7	72450-01	HOUSING, two-way socket (gray)	FLHR, FLHRC
8	72527-01	TERMINAL, socket, 18-20 AWG (4)	FLHR, FLHRC
9	72633-02	WIRE SEAL, 14-16 AWG (white) (4)	FLHR, FLHRC
10	72905-11	HOUSING, two-way pin (black)	FLHR, FLHRC
11	72907-11	HOUSING, four-way pin (black)	FLHR, FLHRC
12	72909-11	TERMINAL, pin, 20-22 AWG (5)	FLHR, FLHRC
13	74112-98BK	HOUSING, two-way socket (black)	FLHR, FLHRC
14	74152-98	SECONDARY LOCK, two-way socket	FLHR, FLHRC
15	74191-98	TERMINAL, socket (2)	FLHR, FLHRC
16	69200220	HOUSING, two-way socket (black)	FLHR, FLHRC
17	69200221	TERMINAL, socket, 18-20 AWG (2)	FLHR, FLHRC
18	69200222	WIRE SEAL, 16 AWG (green) (2)	FLHR, FLHRC
19	69200285	BRACKET, mounting	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHR, FLHRC

2	10177	CABLE STRAP, anchored (2)	FLHR, FLHRC
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHR, FLHRC
4	72009-05	HOUSING, two-way pin (black) (2)	FLHR, FLHRC
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLHR, FLHRC
6	72098-06	HOUSING, two-way socket (gray)	FLHR, FLHRC
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHR, FLHRC
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHR, FLHRC
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHR, FLHRC
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLHR, FLHRC
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHR, FLHRC
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHR, FLHRC
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHR, FLHRC
14	69201390	HOUSING, two-way socket (2)	FLHR, FLHRC
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHR, FLHRC
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHR, FLHRC
17	69201393	HOUSING, two-way socket (black)	FLHR, FLHRC
18	69201394	HOUSING, six-way socket	FLHR, FLHRC
19	69201395	SECONDARY LOCK, six-way socket	FLHR, FLHRC
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHR, FLHRC
21	69201397	HOUSING, two-way pin	FLHR, FLHRC
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHR, FLHRC
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHR, FLHRC
24	69201416	CPA, six-way socket	FLHR, FLHRC
25	69201441	HOUSING, four-way socket	FLHR, FLHRC
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHR, FLHRC

2	10147	CLIP, connector	FLHR, FLHRC
3	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLHR, FLHRC
4	72518-01	HOUSING, two-way socket (red)	FLHR, FLHRC
5	72533-06	PLUG, weather, two-way pin	FLHR, FLHRC
6	72609-08	SECONDARY LOCK, two-way socket	FLHR, FLHRC
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLHR, FLHRC
8	72664-12A	HOUSING, 18-way socket (black)	FLHR, FLHRC
9	72666-12	TERMINAL, socket, 18-20 AWG (43)	FLHR, FLHRC
10	72720-07	HOUSING, two-way socket (black)	FLHR, FLHRC
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLHR, FLHRC
12	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLHR, FLHRC
13	69201415	HOUSING, 18-way socket (brown)	FLHR, FLHRC
14	69201440	HOUSING, 18-way socket (gray)	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLHR, FLHRC

2	72169-07	TERMINAL, pin, 16-20 AWG (8)	FLHR, FLHRC
3	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLHR, FLHRC
4	72478-07BK	HOUSING, eight-way pin (black)	FLHR, FLHRC
5	73213-07	RETAINER, anchored	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLHR, FLHRC

2	10065	CABLE STRAP (4)	FLHR, FLHRC
3	11779	FASTENER, push-in (black) (2)	FLHR, FLHRC
4	72291-94	TERMINAL, socket, 14-16 AWG	FLHR, FLHRC
5	72295-94	CONNECTOR, starter housing	FLHR, FLHRC
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (3)	FLHR, FLHRC
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLHR, FLHRC
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHR, FLHRC
9	72543-07BK	HOUSING, three-way socket (black)	FLHR, FLHRC
10	72544-07	SECONDARY LOCK, three-way socket	FLHR, FLHRC
11	69200175	CADDY, fuse block, electrical panel	FLHR, FLHRC

WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8)




Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLHR, FLHRC

2	10147	CLIP, connector (2)	FLHR, FLHRC
3	10177	CABLE STRAP, anchored (3)	FLHR, FLHRC
4	72065-06A	HOUSING, three-way socket	FLHR, FLHRC
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHR, FLHRC
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLHR, FLHRC
7	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLHR, FLHRC
8	72175-07BK	HOUSING, four-way pin (black)	FLHR, FLHRC
9	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLHR, FLHRC
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLHR, FLHRC
11	72415-07GY	HOUSING, four-way pin (gray)	FLHR, FLHRC
12	72473-07	SEAL PIN, natural	FLHR, FLHRC
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLHR, FLHRC
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLHR, FLHRC
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHR, FLHRC
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLHR, FLHRC
17	72519-09BK	PLUG, weather, three-way socket (2)	FLHR, FLHRC
18	72533-06	PLUG, weather, two-way pin	FLHR, FLHRC
19	72544-07	SECONDARY LOCK, three-way socket	FLHR, FLHRC
20	72589-09	HOUSING, three-way socket	FLHR, FLHRC
21	72606-08	HOUSING, two-way socket (black) (3)	FLHR, FLHRC
22	72607-08	HOUSING, two-way pin (black)	FLHR, FLHRC
23	72608-08	TERMINAL, pin, 16-20 AWG (2)	FLHR, FLHRC
24	72609-08	SECONDARY LOCK, two-way socket (3)	FLHR, FLHRC
25	72610-08	WIRE SEAL, 18-20 AWG (white) (6)	FLHR, FLHRC
26	73213-07	RETAINER, anchored (4)	FLHR, FLHRC
27	74112-98BK	HOUSING, two-way socket (black)	FLHR, FLHRC
28	74152-98	SECONDARY LOCK, two-way socket	FLHR, FLHRC
29	74191-98	TERMINAL, socket (2)	FLHR, FLHRC
30	12500014	CABLE STRAP (2)	FLHR, FLHRC
31	69200183	HOUSING, 26-way socket	FLHR, FLHRC
32	69200184	COVER, wire	FLHR, FLHRC
33	69200185	TERMINAL, socket, 20 AWG (6)	FLHR, FLHRC
34	69200186	TERMINAL, socket, 14-16 AWG (2)	FLHR, FLHRC
35	69200187	TERMINAL, socket, 12 AWG (2)	FLHR, FLHRC
36	69200188	WIRE SEAL, 20 AWG (6)	FLHR, FLHRC
37	69200189	WIRE SEAL, 14-16 AWG (2)	FLHR, FLHRC
38	69200190	WIRE SEAL, 12 AWG (2)	FLHR, FLHRC
39	69200191	SEAL PIN (16)	FLHR, FLHRC
40	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLHR, FLHRC
41	69201396	TERMINAL, socket, 20 AWG (2)	FLHR, FLHRC
42	69201400	HOUSING, two-way socket, CPA (black)	FLHR, FLHRC
43	69201401	SECONDARY LOCK, two-way socket	FLHR, FLHRC
44	69201404	RETAINER, anchored	FLHR, FLHRC
45	69201405	RESISTOR PACK	FLHR, FLHRC
46	69201423	DC LEAD ASSEMBLY, two-way socket	FLHR, FLHRC
47	72232-96	SEAL PIN (2)	FLHR, FLHRC

48	12500018	CABLE STRAP	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
NOTE: Includes the following parts.			
1	6990	WEATHER PLUG, six-way pin	FLHR, FLHRC

2	10006	CABLE STRAP (2)	FLHR, FLHRC
3	10065	CABLE STRAP (2)	FLHR, FLHRC
4	31586-07	RELAY (2)	FLHR, FLHRC
5	72064-06	HOUSING, three-way socket (black)	FLHR, FLHRC
6	72081-11	HOUSING, 48-way socket	FLHR, FLHRC
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLHR, FLHRC
8	72146-94	SECONDARY LOCK, six-way pin	FLHR, FLHRC
9	72169-07	TERMINAL, pin, 16-20 AWG (6)	FLHR, FLHRC
10	72188-07BK	HOUSING, six-way pin (black)	FLHR, FLHRC
11	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLHR, FLHRC
12	72194-94	TERMINAL, pin, 20 AWG (3)	FLHR, FLHRC
13	72195-94	SEAL PIN	FLHR, FLHRC
14	72209-11	COVER, wire	FLHR, FLHRC
15	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLHR, FLHRC
16	72226-11	TERMINAL, socket, 14-16 AWG (3)	FLHR, FLHRC
17	72227-11	TERMINAL, socket, 18-20 AWG (3)	FLHR, FLHRC
18	72256-11	SEAL PIN (9)	FLHR, FLHRC
19	72296-95	TERMINAL, socket, 14-16 AWG (2)	FLHR, FLHRC
20	72298-95	WIRE SEAL, 14-18 AWG (green) (2)	FLHR, FLHRC
21	72299-95	SEAL PIN, green (4)	FLHR, FLHRC
22	72308-97	TERMINAL, socket, 12-14 AWG (3)	FLHR, FLHRC
23	72330-95	FUSE, 15 A (blue)	FLHR, FLHRC
24	72331-95	FUSE, 5 A (tan) (2)	FLHR, FLHRC
25	72345-02	FUSE, 20 A (yellow) (2)	FLHR, FLHRC
26	72350-11	HOUSING, one-way socket (black)	FLHR, FLHRC
27	72356-95	TERMINAL, socket, 18-20 AWG (15)	FLHR, FLHRC
28	72412-97	WIRE SEAL, 12-14 AWG (gray) (3)	FLHR, FLHRC
29	72484-08	TERMINAL, socket, 20 AWG (3)	FLHR, FLHRC
30	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLHR, FLHRC
31	72575-11	SECONDARY LOCK, one-way socket	FLHR, FLHRC
32	73213-07	RETAINER, anchored	FLHR, FLHRC
33	73301-04	HOUSING, two-way pin	FLHR, FLHRC
34	73303-04	SECONDARY LOCK, two-way socket	FLHR, FLHRC
35	73304-04	TERMINAL, socket, 10 AWG (3)	FLHR, FLHRC
36	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLHR, FLHRC
37	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLHR, FLHRC
38	69200194	FUSE BLOCK, 24-way	FLHR, FLHRC
39	69200199	WIRE SEAL, 18-20 AWG (purple) (15)	FLHR, FLHRC
40	69200212	HARNESS, battery tender	FLHR, FLHRC
41	69200293	FUSE, 7.5 A (brown) (2)	FLHR, FLHRC
42	69200312	SECONDARY LOCK, fuse block (3)	FLHR, FLHRC
43	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLHR, FLHRC
44	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHR, FLHRC
45	69201307	BOOT, battery positive	FLHR, FLHRC
46	69201411	COVER, fuse block	FLHR, FLHRC


WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLTRX

2	72130-04	HOUSING, 12-way socket (black)	FLTRX
3	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLTRX
4	72169-07	TERMINAL, pin, 16-20 AWG (8)	FLTRX
5	72189-04	SEAL PIN (6)	FLTRX
6	72364-06	TERMINAL, insulated	FLTRX
7	72414-07BK	HOUSING, six-way socket (black)	FLTRX
8	72473-07	SEAL PIN, natural (5)	FLTRX
9	72490-07GY	HOUSING, 12-way pin (gray)	FLTRX
10	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLTRX
11	72902-01BK	HOUSING, two-way pin (black)	FLTRX
12	72912-01BK	HOUSING, two-way socket (black)	FLTRX
13	73213-07	RETAINER, anchored	FLTRX
14	74196-04	TERMINAL, socket, 20 AWG (6)	FLTRX
15	74197-04	SECONDARY LOCK, 12-way socket	FLTRX
16	12500002	CABLE STRAP	FLTRX
17	69200201	HOUSING, two-way socket (black)	FLTRX
18	69200202	WIRE TROUGH	FLTRX
19	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLTRX
20	69200629	WIRE HARNESS, AM/FM antenna	FLTRX
21	69200700	CADDY	FLTRX
22	69201240	TERMINAL, socket, 18 AWG (2)	FLTRX
23	69201287	BRACKET, mounting, electrical connector	FLTRX
24	69201459	BRACKET	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
NOTE: Includes the following parts.			
1	5118	SEAL PIN	FLTRX

2	10006	CABLE STRAP (3)	FLTRX
3	10065	CABLE STRAP (3)	FLTRX
4	10177	CABLE STRAP, anchored	FLTRX
5	72062-06	HOUSING, two-way socket (gray)	FLTRX
6	72167-07BK	HOUSING, 16-way pin (black)	FLTRX
7	72168-07	TERMINAL, socket, 18-20 AWG (4)	FLTRX
8	72169-07	TERMINAL, pin, 16-20 AWG (39)	FLTRX
9	72175-07BK	HOUSING, four-way pin (black)	FLTRX
10	72209-11	COVER, wire	FLTRX
11	72222-11	TERMINAL, socket, 18-20 AWG (27)	FLTRX
12	72226-11	TERMINAL, socket, 14-16 AWG (8)	FLTRX
13	72256-11	SEAL PIN (13)	FLTRX
14	72414-07BK	HOUSING, six-way socket (black)	FLTRX
15	72473-07	SEAL PIN, natural (7)	FLTRX
16	72484-08	TERMINAL, socket, 20 AWG (2)	FLTRX
17	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLTRX
18	72488-07BK	HOUSING, 12-way pin (black)	FLTRX
19	72490-07GY	HOUSING, 12-way pin (gray)	FLTRX
20	72632-10	PLUG, weather, four-way pin	FLTRX
21	72905-11	HOUSING, two-way pin (black)	FLTRX
22	72907-11	HOUSING, four-way pin (black) (2)	FLTRX
23	72909-11	TERMINAL, pin, 20-22 AWG (9)	FLTRX
24	73213-07	RETAINER, anchored (3)	FLTRX
25	12500002	CABLE STRAP	FLTRX
26	69200193	HOUSING, 48-way socket	FLTRX
27	69200205	WEATHER PLUG, 12-way pin (2)	FLTRX
28	69200700	CADDY	FLTRX
29	69201163	HOUSING, six-way pin (black)	FLTRX
30	69201164	TERMINAL, pin, 22 AWG (6)	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLTRX

2	10177	CABLE STRAP, anchored (2)	FLTRX
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLTRX
4	72009-05	HOUSING, two-way pin (black) (2)	FLTRX
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLTRX
6	72098-06	HOUSING, two-way socket (gray)	FLTRX
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLTRX
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLTRX
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLTRX
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLTRX
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLTRX
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLTRX
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLTRX
14	69201390	HOUSING, two-way socket (2)	FLTRX
15	69201391	TERMINAL, socket, 20 AWG (4)	FLTRX
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLTRX
17	69201393	HOUSING, two-way socket (black)	FLTRX
18	69201394	HOUSING, six-way socket	FLTRX
19	69201395	SECONDARY LOCK, six-way socket	FLTRX
20	69201396	TERMINAL, socket, 20 AWG (4)	FLTRX
21	69201397	HOUSING, two-way pin	FLTRX
22	69201398	TERMINAL, pin, 20 AWG (2)	FLTRX
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLTRX
24	69201416	CPA, six-way socket	FLTRX
25	69201441	HOUSING, four-way socket	FLTRX
26	69201442	TERMINAL, socket, 18 AWG (4)	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLTRX

2	10147	CLIP, connector	FLTRX
3	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLTRX
4	72518-01	HOUSING, two-way socket (red)	FLTRX
5	72533-06	PLUG, weather, two-way pin	FLTRX
6	72609-08	SECONDARY LOCK, two-way socket	FLTRX
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLTRX
8	72664-12A	HOUSING, 18-way socket (black)	FLTRX
9	72666-12	TERMINAL, socket, 18-20 AWG (43)	FLTRX
10	72720-07	HOUSING, two-way socket (black)	FLTRX
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLTRX
12	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLTRX
13	69201415	HOUSING, 18-way socket (brown)	FLTRX
14	69201440	HOUSING, 18-way socket (gray)	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLTRX

2	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLTRX
3	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLTRX
4	72415-07GY	HOUSING, four-way pin (gray) (2)	FLTRX
5	73213-07	RETAINER, anchored	FLTRX
6	69200629	WIRE HARNESS, AM/FM antenna	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLTRX

2	10065	CABLE STRAP (4)	FLTRX
3	11779	FASTENER, push-in (black) (2)	FLTRX
4	72291-94	TERMINAL, socket, 14-16 AWG	FLTRX
5	72295-94	CONNECTOR, starter housing	FLTRX
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (2)	FLTRX
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLTRX
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLTRX
9	72543-07BK	HOUSING, three-way socket (black)	FLTRX
10	72544-07	SECONDARY LOCK, three-way socket	FLTRX
11	69200175	CADDY, fuse block, electrical panel	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
NOTE: Includes the following parts.			
1	10065	CABLE STRAP	FLTRX

2	10147	CLIP, connector (2)	FLTRX
3	10177	CABLE STRAP, anchored (3)	FLTRX
4	72065-06A	HOUSING, three-way socket	FLTRX
5	72127-06	SECONDARY LOCK, three-way (gray)	FLTRX
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLTRX
7	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLTRX
8	72175-07BK	HOUSING, four-way pin (black)	FLTRX
9	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLTRX
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLTRX
11	72415-07GY	HOUSING, four-way pin (gray)	FLTRX
12	72473-07	SEAL PIN, natural	FLTRX
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLTRX
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLTRX
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLTRX
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLTRX
17	72519-09BK	PLUG, weather, three-way socket (2)	FLTRX
18	72533-06	PLUG, weather, two-way pin	FLTRX
19	72544-07	SECONDARY LOCK, three-way socket	FLTRX
20	72589-09	HOUSING, three-way socket	FLTRX
21	72606-08	HOUSING, two-way socket (black) (2)	FLTRX
22	72607-08	HOUSING, two-way pin (black)	FLTRX
23	72608-08	TERMINAL, pin, 16-20 AWG (2)	FLTRX
24	72609-08	SECONDARY LOCK, two-way socket (2)	FLTRX
25	72610-08	WIRE SEAL, 18-20 AWG (white) (4)	FLTRX
26	73213-07	RETAINER, anchored (4)	FLTRX
27	74112-98BK	HOUSING, two-way socket (black)	FLTRX
28	74152-98	SECONDARY LOCK, two-way socket	FLTRX
29	74191-98	TERMINAL, socket (2)	FLTRX
30	12500014	CABLE STRAP (2)	FLTRX
31	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLTRX
32	69201396	TERMINAL, socket, 20 AWG (2)	FLTRX
33	69201400	HOUSING, two-way socket, CPA (black)	FLTRX
34	69201401	SECONDARY LOCK, two-way socket	FLTRX
35	69201404	RETAINER, anchored	FLTRX
36	69201405	RESISTOR PACK	FLTRX
37	69201423	DC LEAD ASSEMBLY, two-way socket	FLTRX
38	72232-96	SEAL PIN (2)	FLTRX
39	12500018	CABLE STRAP	FLTRX

WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8)




Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
NOTE: Includes the following parts.			
1	6990	WEATHER PLUG, six-way pin	FLTRX

2	10006	CABLE STRAP (2)	FLTRX
3	10065	CABLE STRAP (2)	FLTRX
4	31586-07	RELAY (2)	FLTRX
5	72064-06	HOUSING, three-way socket (black)	FLTRX
6	72081-11	HOUSING, 48-way socket	FLTRX
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLTRX
8	72146-94	SECONDARY LOCK, six-way pin	FLTRX
9	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLTRX
10	72175-07BK	HOUSING, four-way pin (black)	FLTRX
11	72188-07BK	HOUSING, six-way pin (black)	FLTRX
12	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLTRX
13	72194-94	TERMINAL, pin, 20 AWG (3)	FLTRX
14	72195-94	SEAL PIN	FLTRX
15	72209-11	COVER, wire	FLTRX
16	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLTRX
17	72226-11	TERMINAL, socket, 14-16 AWG	FLTRX
18	72227-11	TERMINAL, socket, 18-20 AWG (5)	FLTRX
19	72256-11	SEAL PIN (9)	FLTRX
20	72296-95	TERMINAL, socket, 14-16 AWG (3)	FLTRX
21	72298-95	WIRE SEAL, 14-18 AWG (green) (3)	FLTRX
22	72299-95	SEAL PIN, green (2)	FLTRX
23	72308-97	TERMINAL, socket, 12-14 AWG (5)	FLTRX
24	72330-95	FUSE, 15 A (blue)	FLTRX
25	72331-95	FUSE, 5 A (tan) (2)	FLTRX
26	72345-02	FUSE, 20 A (yellow) (3)	FLTRX
27	72350-11	HOUSING, one-way socket (black)	FLTRX
28	72356-95	TERMINAL, socket, 18-20 AWG (14)	FLTRX
29	72412-97	WIRE SEAL, 12-14 AWG (gray) (5)	FLTRX
30	72484-08	TERMINAL, socket, 20 AWG (3)	FLTRX
31	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLTRX
32	72575-11	SECONDARY LOCK, one-way socket	FLTRX
33	72632-10	PLUG, weather, four-way pin	FLTRX
34	73213-07	RETAINER, anchored	FLTRX
35	73301-04	HOUSING, two-way pin	FLTRX
36	73303-04	SECONDARY LOCK, two-way socket	FLTRX
37	73304-04	TERMINAL, socket, 10 AWG (3)	FLTRX
38	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLTRX
39	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLTRX
40	69200194	FUSE BLOCK, 24-way	FLTRX
41	69200199	WIRE SEAL, 18-20 AWG (purple) (14)	FLTRX
42	69200212	HARNESS, battery tender	FLTRX
43	69200293	FUSE, 7.5 A (brown) (2)	FLTRX
44	69200312	SECONDARY LOCK, fuse block (3)	FLTRX
45	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLTRX
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLTRX
47	69201307	BOOT, battery positive	FLTRX

48	69201411	COVER, fuse block	FLTRX


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
NOTE: Includes the following parts.			
1	10006	CABLE STRAP (4)	FLTRX, FLTRXS

2	72130-04	HOUSING, 12-way socket (black)	FLTRX, FLTRXS
3	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLTRX, FLTRXS
4	72169-07	TERMINAL, pin, 16-20 AWG (8)	FLTRX, FLTRXS
5	72189-04	SEAL PIN (6)	FLTRX, FLTRXS
6	72364-06	TERMINAL, insulated	FLTRX, FLTRXS
7	72414-07BK	HOUSING, six-way socket (black)	FLTRX, FLTRXS
8	72473-07	SEAL PIN, natural (5)	FLTRX, FLTRXS
9	72490-07GY	HOUSING, 12-way pin (gray)	FLTRX, FLTRXS
10	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLTRX, FLTRXS
11	72902-01BK	HOUSING, two-way pin (black)	FLTRX, FLTRXS
12	72912-01BK	HOUSING, two-way socket (black)	FLTRX, FLTRXS
13	73213-07	RETAINER, anchored	FLTRX, FLTRXS
14	74196-04	TERMINAL, socket, 20 AWG (6)	FLTRX, FLTRXS
15	74197-04	SECONDARY LOCK, 12-way socket	FLTRX, FLTRXS
16	12500002	CABLE STRAP	FLTRX, FLTRXS
17	69200201	HOUSING, two-way socket (black)	FLTRX, FLTRXS
18	69200202	WIRE TROUGH	FLTRX, FLTRXS
19	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLTRX, FLTRXS
20	69200629	WIRE HARNESS, AM/FM antenna	FLTRX, FLTRXS
21	69200700	CADDY	FLTRX, FLTRXS
22	69201240	TERMINAL, socket, 18 AWG (2)	FLTRX, FLTRXS
23	69201287	BRACKET, mounting, electrical connector	FLTRX, FLTRXS
24	69201459	BRACKET	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
NOTE: Includes the following parts.			
1	5118	SEAL PIN	FLTRX, FLTRXS

2	10006	CABLE STRAP (3)	FLTRX, FLTRXS
3	10065	CABLE STRAP (4)	FLTRX, FLTRXS
4	10177	CABLE STRAP, anchored	FLTRX, FLTRXS
5	72062-06	HOUSING, two-way socket (gray)	FLTRX, FLTRXS
6	72167-07BK	HOUSING, 16-way pin (black)	FLTRX, FLTRXS
7	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLTRX, FLTRXS
8	72169-07	TERMINAL, pin, 16-20 AWG (39)	FLTRX, FLTRXS
9	72175-07BK	HOUSING, four-way pin (black)	FLTRX, FLTRXS
10	72209-11	COVER, wire	FLTRX, FLTRXS
11	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLTRX, FLTRXS
12	72222-11	TERMINAL, socket, 18-20 AWG (27)	FLTRX, FLTRXS
13	72226-11	TERMINAL, socket, 14-16 AWG (8)	FLTRX, FLTRXS
14	72256-11	SEAL PIN (13)	FLTRX, FLTRXS
15	72414-07BK	HOUSING, six-way socket (black)	FLTRX, FLTRXS
16	72473-07	SEAL PIN, natural (7)	FLTRX, FLTRXS
17	72484-08	TERMINAL, socket, 20 AWG (2)	FLTRX, FLTRXS
18	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLTRX, FLTRXS
19	72488-07BK	HOUSING, 12-way pin (black)	FLTRX, FLTRXS
20	72490-07GY	HOUSING, 12-way pin (gray)	FLTRX, FLTRXS
21	72606-08	HOUSING, two-way socket (black)	FLTRX, FLTRXS
22	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLTRX, FLTRXS
23	72632-10	PLUG, weather, four-way pin	FLTRX, FLTRXS
24	72639-10	SECONDARY LOCK, two-way socket	FLTRX, FLTRXS
25	72905-11	HOUSING, two-way pin (black)	FLTRX, FLTRXS
26	72907-11	HOUSING, four-way pin (black) (2)	FLTRX, FLTRXS
27	72909-11	TERMINAL, pin, 20-22 AWG (9)	FLTRX, FLTRXS
28	73213-07	RETAINER, anchored (3)	FLTRX, FLTRXS
29	12500002	CABLE STRAP	FLTRX, FLTRXS
30	69200193	HOUSING, 48-way socket	FLTRX, FLTRXS
31	69200205	WEATHER PLUG, 12-way pin (2)	FLTRX, FLTRXS
32	69200700	CADDY	FLTRX, FLTRXS
33	69201163	HOUSING, six-way pin (black)	FLTRX, FLTRXS
34	69201164	TERMINAL, pin, 22 AWG (6)	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLTRX, FLTRXS

2	10177	CABLE STRAP, anchored (2)	FLTRX, FLTRXS
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLTRX, FLTRXS
4	72009-05	HOUSING, two-way pin (black) (2)	FLTRX, FLTRXS
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLTRX, FLTRXS
6	72098-06	HOUSING, two-way socket (gray)	FLTRX, FLTRXS
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLTRX, FLTRXS
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLTRX, FLTRXS
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLTRX, FLTRXS
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLTRX, FLTRXS
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLTRX, FLTRXS
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLTRX, FLTRXS
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLTRX, FLTRXS
14	69201390	HOUSING, two-way socket (2)	FLTRX, FLTRXS
15	69201391	TERMINAL, socket, 20 AWG (4)	FLTRX, FLTRXS
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLTRX, FLTRXS
17	69201393	HOUSING, two-way socket (black)	FLTRX, FLTRXS
18	69201394	HOUSING, six-way socket	FLTRX, FLTRXS
19	69201395	SECONDARY LOCK, six-way socket	FLTRX, FLTRXS
20	69201396	TERMINAL, socket, 20 AWG (4)	FLTRX, FLTRXS
21	69201397	HOUSING, two-way pin	FLTRX, FLTRXS
22	69201398	TERMINAL, pin, 20 AWG (2)	FLTRX, FLTRXS
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLTRX, FLTRXS
24	69201416	CPA, six-way socket	FLTRX, FLTRXS
25	69201441	HOUSING, four-way socket	FLTRX, FLTRXS
26	69201442	TERMINAL, socket, 18 AWG (4)	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLTRX, FLTRXS

2	10147	CLIP, connector	FLTRX, FLTRXS
3	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLTRX, FLTRXS
4	72518-01	HOUSING, two-way socket (red)	FLTRX, FLTRXS
5	72533-06	PLUG, weather, two-way pin	FLTRX, FLTRXS
6	72609-08	SECONDARY LOCK, two-way socket	FLTRX, FLTRXS
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLTRX, FLTRXS
8	72664-12A	HOUSING, 18-way socket (black)	FLTRX, FLTRXS
9	72666-12	TERMINAL, socket, 18-20 AWG (36)	FLTRX, FLTRXS
10	72720-07	HOUSING, two-way socket (black)	FLTRX, FLTRXS
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLTRX, FLTRXS
12	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLTRX, FLTRXS
13	69201415	HOUSING, 18-way socket (brown)	FLTRX, FLTRXS
14	69201440	HOUSING, 18-way socket (gray)	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLTRX, FLTRXS

2	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLTRX, FLTRXS
3	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLTRX, FLTRXS
4	72415-07GY	HOUSING, four-way pin (gray) (2)	FLTRX, FLTRXS
5	73213-07	RETAINER, anchored	FLTRX, FLTRXS
6	69200629	WIRE HARNESS, AM/FM antenna	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLTRX, FLTRXS

2	10065	CABLE STRAP (4)	FLTRX, FLTRXS
3	11779	FASTENER, push-in (black) (2)	FLTRX, FLTRXS
4	72291-94	TERMINAL, socket, 14-16 AWG	FLTRX, FLTRXS
5	72295-94	CONNECTOR, starter housing	FLTRX, FLTRXS
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (2)	FLTRX, FLTRXS
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLTRX, FLTRXS
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLTRX, FLTRXS
9	72543-07BK	HOUSING, three-way socket (black)	FLTRX, FLTRXS
10	72544-07	SECONDARY LOCK, three-way socket	FLTRX, FLTRXS
11	69200175	CADDY, fuse block, electrical panel	FLTRX, FLTRXS

WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8)




Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLTRX, FLTRXS

2	10147	CLIP, connector (2)	FLTRX, FLTRXS
3	10177	CABLE STRAP, anchored (3)	FLTRX, FLTRXS
4	72065-06A	HOUSING, three-way socket	FLTRX, FLTRXS
5	72127-06	SECONDARY LOCK, three-way (gray)	FLTRX, FLTRXS
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLTRX, FLTRXS
7	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLTRX, FLTRXS
8	72175-07BK	HOUSING, four-way pin (black)	FLTRX, FLTRXS
9	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLTRX, FLTRXS
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLTRX, FLTRXS
11	72415-07GY	HOUSING, four-way pin (gray)	FLTRX, FLTRXS
12	72473-07	SEAL PIN, natural	FLTRX, FLTRXS
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLTRX, FLTRXS
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLTRX, FLTRXS
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLTRX, FLTRXS
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLTRX, FLTRXS
17	72519-09BK	PLUG, weather, three-way socket (2)	FLTRX, FLTRXS
18	72533-06	PLUG, weather, two-way pin	FLTRX, FLTRXS
19	72544-07	SECONDARY LOCK, three-way socket	FLTRX, FLTRXS
20	72589-09	HOUSING, three-way socket	FLTRX, FLTRXS
21	72606-08	HOUSING, two-way socket (black) (3)	FLTRX, FLTRXS
22	72607-08	HOUSING, two-way pin (black)	FLTRX, FLTRXS
23	72608-08	TERMINAL, pin, 16-20 AWG (2)	FLTRX, FLTRXS
24	72609-08	SECONDARY LOCK, two-way socket (3)	FLTRX, FLTRXS
25	72610-08	WIRE SEAL, 18-20 AWG (white) (6)	FLTRX, FLTRXS
26	73213-07	RETAINER, anchored (4)	FLTRX, FLTRXS
27	74112-98BK	HOUSING, two-way socket (black)	FLTRX, FLTRXS
28	74152-98	SECONDARY LOCK, two-way socket	FLTRX, FLTRXS
29	74191-98	TERMINAL, socket (2)	FLTRX, FLTRXS
30	12500014	CABLE STRAP (2)	FLTRX, FLTRXS
31	69200183	HOUSING, 26-way socket	FLTRX, FLTRXS
32	69200184	COVER, wire	FLTRX, FLTRXS
33	69200185	TERMINAL, socket, 20 AWG (6)	FLTRX, FLTRXS
34	69200186	TERMINAL, socket, 14-16 AWG (2)	FLTRX, FLTRXS
35	69200187	TERMINAL, socket, 12 AWG (2)	FLTRX, FLTRXS
36	69200188	WIRE SEAL, 20 AWG (6)	FLTRX, FLTRXS
37	69200189	WIRE SEAL, 14-16 AWG (2)	FLTRX, FLTRXS
38	69200190	WIRE SEAL, 12 AWG (2)	FLTRX, FLTRXS
39	69200191	SEAL PIN (16)	FLTRX, FLTRXS
40	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLTRX, FLTRXS
41	69201396	TERMINAL, socket, 20 AWG (2)	FLTRX, FLTRXS
42	69201400	HOUSING, two-way socket, CPA (black)	FLTRX, FLTRXS
43	69201401	SECONDARY LOCK, two-way socket	FLTRX, FLTRXS
44	69201404	RETAINER, anchored	FLTRX, FLTRXS
45	69201405	RESISTOR PACK	FLTRX, FLTRXS
46	69201423	DC LEAD ASSEMBLY, two-way socket	FLTRX, FLTRXS
47	72232-96	SEAL PIN (2)	FLTRX, FLTRXS

48	12500018	CABLE STRAP	FLTRX, FLTRXS

WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8)




Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS

NOTE: Includes the following parts.			
1	6990	WEATHER PLUG, six-way pin	FLTRX, FLTRXS
2	10006	CABLE STRAP (2)	FLTRX, FLTRXS
3	10065	CABLE STRAP (2)	FLTRX, FLTRXS
4	31586-07	RELAY (2)	FLTRX, FLTRXS
5	72064-06	HOUSING, three-way socket (black)t	FLTRX, FLTRXS
6	72081-11	HOUSING, 48-way socket	FLTRX, FLTRXS
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLTRX, FLTRXS
8	72146-94	SECONDARY LOCK, six-way pin	FLTRX, FLTRXS
9	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLTRX, FLTRXS
10	72175-07BK	HOUSING, four-way pin (black)	FLTRX, FLTRXS
11	72188-07BK	HOUSING, six-way pin (black)	FLTRX, FLTRXS
12	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLTRX, FLTRXS
13	72194-94	TERMINAL, pin, 20 AWG (3)	FLTRX, FLTRXS
14	72195-94	SEAL PIN	FLTRX, FLTRXS
15	72209-11	COVER, wire	FLTRX, FLTRXS
16	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLTRX, FLTRXS
17	72226-11	TERMINAL, socket, 14-16 AWG	FLTRX, FLTRXS
18	72227-11	TERMINAL, socket, 18-20 AWG (5)	FLTRX, FLTRXS
19	72256-11	SEAL PIN (9)	FLTRX, FLTRXS
20	72296-95	TERMINAL, socket, 14-16 AWG (3)	FLTRX, FLTRXS
21	72298-95	WIRE SEAL, 14-18 AWG (green) (3)	FLTRX, FLTRXS
22	72299-95	SEAL PIN, green (2)	FLTRX, FLTRXS
23	72308-97	TERMINAL, socket, 12-14 AWG (5)	FLTRX, FLTRXS
24	72330-95	FUSE, 15 A (blue)	FLTRX, FLTRXS
25	72331-95	FUSE, 5 A (tan) (2)	FLTRX, FLTRXS
26	72345-02	FUSE, 20 A (yellow) (3)	FLTRX,

			FLTRXS
27	72350-11	HOUSING, one-way socket (black)	FLTRX, FLTRXS
28	72356-95	TERMINAL, socket, 18-20 AWG (14)	FLTRX, FLTRXS
29	72412-97	WIRE SEAL, 12-14 AWG (gray) (5)	FLTRX, FLTRXS
30	72484-08	TERMINAL, socket, 20 AWG (3)	FLTRX, FLTRXS
31	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLTRX, FLTRXS
32	72575-11	SECONDARY LOCK, one-way socket	FLTRX, FLTRXS
33	72632-10	PLUG, weather, four-way pin	FLTRX, FLTRXS
34	73213-07	RETAINER, anchored	FLTRX, FLTRXS
35	73301-04	HOUSING, two-way pin	FLTRX, FLTRXS
36	73303-04	SECONDARY LOCK, two-way socket	FLTRX, FLTRXS
37	73304-04	TERMINAL, socket, 10 AWG (3)	FLTRX, FLTRXS
38	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLTRX, FLTRXS
39	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLTRX, FLTRXS
40	69200194	FUSE BLOCK, 24-way	FLTRX, FLTRXS
41	69200199	WIRE SEAL, 18-20 AWG (purple) (14)	FLTRX, FLTRXS
42	69200212	HARNESS, battery tender	FLTRX, FLTRXS
43	69200293	FUSE, 7.5 A (brown) (2)	FLTRX, FLTRXS
44	69200312	SECONDARY LOCK, fuse block (3)	FLTRX, FLTRXS
45	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLTRX, FLTRXS
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLTRX, FLTRXS
47	69201307	BOOT, battery positive	FLTRX, FLTRXS
48	69201411	COVER, fuse block	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLTRU

2	10065	CABLE STRAP	FLTRU
3	72130-04	HOUSING, 12-way socket (black)	FLTRU
4	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLTRU
5	72169-07	TERMINAL, pin, 16-20 AWG (8)	FLTRU
6	72189-04	SEAL PIN (6)	FLTRU
7	72364-06	TERMINAL, insulated	FLTRU
8	72414-07BK	HOUSING, six-way socket (black)	FLTRU
9	72473-07	SEAL PIN, natural (5)	FLTRU
10	72490-07GY	HOUSING, 12-way pin (gray)	FLTRU
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLTRU
12	73213-07	RETAINER, anchored	FLTRU
13	74196-04	TERMINAL, socket, 20 AWG (6)	FLTRU
14	74197-04	SECONDARY LOCK, 12-way socket	FLTRU
15	12500002	CABLE STRAP	FLTRU
16	69200201	HOUSING, two-way socket (black)	FLTRU
17	69200202	WIRE TROUGH	FLTRU
18	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLTRU
19	69201017	WIRE HARNESS, AM/FM antenna	FLTRU
20	69200700	CADDY	FLTRU
21	69201018A	WIRE HARNESS, CB antenna	FLTRU
22	69201287	BRACKET, mounting, electrical connector	FLTRU
23	69201459	BRACKET	FLTRU


WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
NOTE: Includes the following parts.			
1	5118	SEAL PIN	FLTRU

2	10006	CABLE STRAP (3)	FLTRU
3	10065	CABLE STRAP (3)	FLTRU
4	10177	CABLE STRAP, anchored	FLTRU
5	72062-06	HOUSING, two-way socket (gray)	FLTRU
6	72167-07BK	HOUSING, 16-way pin (black)	FLTRU
7	72168-07	TERMINAL, socket, 18-20 AWG (4)	FLTRU
8	72169-07	TERMINAL, pin, 16-20 AWG (35)	FLTRU
9	72209-11	COVER, wire	FLTRU
10	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLTRU
11	72222-11	TERMINAL, socket, 18-20 AWG (28)	FLTRU
12	72226-11	TERMINAL, socket, 14-16 AWG (8)	FLTRU
13	72256-11	SEAL PIN (12)	FLTRU
14	72414-07BK	HOUSING, six-way socket (black)	FLTRU
15	72473-07	SEAL PIN, natural (7)	FLTRU
16	72484-08	TERMINAL, socket, 20 AWG (2)	FLTRU
17	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLTRU
18	72488-07BK	HOUSING, 12-way pin (black)	FLTRU
19	72490-07GY	HOUSING, 12-way pin (gray)	FLTRU
20	72606-08	HOUSING, two-way socket (black)	FLTRU
21	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLTRU
22	72639-10	SECONDARY LOCK, two-way socket	FLTRU
23	72905-11	HOUSING, two-way pin (black)	FLTRU
24	72907-11	HOUSING, four-way pin (black) (2)	FLTRU
25	72909-11	TERMINAL, pin, 20-22 AWG (9)	FLTRU
26	73213-07	RETAINER, anchored (3)	FLTRU
27	12500002	CABLE STRAP	FLTRU
28	69200193	HOUSING, 48-way socket	FLTRU
29	69200205	WEATHER PLUG, 12-way pin (2)	FLTRU
30	69200700	CADDY	FLTRU
31	69201163	HOUSING, six-way pin (black)	FLTRU
32	69201164	TERMINAL, pin, 22 AWG (6)	FLTRU


WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLTRU

2	10177	CABLE STRAP, anchored (2)	FLTRU
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLTRU
4	72009-05	HOUSING, two-way pin (black) (2)	FLTRU
5	72010-05	WIRE SEAL, 22-26 AWG (green) (4)	FLTRU
6	72098-06	HOUSING, two-way socket (gray)	FLTRU
7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLTRU
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLTRU
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLTRU
10	72283-09	TERMINAL, socket, 14-16 AWG, 90 degree (2)	FLTRU
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLTRU
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLTRU
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLTRU
14	69201390	HOUSING, two-way socket (2)	FLTRU
15	69201391	TERMINAL, socket, 20 AWG (4)	FLTRU
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLTRU
17	69201393	HOUSING, two-way socket (black)	FLTRU
18	69201394	HOUSING, six-way socket	FLTRU
19	69201395	SECONDARY LOCK, six-way socket	FLTRU
20	69201396	TERMINAL, socket, 20 AWG (4)	FLTRU
21	69201397	HOUSING, two-way pin	FLTRU
22	69201398	TERMINAL, pin, 20 AWG (2)	FLTRU
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLTRU
24	69201416	CPA, six-way socket	FLTRU
25	69201441	HOUSING, four-way socket	FLTRU
26	69201442	TERMINAL, socket, 18 AWG (4)	FLTRU


WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLTRU

2	10147	CLIP, connector	FLTRU
3	72213-94	TERMINAL, socket, 16-20 AWG (2)	FLTRU
4	72518-01	HOUSING, two-way socket (red)	FLTRU
5	72533-06	PLUG, weather, two-way pin	FLTRU
6	72609-08	SECONDARY LOCK, two-way socket	FLTRU
7	72610-08	WIRE SEAL, 18-20 AWG (white) (2)	FLTRU
8	72664-12A	HOUSING, 18-way socket (black)	FLTRU
9	72666-12	TERMINAL, socket, 18-20 AWG (46)	FLTRU
10	72720-07	HOUSING, two-way socket (black)	FLTRU
11	72721-07	TERMINAL, socket, 18-20 AWG (2)	FLTRU
12	69201168	TERMINAL, socket, 22 AWG (silver) (2)	FLTRU
13	69201410	HOUSING, 18-way socket (brown)	FLTRU
14	69201414	HOUSING, 18-way socket (gray)	FLTRU


WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
NOTE: Includes the following parts.			
1	9819	TERMINAL, 1/4 in ring, 12 AWG (3)	FLTRU

2	10065	CABLE STRAP	FLTRU
3	72167-07BK	HOUSING, 16-way pin (black)	FLTRU
4	72168-07	TERMINAL, socket, 18-20 AWG (6)	FLTRU
5	72169-07	TERMINAL, pin, 16-20 AWG (23)	FLTRU
6	72188-07BK	HOUSING, six-way pin (black)	FLTRU
7	72249-94	HEAT SHRINK TUBE, .415 x 1 in (black)	FLTRU
8	72414-07BK	HOUSING, six-way socket (black)	FLTRU
9	72415-07GY	HOUSING, four-way pin (gray) (2)	FLTRU
10	72473-07	SEAL PIN, natural (3)	FLTRU
11	73213-07	RETAINER, anchored (3)	FLTRU
12	69201017	WIRE HARNESS, AM/FM antenna	FLTRU
13	69201018A	WIRE HARNESS, CB antenna	FLTRU


WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
NOTE: Includes the following parts.			
1	10006	CABLE STRAP	FLTRU

2	10065	CABLE STRAP (4)	FLTRU
3	11779	FASTENER, push-in (black) (2)	FLTRU
4	72291-94	TERMINAL, socket, 14-16 AWG	FLTRU
5	72295-94	CONNECTOR, starter housing	FLTRU
6	72405-98BK	WIRE ASSEMBLY, push-on, right angle molded, 65-1/2 in length (2)	FLTRU
7	72484-08	TERMINAL, socket, 20 AWG (3)	FLTRU
8	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLTRU
9	72543-07BK	HOUSING, three-way socket (black)	FLTRU
10	72544-07	SECONDARY LOCK, three-way socket	FLTRU
11	69200175	CADDY, fuse block, electrical panel	FLTRU

WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)




Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
NOTE: Includes the following parts.			
1	10065	CABLE STRAP (3)	FLTRU

2	10147	CLIP, connector	FLTRU
3	10177	CABLE STRAP, anchored (3)	FLTRU
4	72065-06A	HOUSING, three-way socket	FLTRU
5	72127-06	SECONDARY LOCK, three-way (gray)	FLTRU
6	72168-07	TERMINAL, socket, 18-20 AWG (5)	FLTRU
7	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLTRU
8	72175-07BK	HOUSING, four-way pin (black) (2)	FLTRU
9	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLTRU
10	72343-10	TERMINAL, pin, 16-20 AWG (gold) (4)	FLTRU
11	72415-07GY	HOUSING, four-way pin (gray)	FLTRU
12	72473-07	SEAL PIN, natural	FLTRU
13	72484-08	TERMINAL, socket, 20 AWG (6)	FLTRU
14	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLTRU
15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLTRU
16	72512-07BK	HOUSING, three-way socket (black) (2)	FLTRU
17	72519-09BK	PLUG, weather, three-way socket (2)	FLTRU
18	72533-06	PLUG, weather, two-way pin	FLTRU
19	72544-07	SECONDARY LOCK, three-way socket	FLTRU
20	72589-09	HOUSING, three-way socket	FLTRU
21	72606-08	HOUSING, two-way socket (black) (2)	FLTRU
22	72609-08	SECONDARY LOCK, two-way socket (2)	FLTRU
23	72610-08	WIRE SEAL, 18-20 AWG (white) (4)	FLTRU
24	73213-07	RETAINER, anchored (6)	FLTRU
25	74112-98BK	HOUSING, two-way socket (black)	FLTRU
26	74152-98	SECONDARY LOCK, two-way socket	FLTRU
27	74191-98	TERMINAL, socket (2)	FLTRU
28	12500014	CABLE STRAP (2)	FLTRU
29	69200183	HOUSING, 26-way socket	FLTRU
30	69200184	COVER, wire	FLTRU
31	69200185	TERMINAL, socket, 20 AWG (6)	FLTRU
32	69200186	TERMINAL, socket, 14-16 AWG (2)	FLTRU
33	69200187	TERMINAL, socket, 12 AWG (2)	FLTRU
34	69200188	WIRE SEAL, 20 AWG (6)	FLTRU
35	69200189	WIRE SEAL, 14-16 AWG (2)	FLTRU
36	69200190	WIRE SEAL, 12 AWG (2)	FLTRU
37	69200191	SEAL PIN (16)	FLTRU
38	69200238	TERMINAL, insulated, 20 AWG (black) (2)	FLTRU
39	69200272	HOUSING, two-way pin (black)	FLTRU
40	69201301	WIRE SEAL, 20-22 AWG (green) (3)	FLHX
41	69201396	TERMINAL, socket, 20 AWG (2)	FLTRU
42	69201400	HOUSING, two-way socket, CPA (black)	FLTRU
43	69201401	SECONDARY LOCK, two-way socket	FLTRU
44	69201404	RETAINER, anchored	FLTRU
45	69201405	RESISTOR PACK	FLTRU
46	69201406	HOUSING, three-way socket	FLTRU
47	69201407	TERMINAL, socket, 20 AWG (3)	FLTRU

48	69201423	DC LEAD ASSEMBLY, two-way socket	FLTRU
49	12500018	CABLE STRAP	FLTRU

WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)




Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
NOTE: Includes the following parts.			
1	6990	WEATHER PLUG, six-way pin	FLTRU

2	10006	CABLE STRAP (2)	FLTRU
3	10065	CABLE STRAP (2)	FLTRU
4	31586-07	RELAY (2)	FLTRU
5	72064-06	HOUSING, three-way socket (black)	FLTRU
6	72081-11	HOUSING, 48-way socket	FLTRU
7	72106-94BK	HOUSING, six-way pin (black) (replaces gray connector)	FLTRU
8	72146-94	SECONDARY LOCK, six-way pin	FLTRU
9	72169-07	TERMINAL, pin, 16-20 AWG (10)	FLTRU
10	72175-07BK	HOUSING, four-way pin (black)	FLTRU
11	72188-07BK	HOUSING, six-way pin (black)	FLTRU
12	72190-94	TERMINAL, pin, 16-18 AWG (2)	FLTRU
13	72194-94	TERMINAL, pin, 20 AWG (3)	FLTRU
14	72195-94	SEAL PIN	FLTRU
15	72209-11	COVER, wire	FLTRU
16	72222-11	TERMINAL, socket, 18-20 AWG (21)	FLTRU
17	72226-11	TERMINAL, socket, 14-16 AWG	FLTRU
18	72227-11	TERMINAL, socket, 18-20 AWG (5)	FLTRU
19	72256-11	SEAL PIN (9)	FLTRU
20	72296-95	TERMINAL, socket, 14-16 AWG (3)	FLTRU
21	72298-95	WIRE SEAL, 14-18 AWG (green) (3)	FLTRU
22	72299-95	SEAL PIN, green (2)	FLTRU
23	72308-97	TERMINAL, socket, 12-14 AWG (5)	FLTRU
24	72330-95	FUSE, 15 A (blue)	FLTRU
25	72331-95	FUSE, 5 A (tan) (2)	FLTRU
26	72345-02	FUSE, 20 A (yellow) (3)	FLTRU
27	72350-11	HOUSING, one-way socket (black)	FLTRU
28	72356-95	TERMINAL, socket, 18-20 AWG (14)	FLTRU
29	72412-97	WIRE SEAL, 12-14 AWG (gray) (5)	FLTRU
30	72484-08	TERMINAL, socket, 20 AWG (3)	FLTRU
31	72486-08	WIRE SEAL, 20 AWG (green) (3)	FLTRU
32	72575-11	SECONDARY LOCK, one-way socket	FLTRU
33	72632-10	PLUG, weather, four-way pin	FLTRU
34	73213-07	RETAINER, anchored	FLTRU
35	73301-04	HOUSING, two-way pin	FLTRU
36	73303-04	SECONDARY LOCK, two-way socket	FLTRU
37	73304-04	TERMINAL, socket, 10 AWG (3)	FLTRU
38	73305-04	SEAL WIRE, 10 AWG (blue) (3)	FLTRU
39	11100115	CLOTH, HARNESS WRAP, 50 m (not shown)	FLTRU
40	69200194	FUSE BLOCK, 24-way	FLTRU
41	69200199	WIRE SEAL, 18-20 AWG (purple) (14)	FLTRU
42	69200212	HARNESS, battery tender	FLTRU
43	69200293	FUSE, 7.5 A (brown) (2)	FLTRU
44	69200312	SECONDARY LOCK, fuse block (3)	FLTRU
45	69200336	MAIN FUSE, 50 A (red), NOTE: Fuse is sold separately and is not part of main harness	FLTRU
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLTRU
47	69201307	BOOT, battery positive	FLTRU

48	69201411	COVER, fuse block	FLTRU


WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS
(1 OF 2)



Index No.	Part No.	Description	Model(s)
	69200121	WIRING HARNESS, fairing	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
NOTE: Includes the following parts.			

1	5118	SEAL PIN	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
2	10065	CABLE STRAP (8)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
3	72167-07BK	HOUSING, 16-way pin (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
4	72169-07	TERMINAL, pin, 16-20 AWG (19)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
5	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
6	72473-07	SEAL PIN, natural (9)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
7	72490-07GY	HOUSING, 12-way pin (gray)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
8	72610-08	WIRE SEAL, 18-20 AWG (white) (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
9	72902-01BK	HOUSING, two-way pin (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
10	72905-11	HOUSING, two-way pin (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	72907-11	HOUSING, four-way pin (black) (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
12	72909-11	TERMINAL, pin, 20-22 AWG (17)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
13	72912-01BK	HOUSING, two-way socket (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
14	69200109	CADDY, fairing harness	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
15	69200254	HOUSING, four-way socket	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
16	69200256	SECONDARY LOCK, four-way socket	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
17	69201240	TERMINAL, socket, 18 AWG (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS


WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)



Index No.	Part No.	Description	Model(s)
	69200121	WIRING HARNESS, fairing	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
NOTE: Includes the following parts.			

1	10177	CABLE STRAP, anchored (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
2	72066-06A	HOUSING, four-way socket (black) (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
3	72097-06	SEAL PIN, orange (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
4	72130-04	HOUSING, 12-way socket (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
5	72135-06	SECONDARY LOCK, four-way socket (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
6	72189-04	SEAL PIN (5)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
7	72264-94	TERMINAL, socket, 18-20 AWG (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
8	72272-07	TERMINAL, socket, 14-16 AWG (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
9	72484-08	TERMINAL, socket, 20 AWG (6)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
10	72486-08	WIRE SEAL, 20 AWG (green) (6)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	73101-96BK	PIN HOUSING, two-way, with panel mount (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
12	73102-96BK	HOUSING, two-way pin (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
13	73152-96BK	HOUSING, two-way socket (black)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
14	73190-96	TERMINAL, pin, 16-20 AWG (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
15	74196-04	TERMINAL, socket, 20 AWG (7)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
16	74197-04	SECONDARY LOCK, 12-way socket	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
17	12500002	CABLE STRAP (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
18	69200271	HOUSING, two-way socket (black) (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
19	69200337	HOUSING, two-way socket (gray)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS


WIRING HARNESS, CONSOLE - FLHR AND FLHRC



Index No.	Part No.	Description	Model(s)
1	72062-06	HOUSING, two-way socket (gray)	FLHR, FLHRC
2	72130-04	HOUSING, 12-way socket (black)	FLHR, FLHRC
3	72168-07	TERMINAL, socket 18-20 AWG (8)	FLHR, FLHRC

4	72189-04	SEAL PIN (2)	FLHR, FLHRC
5	72479-07BK	HOUSING, eight-way socket (black)	FLHR, FLHRC
6	72484-08	TERMINAL, socket, 20 AWG (2)	FLHR, FLHRC
7	72485-07	HOUSING, four-way socket (black)	FLHR, FLHRC
8	72486-08	WIRE SEAL, 20 AWG (green) (2)	FLHR, FLHRC
9	72493-07	TERMINAL, socket, 16-18 AWG (4)	FLHR, FLHRC
10	72494-07	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHR, FLHRC
11	72557-07	SECONDARY LOCK, four-way socket	FLHR, FLHRC
12	72662-11	TERMINAL, socket, 22 AWG (5)	FLHR, FLHRC
13	74196-04	TERMINAL, socket, 20 AWG (5)	FLHR, FLHRC
14	74197-04	SECONDARY LOCK, 12-way socket	FLHR, FLHRC
15	69200124	WIRE HARNESS, console	FLHR, FLHRC


WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS



Index No.	Part No.	Description	Model(s)
	69200122	WIRING HARNESS - FAIRING	FLTRU, FLTRX, FLTRXS
NOTE: Includes the following parts.			
1	5118	SEAL PIN (2)	FLTRU, FLTRX, FLTRXS

2	10006	CABLE STRAP (2)	FLTRU, FLTRX, FLTRXS
3	10177	CABLE STRAP, anchored (2)	FLTRU, FLTRX, FLTRXS
4	72166-07BK	HOUSING, 16-way socket (black)	FLTRU, FLTRX, FLTRXS
5	72168-07	TERMINAL, socket, 18-20 AWG (16)	FLTRU, FLTRX, FLTRXS
6	72213-94	TERMINAL, socket, 16-20 AWG (4)	FLTRU, FLTRX, FLTRXS
7	72272-07	TERMINAL, socket, 14-16 AWG (8)	FLTRU, FLTRX, FLTRXS
8	72473-07	SEAL PIN, natural (8)	FLTRU, FLTRX, FLTRXS
9	72489-07GY	HOUSING, 12-way socket (gray)	FLTRU, FLTRX, FLTRXS
10	72610-08	WIRE SEAL, 18-20 AWG (white) (4)	FLTRU, FLTRX, FLTRXS
11	72907-11	HOUSING, four-way pin (black) (5)	FLTRU, FLTRX, FLTRXS
12	72908-11	HOUSING, four-way socket (black)	FLTRU, FLTRX, FLTRXS
13	72909-11	TERMINAL, pin, 20-22 AWG (18)	FLTRU, FLTRX, FLTRXS
14	72910-11	TERMINAL, socket, 20-22 AWG (4)	FLTRU, FLTRX, FLTRXS
15	73102-96BK	HOUSING, two-way pin (black) (2)	FLTRU, FLTRX, FLTRXS
16	73152-96BK	HOUSING, two-way socket (black)	FLTRU, FLTRX, FLTRXS
17	73190-96	TERMINAL, pin, 16-20 AWG (4)	FLTRU, FLTRX, FLTRXS
18	12500002	CABLE STRAP (2)	FLTRU, FLTRX, FLTRXS
19	69200254	HOUSING, four-way socket	FLTRU, FLTRX, FLTRXS
20	69200256	SECONDARY LOCK, four-way socket	FLTRU, FLTRX, FLTRXS
21	69200271	HOUSING, two-way socket (black) (2)	FLTRU, FLTRX, FLTRXS


BATTERY



Index No.	Part No.	Description	Model(s)
1	3634	SCREW (6)	ALL
2	4312C	SCREW (2)	ALL

3	4705	SCREW (2)	ALL
4	7792	NUT	ALL
5	14263-04	LABEL BATTERY (Brazil)	FLHRC, FLHTK, FLHXS
6	15368-01A	LABEL BATTERY WARNING	ALL
7	66010-97C	BATTERY, with 4312C (except Brazil)	ALL
	66000066	BATTERY, with 4312C (Brazil)	FLHRC, FLHTK, FLHXS
8	66051-08	STRAP, battery removal	ALL
9	72242-94	TERMINAL, ring, 10-12 AWG	ALL
10	73304-04	TERMINAL, socket, 10 AWG	ALL
11	73305-04	SEAL WIRE, 10 AWG (blue)	ALL
12	66000010	BATTERY TRAY	ALL
13	66000116	CABLE ASSEMBLY, starter to ground, with 72242-94	ALL
14	69200174	CADDY, electronic control module (ECM)	ALL
15	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	ALL
16	69201178	BRACKET, battery hold down	ALL
17	69201307	BOOT, battery positive	ALL


HORN



Index No.	Part No.	Description	Model(s)
1	3563	SCREW (2)	ALL
2	4775	SCREW (2)	ALL
3	6019	WASHER (2)	ALL

4	6109	WASHER	ALL
5	7495	NUT	ALL
6	7549A	ACORN NUT	ALL
7	8108	SPEEDNUT (2)	ALL
8	69060-90H	HORN ASSEMBLY	ALL
9	69062-91A	CLAMP	ALL
10	69120-91	BRACKET, horn	ALL
11	69123-92A	MOUNT, horn, rubber	ALL
12	14100764	INSERT, horn	ALL
13	61300523	COVER, horn (chrome)	ALL
14	69000083	BRACKET ASSEMBLY, horn mount	ALL

SWITCHES




Index No.	Part No.	Description	Model(s)
1	2647B	SCREW (2)	ALL
2	6150W	WASHER (2)	ALL

3	9907	WIRE TERMINAL (2)	ALL
4	10065	CABLE STRAP (2)	ALL
5	33926-06B	SWITCH, neutral indicator, with O-ring	ALL
6	61081-92	COVER, key head (set of 2)	ALL
7	66373-06	BATTERY, 3V, CR2032 (2)	ALL
8	68956-07	ANTENNA MODULE, security system	ALL
9	68958-07C	SIREN ALARM, with 68309-10 (Australia, England, HDI, Japan and Asia-Pacific)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
10	69309-10	BATTERY, siren alarm (Australia, England, HDI, Japan and Asia-Pacific)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
11	71540-94B	FORK LOCK (specify key number)	FLHR, FLHRC
12	71660-03	NUT, ignition switch	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
13	72023-51E	KIT, SWITCH, rear brakelite, with 9907	ALL
14	72594-11	PLUG, weather, two-way socket (without security)	FLHR, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
15	14100158	DECAL, ignition switch knob	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
16	32700010	SENSOR, ambient temperature	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
17	41000341A	BODY CONTROL MODULE (BCM) with security (Domestic, HDI)	ALL
	41000342A	BODY CONTROL MODULE (BCM) with security (Japan)	FLHR, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
	41000351A	BODY CONTROL MODULE (BCM)	FLHR, FLHTCU, FLHX, FLTRX
18	71400010A	LOCKSET, complete, with keys, ignition switch, fork lock and saddle bag lock	FLHR
	71400011A	LOCKSET, complete, with keys, ignition switch, cover and fork lock	FLHRC
19	71400012A	HOUSING, ignition switch, with 71660-03 and 71400081 (Domestic)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	71400013A	HOUSING, ignition switch, with 71660-03 and 71400081 (HDI)	FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
20	71400015A	LOCKSET, complete, with keys, ignition knob, saddlebag and Tour-Pak locks	FLHTCU, FLHTK, FLHTKL, FLTRU
	71400016A	LOCKSET, complete, with keys, ignition knob and saddlebag lock	FLHX, FLHXS, FLTRX, FLTRXS
21	71400017A	KNOB, ignition switch, with 14100158 (specify key number)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
22	71400073	SPRING, ignition knob	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
23	71400081	COLLAR, ignition switch, top	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
24	90300043	KEY, with 61081-92 (set of 2) (specify key number)	ALL
25	90300111	REMOTE CONTROL FOB, with 66373-06 (except Japan) (2)	ALL
	90300112	REMOTE CONTROL FOB, with 66373-06 (Japan) (2)	ALL

NOTE: For additional fuse and relay part number information see wiring harness pages.

SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)




Index No.	Part No.	Description	Model(s)
1	10006	CABLE STRAP	FLHTCU, FLHTK, FLHTKL, FLHXS

2	10065	CABLE STRAP (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
3	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
4	72290-94	TERMINAL, insulated (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
5	72294-94	TERMINAL, insulated (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
6	73213-07	RETAINER, anchored (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
7	77117-10	HEADSET ASSEMBLY, with 77126-10, 77148-10 and 76000243 (Domestic, California, Canada)	FLHTCU, FLHTK, FLHTKL
7	77117-10	HEADSET ASSEMBLY, with 77126-10, 77148-10 and 76000243 (HDI, Australia, Japan, Asia-Pacific, Brazil, England) (2)	FLHTK, FLHTKL
8	77126-10	WIND SOCK, microphone (Domestic, California, Canada)	FLHTCU, FLHTK, FLHTKL
8	77126-10	WIND SOCK, microphone (HDI, Australia, Japan, Asia-Pacific, Brazil, England) (2)	FLHTK, FLHTKL
9	77148-10	COILED CORD, headset (Domestic, California, Canada)	FLHTCU, FLHTK, FLHTKL
9	77148-10	COILED CORD, headset (HDI, Australia, Japan, Asia-Pacific, Brazil, England) (2)	FLHTK, FLHTKL
10	10200205	SCREW (8)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
11	10500017	SCREW (6)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
12	12600070	BOLT (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
13	12600071	RETAINER, bolt (4)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
14	12600073	SCREW, accessory module (2)	FLHTCU, FLHTK, FLHTKL, FLHXS
15	69200032	WIRE HARNESS, AM/FM antenna	FLHTCU, FLHTK, FLHTKL
	69200294	CABLE, AM/FM antenna	FLHX, FLHXS
16	69200136	WIRE HARNESS, C.B. antenna	FLHTK, FLHTKL
17	69200247	WIRE HARNESS, speaker jumper, with 10065, 72169-07, 72290-94, 72294-94, 73213-07 and 69200072 (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
18	69200272	HOUSING, two-way pin (black) (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
19	76000055	SPEAKER ADAPTOR AND GRILLE (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS

NOTE: For all service and warranty claims on Boom!™ Audio System components please refer to the latest Warranty Bulletin revision of the Boom!™ Audio Systems Warranty Procedures located on h-dnet.com. Customer: For all service and warranty claims on Boom!™ Audio System components please contact your Harley-Davidson dealership.

SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)




Index No.	Part No.	Description	Model(s)
20	76000076B	RADIO, premium, with navigation, with 12600070, 12600071, 12600073 and 76000252 (Domestic, California, Canada) (See NOTE 1)	FLHTCU, FLHTK, FLHTKL, FLHXS

	76000231B	RADIO, premium, with navigation, with 12600070, 12600071, 12600073 and 76000252 (England, HDI) (See NOTE 2)	FLHTK, FLHTKL, FLHXS
	76000232B	RADIO, premium, with 12600070, 12600071, 12600073 and 76000252 (Australia, HDI, Japan, Asia-Pacific, Brazil) (See NOTE 3)	FLHTK, FLHTKL, FLHXS
	76000075B	RADIO, standard, with 12600070 and 12600071 (Domestic, California, Canada)	FLHTCU, FLHX
	76000230B	RADIO, standard, with 12600070 and 12600071 (Canada)	FLHTCU, FLHX
21	76000096	SPEAKER, 5-1/4 in (2)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
22	76000222	ANTENNA, GPS	FLHTCU, FLHTK, FLHTKL, FLHXS
23	76000243	EAR PAD, foam (Domestic, California, Canada) (2)	FLHTCU, FLHTK, FLHTKL
23	76000243	EAR PAD, foam (HDI, Australia, Japan, Asia-Pacific, Brazil, England) (4)	FLHTK, FLHTKL
24	76000252	PLATE, accessory module	FLHTCU, FLHTK, FLHTKL, FLHXS
25	91700034	KIT, RADIO TOUCH SCREEN PROTECTOR	FLHTCU, FLHTK, FLHTKL, FLHXS

NOTE 1: 76000076B radio with the North America mapset is used in these countries/regions: Bahamas, Canada, Mexico, Puerto Rico and United States. NOTE 2: 76000231B radio with the European mapset is used in these countries/regions: Albania, Andorra, Austria, Belarus, Belgium, Bosnia, Bulgaria, Croatia, Czech Republic, Denmark, Estonia, Finland, France, Germany, Gibraltar, Greece, Hungary, Iceland, Ireland, Italy, Kosovo, Latvia, Liechtenstein, Lithuania, Luxembourg, Macedonia, Malta, Moldova, Monaco, Montenegro, Netherlands, Norway, Poland, Portugal, Romania, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey, Ukraine, United Kingdom and Vatican City. NOTE 3: 76000232B radio with the Rest Of World mapset is used in these countries/regions: Argentina, Australia, Azerbaijan, Bahrain, Bolivia, Botswana, Brazil, Brunei, Chile, Columbia, Costa Rica, Egypt, Hong Kong, India, Indonesia, Jordan, Kazakhstan, Kenya, Kuwait, Lebanon, Malaysia, Morocco, Namibia, New Zealand, Nigeria, Oman, Peru, Qatar, Reunion, Russia, Saudi Arabia, Singapore, South Africa, Thailand, United Arab Emirates, Uruguay, Venezuela and the Rest Of the World. NOTE: For all service and warranty claims on Boom!™ Audio System components please refer to the latest Warranty Bulletin revision of the Boom!™ Audio Systems Warranty Procedures located on h-dnet.com. Customer: For all service and warranty claims on Boom!™ Audio System components please contact your Harley-Davidson dealership.

SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)




Index No.	Part No.	Description	Model(s)
1	2478	SCREW (2)	FLTRU, FLTRX, FLTRXS

2	3152	SCREW (8)	FLTRU, FLTRX, FLTRXS
3	10065	CABLE STRAP	FLTRU, FLTRX, FLTRXS
4	72169-07	TERMINAL, pin, 16-20 AWG (4)	FLTRU, FLTRX, FLTRXS
5	72290-94	TERMINAL, insulated (2)	FLTRU, FLTRX, FLTRXS
6	72294-94	TERMINAL, insulated (2)	FLTRU, FLTRX, FLTRXS
7	73213-07	RETAINER, anchored (2)	FLTRU, FLTRX, FLTRXS
8	77117-10	HEADSET ASSEMBLY, with 77126-10, 77148-10 and 76000243 (Domestic, California, Canada)	FLTRU
8	77117-10	HEADSET ASSEMBLY, with 77126-10, 77148-10 and 76000243 (HDI, Japan, Asia-Pacific, England) (2)	FLTRU
9	77126-10	WIND SOCK, microphone (Domestic, California, Canada)	FLTRU
9	77126-10	WIND SOCK, microphone (HDI, Japan, Asia-Pacific, England) (2)	FLTRU
10	77148-10	COILED CORD, headset (Domestic, California, Canada)	FLTRU
10	77148-10	COILED CORD, headset (HDI, Japan, Asia-Pacific, England) (2)	FLTRU
11	12200025	CLIP (4)	FLTRU, FLTRX, FLTRXS
12	12600070	BOLT (4)	FLTRU, FLTRX, FLTRXS
13	12600071	RETAINER, bolt (4)	FLTRU, FLTRX, FLTRXS
14	12600073	SCREW, accessory module (2)	FLTRU, FLTRXS
15	47200217	BRACKET	FLTRU, FLTRX, FLTRXS
16	69200272	HOUSING, two-way pin (black) (2)	FLTRU, FLTRX, FLTRXS
17	69200629	WIRE HARNESS, AM/FM antenna	FLTRX, FLTRXS
	69201017	WIRE HARNESS, AM/FM antenna	FLTRU
18	69200752	WIRE HARNESS, speaker jumper, with 72169-07, 72290-94, 72294-94, 73213-07 and 69200272 (2)	FLTRU, FLTRX, FLTRXS
19	76000075A	RADIO, standard, with 12600070 and 12600071 (Domestic, California, Canada)	FLTRX
	76000076A	RADIO, premium, with navigation, with 12600070, 12600071, 12600073 and 76000252 (Domestic) (See NOTE 1)	FLTRU, FLTRXS
	76000231A	RADIO, premium, with navigation, with 12600070, 12600071, 12600073 and 76000252 (HDI, England) (See NOTE 2)	FLTRU, FLTRXS
	76000232A	RADIO, premium, with 12600070, 12600071, 12600073 and 76000252 (Canada, HDI, Australia, Japan, Asia-Pacific) (See NOTE 3)	FLTRU, FLTRXS

NOTE 1: 76000076A radio with the North America mapset is used in these countries/regions: Bahamas, Canada, Mexico, Puerto Rico and United States. NOTE 2: 76000231A radio with the European mapset is used in these countries/regions: Albania, Andorra, Austria, Belarus, Belgium, Bosnia, Bulgaria, Croatia, Czech Republic, Denmark, Estonia, Finland, France, Germany, Gibraltar, Greece, Hungary, Iceland, Ireland, Italy, Kosovo, Latvia, Liechtenstein, Lithuania, Luxembourg, Macedonia, Malta, Moldova, Monaco, Montenegro, Netherlands, Norway, Poland, Portugal, Romania, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey, Ukraine, United Kingdom and Vatican City. NOTE 3: 76000232A radio with the Rest Of World mapset is used in these countries/regions: Argentina, Australia, Azerbaijan, Bahrain, Bolivia, Botswana, Brazil, Brunei, Chile, Columbia, Costa Rica, Egypt, Hong Kong, India, Indonesia, Jordan, Kazakhstan, Kenya, Kuwait, Lebanon, Malaysia, Morocco, Namibia, New Zealand, Nigeria, Oman, Peru, Qatar, Reunion, Russia, Saudi Arabia, Singapore, South Africa, Thailand, United Arab Emirates, Uruguay, Venezuela and the Rest Of the World.

SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)




Index No.	Part No.	Description	Model(s)
20	76000096	SPEAKER, 5-1/4 in (2)	FLTRU, FLTRX, FLTRXS
21	76000222	ANTENNA, GPS	FLTRU, FLTRXS
22	76000243	EAR PAD, foam (Domestic, California, Canada) (2)	FLTRU

22	76000243	EAR PAD, foam (HDI, Japan, Asia-Pacific, England) (4)	FLTRU
23	76000252	PLATE	FLTRU, FLTRXS
24	76000453	SPEAKER GRILLE (right)	FLTRU, FLTRX, FLTRXS
25	76000454	SPEAKER GRILLE (left)	FLTRU, FLTRX, FLTRXS
26	76000455	GASKET (right)	FLTRU, FLTRX, FLTRXS
27	76000456	GASKET (left)	FLTRU, FLTRX, FLTRXS
28	76000468	BRACKET, radio	FLTRU, FLTRX, FLTRXS
29	91700034	KIT, RADIO TOUCH SCREEN PROTECTOR	FLTRU, FLTRXS

NOTE: For all service and warranty claims on Boom!™ Audio System components please refer to the latest Warranty Bulletin revision of the Boom!™ Audio Systems Warranty Procedures located on h-dnet.com. Customer: For all service and warranty claims on Boom!™ Audio System components please contact your Harley-Davidson dealership.


ANTENNAS



Index No.	Part No.	Description	Model(s)
1	4867	SCREW	FLHX, FLHXS, FLTRX, FLTRXS
2	7129	LOCKWASHER	FLHX, FLHXS, FLTRX, FLTRXS

3	11543	GROMMET	FLHX, FLHXS, FLTRX, FLTRXS
4	76259-86	NUT (2)	FLHX, FLHXS, FLTRX, FLTRXS
5	76335-87	ANTENNA BASE ASSEMBLY, with 7129 and 76259-86	FLHX, FLHXS, FLTRX, FLTRXS
6	76503-08	ANTENNA MAST, AM/FM/WB/LW	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
7	69200210	CABLE EXTENSION, AM/FM antenna	FLHTCU, FLHTK, FLHTKL, FLTRU
8	69200211	CABLE EXTENSION, CB antenna	FLHTCU, FLHTK, FLHTKL, FLTRU
9	69200295	CABLE EXTENSION, AM/FM antenna	FLHX, FLHXS, FLTRX, FLTRXS
10	69200313	CLIP, harness (3)	FLHX, FLHXS, FLTRX, FLTRXS
11	76000183	BRACKET, antenna mounting	FLHX, FLHXS, FLTRX, FLTRXS


INTERCOM CONTROL POD



Index No.	Part No.	Description	Model(s)
1	15341-08	HOUSING, pod	FLHTCU, FLHTK, FLHTKL, FLTRU
2	72168-07	TERMINAL, socket, 18-20 AWG (6)	FLHTCU, FLHTK, FLHTKL, FLTRU
3	72414-07BK	HOUSING, six-way socket (black)	FLHTCU, FLHTK, FLHTKL, FLTRU

4	14100083	INSERT, console pod	FLHTCU, FLTRU
5	14100085	INSERT, console pod	FLHTK, FLHTKL
6	69200127	HARNESS, console audio, DIN, with 72168-07 and 72414-07BK	FLHTCU, FLHTK, FLHTKL, FLTRU
7	76266-98A	CAP ASSEMBLY, weather	FLHTCU, FLHTK, FLHTKL, FLTRU

TOUR-PAK (BOTTOM)




Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	2724	SCREW (2)	FLHTCU, FLHTK, FLHTKL,

			FLTRU
2	2968	SCREW (4)	FLHTCU, FLHTK, FLHTKL, FLTRU
3	3767B	BOLT (Asia-Pacific) (4)	FLHTK, FLHTKL, FLTRU
4	3910	SCREW (6)	FLHTCU, FLHTK, FLHTKL, FLTRU
5	6703	WASHER (6)	FLHTCU, FLHTK, FLHTKL, FLTRU
6	6703	WASHER (Asia-Pacific) (4)	FLHTK, FLHTKL, FLTRU
7	7586	JAMNUT	FLHTCU, FLHTK, FLHTKL, FLTRU
8	7716	LOCKNUT (4)	FLHTCU, FLHTK, FLHTKL, FLTRU
9	53598-88A	LINER, removable	FLHTCU, FLTRU
	92038-10	LINER, removable	FLHTK, FLHTKL
10	53734-06	TRIM, left-bottom, Tour-Pak (chrome) (HDI, Japan, Asia-Pacific)	FLHTK, FLHTKL, FLTRU
	53735-06	TRIM, right-bottom, Tour-Pak (chrome) (HDI, Japan, Asia-Pacific)	FLHTK, FLHTKL, FLTRU
11	53788-06	LIGHT, right-bottom, Tour-Pak, sidemarker, with 73152-96BK and 73191-96 (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
	53789-06	LIGHT, left-bottom, Tour-Pak, sidemarker, with 73152-96BK and 73191-96 (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU
12	57978-00	GROMMET (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
13	61081-92	COVER, key-head (set of 2)	FLHTCU, FLHTK, FLHTKL, FLTRU
14	73152-96BK	HOUSING, two-way socket (Domestic) (black) (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
15	73191-96	TERMINAL, socket, 16-20 AWG (Domestic) (4)	FLHTCU, FLHTK, FLHTKL, FLTRU
16	90844-80	ACORN NUT (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
17	99461-89	COVER, owner manual (Domestic, California, Canada, Australia)	FLHTCU, FLHTK, FLHTKL, FLTRU
18	10200061	SCREW (12)	FLHTCU, FLHTK, FLHTKL, FLTRU
19	10200062	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
20	53000091	PLATE, Tour-Pak reinforcing	FLHTCU, FLHTK, FLHTKL, FLTRU
21	53000123	LINER, molded, with pouch	FLHTCU
	53000124	LINER, molded, with pouch	FLHTK, FLHTKL, FLTRU
22	53000132	GROMMET	FLHTCU, FLHTK, FLHTKL, FLTRU
23	53000138	HASP ASSEMBLY, bottom	FLHTCU, FLHTK, FLHTKL, FLTRU
24	53000139	HINGE ASSEMBLY, rear	FLHTCU, FLHTK, FLHTKL, FLTRU
25	53000140	HINGE ASSEMBLY, front	FLHTCU, FLHTK, FLHTKL, FLTRU
26	53000308	COVER, TOUR-PAK wiring	FLHTCU, FLHTK, FLHTKL,

			FLTRU
27	53000311	ADAPTER PLATE, TOUR-PAK (Asia-Pacific)	FLHTK, FLHTKL, FLTRU
28	53000346	BOTTOM, Tour-Pak (unpainted)	FLHTCU, FLHTK, FLHTKL, FLTRU
29	76000172	MOUNTING BRACKET, speaker (left)	FLHTCU, FLHTK, FLHTKL, FLTRU
30	76000173	MOUNTING BRACKET, speaker (right)	FLHTCU, FLHTK, FLHTKL, FLTRU
31	76000174	GASKET, speaker pod (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
32	90300030	LOCK, with 7586 (specify key number)	FLHTCU, FLHTK, FLHTKL, FLTRU
33	90300043	KEY, with 61081-92 (set of 2) (specify key number)	FLHTCU, FLHTK, FLHTKL, FLTRU


TOUR-PAK (COVER)



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	923	SCREW (4)	FLHTK, FLHTKL, FLTRU

2	6703	WASHER (4)	FLHTK, FLHTKL, FLTRU
3	53665-87	LUGGAGE RACK, Tour-Pak, with hardware, with 6703 and 90869-85A (chrome)	FLHTK, FLHTKL, FLTRU
4	90821-74C	LABEL, TOUR-PAK, load limit	FLHTCU, FLHTK, FLHTKL, FLTRU
5	90869-85A	MOUNTING PAD AND WASHER SET, luggage rack	FLHTK, FLHTKL, FLTRU
6	10200061	SCREW (4)	FLHTCU, FLHTK, FLHTKL, FLTRU
7	10200062	SCREW (8)	FLHTCU, FLHTK, FLHTKL, FLTRU
8	10200154	SCREW (5)	FLHTCU, FLHTK, FLHTKL, FLTRU
9	53000090	GASKET, cover	FLHTCU, FLHTK, FLHTKL, FLTRU
10	53000137	HASP, Tour-Pak lid	FLHTCU, FLHTK, FLHTKL, FLTRU
11	53000139	HINGE ASSEMBLY, rear	FLHTCU, FLHTK, FLHTKL, FLTRU
12	53000140	HINGE ASSEMBLY, front	FLHTCU, FLHTK, FLHTKL, FLTRU
13	53000141	TETHER, retractable	FLHTCU, FLHTK, FLHTKL, FLTRU
14	53000347	COVER, Tour-Pak (unpainted)	FLHTCU
	53000370	COVER, Tour-Pak (unpainted)	FLHTK, FLHTKL, FLTRU


LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)



Index No.	Part No.	Description	Model(s)
1	3612	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
2	5210	WELL NUT (8)	FLHTCU, FLHTK, FLHTKL, FLTRU
3	5211	CRIMP NUT (6)	FLHTCU, FLHTK, FLHTKL, FLTRU

4	6113	WASHER	FLHTCU, FLHTK, FLHTKL, FLTRU
5	6220W	WASHER	FLHTCU, FLHTK, FLHTKL, FLTRU
6	7492	NUT, with lockwasher	FLHTCU, FLHTK, FLHTKL, FLTRU
7	10006	CABLE STRAP	FLHTCU, FLHTK, FLHTKL, FLTRU
8	10065	CABLE STRAP (3)	FLHTCU, FLHTK, FLHTKL, FLTRU
9	72166-07BK	HOUSING, 16-way socket (black)	FLHTCU, FLHTK, FLHTKL, FLTRU
10	72168-07	TERMINAL, socket, 18-20 AWG (13)	FLHTCU, FLHTK, FLHTKL, FLTRU
11	72169-07	TERMINAL, pin, 16-20 AWG (6)	FLHTCU, FLHTK, FLHTKL, FLTRU
12	72188-07BK	HOUSING, six-way pin (black)	FLHTCU, FLHTK, FLHTKL, FLTRU
13	72213-94	TERMINAL, socket, 16-20 AWG (5)	FLHTCU, FLHTK, FLHTKL, FLTRU
14	72290-94	TERMINAL, insulated	FLHTCU, FLHTK, FLHTKL, FLTRU
15	72473-07	SEAL PIN, natural (3)	FLHTCU, FLHTK, FLHTKL, FLTRU
16	72610-08	WIRE SEAL, 18-20 AWG (white) (5)	FLHTCU, FLHTK, FLHTKL, FLTRU
17	73102-96BK	HOUSING, two-way pin (black) (2)	FLHTCU
17	73102-96BK	HOUSING, two-way pin (black) (3)	FLHTK, FLHTKL, FLTRU
18	73152-96WE	SOCKET HOUSING, two-way (white)	FLHTCU, FLHTK, FLHTKL, FLTRU
19	73190-96	TERMINAL, pin, 16-20 AWG (4)	FLHTCU
19	73190-96	TERMINAL, pin, 16-20 AWG (6)	FLHTK, FLHTKL, FLTRU
20	73191-96	TERMINAL, socket, 16-20 AWG (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
21	73213-07	RETAINER, anchored	FLHTCU, FLHTK, FLHTKL, FLTRU
22	76353-00	NUT	FLHTCU, FLHTK, FLHTKL, FLTRU
23	10200105	SCREW (8)	FLHTCU, FLHTK, FLHTKL, FLTRU
24	10200133	SCREW (8)	FLHTCU, FLHTK, FLHTKL, FLTRU
25	12100017	GROMMET, speaker (right)	FLHTCU, FLHTK, FLHTKL, FLTRU
26	12100018	GROMMET, speaker (left)	FLHTCU, FLHTK, FLHTKL, FLTRU
27	12100023	PLUG	FLHTCU, FLHTK, FLHTKL, FLTRU

LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)




Index No.	Part No.	Description	Model(s)
28	67800093	LAMP, Tour-Pak, with 76000164, 76000165, 76000186 and 76000208 (Domestic)	FLHTCU, FLHTK,

			FLHTKL, FLTRU
	67800101	LAMP, Tour-Pak, with 76000164, 76000165, 76000186 and 76000208 (HDI)	FLHTK, FLHTKL, FLTRU
29	69200131	WIRING HARNESS, Tour-Pak, with 10065, 72169-07, 72188-07BK, 72213-94, 72610-08, 73102-96BK, 73152-96WE, 73190-96, 73191-96, 69200210, 69200211, 69200225 and 69200226	FLHTCU, FLHTK, FLHTKL, FLTRU
30	69200135	WIRING HARNESS, AM/FM ground jumper, with 72290-94	FLHTCU, FLHTK, FLHTKL, FLTRU
31	69200138	WIRING HARNESS, speaker, with 10065 and 72168-07 (left)	FLHTCU, FLHTK, FLHTKL, FLTRU
32	69200139	WIRING HARNESS, speaker, with 10065, 72168-07 and 71400005 (right)	FLHTCU, FLHTK, FLHTKL, FLTRU
33	69200210	CABLE EXTENSION, AM/FM antenna	FLHTCU, FLHTK, FLHTKL, FLTRU
34	69200211	CABLE EXTENSION, CB antenna	FLHTCU, FLHTK, FLHTKL, FLTRU
35	69200225	HOUSING, five-way socket (black)	FLHTCU, FLHTK, FLHTKL, FLTRU
36	69200226	SECONDARY LOCK, five-way (black)	FLHTCU, FLHTK, FLHTKL, FLTRU
37	69200237	WEATHER CAP ASSEMBLY	FLHTCU, FLHTK, FLHTKL, FLTRU
38	69200826	KIT, AUXILIARY POWER OUTLET, Tour-Pak, with 73102-96BK and 73190-96	FLHTK, FLHTKL, FLTRU
39	71400005	SWITCH ASSEMBLY, rear speaker, with 71400006 and 71400007	FLHTCU, FLHTK, FLHTKL, FLTRU
40	71400006	KNOB, push to talk (ptt) vol-/vol+ rear control switch	FLHTCU, FLHTK, FLHTKL, FLTRU
41	71400007	KNOB, mode select up/down rear control switch	FLHTCU, FLHTK, FLHTKL, FLTRU
42	76000092	GRILLE, rear speaker (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
43	76000096	SPEAKER, 5.25 inch (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
44	76000160	SPEAKER BOX ENCLOSURE, right rear	FLHTCU, FLHTK, FLHTKL, FLTRU
45	76000161	SPEAKER BOX ENCLOSURE, left rear	FLHTCU, FLHTK, FLHTKL, FLTRU
46	76000164	STUD, antenna	FLHTCU,

			FLHTK, FLHTKL, FLTRU
47	76000165	SET SCREW, antenna, M5 X 43mm	FLHTCU, FLHTK, FLHTKL, FLTRU
48	76000177	BEZEL, speaker switch	FLHTCU, FLHTK, FLHTKL, FLTRU
49	76000186	STUD, antenna	FLHTCU, FLHTK, FLHTKL, FLTRU
50	76000208	PLUG ASSEMBLY, antenna	FLHTCU, FLHTK, FLHTKL, FLTRU


SADDLEBAGS (1 OF 2)



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
1	3656	SCREW (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS,

			FLTRU, FLTRX, FLTRXS
2	7586	JAMNUT (2)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
3	69490-07	REFLECTOR (red) (Canada) (2)	FLHX, FLHXS, FLTRX, FLTRXS
4	10200062	SCREW (6)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
5	10200063	SCREW (12)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
6	10200064	SCREW (2)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
7	10200065	SCREW (8)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
8	10200103	SCREW (16)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
9	10200533	SCREW, single sided lever (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
10	10400034	NUT, clip (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
11	67900065	REFLECTOR (left) (red) (Domestic)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	67900066	REFLECTOR (left) (amber) (HDI)	FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
	67900067	REFLECTOR (right) (red) (Domestic)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	67900068	REFLECTOR (right) (amber) (HDI)	FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
12	67900256	REFLECTOR ASSEMBLY, with 69490-07 (red) (Canada) (2)	FLHX, FLHXS, FLTRX, FLTRXS
13	71400010A	LOCKSET, complete, with keys, ignition knob, fork lock and saddlebag locks	FLHR
	71400015A	LOCKSET, complete, with keys, ignition knob, saddlebag and Tour-Pak locks	FLHTCU, FLHTK, FLHTKL, FLTRU
	71400016A	LOCKSET, complete, with keys, ignition knob and saddlebag lock	FLHX, FLHXS, FLTRX, FLTRXS
14	90200411	SADDLEBAG COVER (right) (unpainted)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	90200413	SADDLEBAG COVER (left) (unpainted)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
15	90200412	SADDLEBAG BOTTOM (right) (unpainted)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	90200414	SADDLEBAG BOTTOM (left) (unpainted)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
16	90200415	GASKET, cover (2)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
17	90200467	CUSHION, saddlebag support (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
18	90200488	LINER (2)	FLHTCU, FLTRU
	90200489	LINER (2)	FLHTK, FLHTKL
19	90200519	STRIKE, saddlebag (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
20	90200520	LATCH ASSEMBLY (right)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	90200521	LATCH ASSEMBLY (left)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS


SADDLEBAGS (2 OF 2)



Index No.	Part No.	Description	Model(s)
NOTE: Refer to the Service Section of h-dnet.com for painted part numbers.			
21	90200522	TETHER, saddlebag (2)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS,

			FLTRU, FLTRX, FLTRXS
22	90200611	ISOLATOR, saddlebag (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
23	90200899	HINGE ASSEMBLY (right)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	90200900	HINGE ASSEMBLY (left)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
24	90200901	SEAL (2)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
25	90200902	HANDLE KIT, saddlebag, with 10200064 and grommet (right)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	90200903	HANDLE KIT, saddlebag, with 10200064 and grommet (left)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
26	90201295	FACEPLATE (left) (chrome)	FLHR, FLHTCU, FLHTK, FLHTKL, FLTRU
	90200983BYM	FACEPLATE (left) (black denim)	FLHX, FLHXS, FLTRXS
	90200983DH	FACEPLATE (left) (vivid black)	FLHX, FLHXS, FLTRX, FLTRXS
	90200983DWC	FACEPLATE (left) (superior blue)	FLHX, FLHXS, FLTRX, FLTRXS
	90200983DZN	FACEPLATE (left) (charcoal denim)	FLHXS
	90200983DZP	FACEPLATE (left) (billet silver)	FLTRX
	90200983DZS	FACEPLATE (left) (crushed ice pearl)	FLHXS
	90200983DZT	FACEPLATE (left) (velocity red sunglo)	FLHX, FLHXS, FLTRX, FLTRXS
	90200983DZW	FACEPLATE (left) (olive gold)	FLTRXS
	90201296	FACEPLATE (right) (chrome)	FLHR, FLHTCU, FLHTK, FLHTKL, FLTRU
	90200984BYM	FACEPLATE (right) (black denim)	FLHX, FLHXS, FLTRXS
	90200984DH	FACEPLATE (right) (vivid black)	FLHX, FLHXS, FLTRX, FLTRXS
	90200984DWC	FACEPLATE (right) (superior blue)	FLHX, FLHXS, FLTRX, FLTRXS
	90200984DZN	FACEPLATE (right) (charcoal denim)	FLHXS
	90200984DZP	FACEPLATE (right) (billet silver)	FLTRX
	90200984DZS	FACEPLATE (right) (crushed ice pearl)	FLHXS
	90200984DZT	FACEPLATE (right) (velocity red sunglo)	FLHX, FLHXS, FLTRX, FLTRXS
	90200984DZW	FACEPLATE (right) (olive gold)	FLTRXS
27	90201540	KIT, SADDLEBAG MOUNT, with 10200533 and 10400034 (set of 4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
28	90300024	LOCK, with 7586 (specify key number) (2)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
29	90300043	KEY, with 61081-92 (set of 2) (specify key number)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS


SADDLEBAGS - FLHRC



Index No.	Part No.	Description	Model(s)
1	8126A	PUSH NUT, eight prong (4)	FLHRC
2	90382-98	SPRING KIT, hinge, with two springs (2)	FLHRC

3	90425-98	BUCKLE (4)	FLHRC
4	90439-10	SADDLEBAG STRAP REPAIR KIT (left)	FLHRC
	90482-10	SADDLEBAG STRAP REPAIR KIT (right)	FLHRC
5	90820-93D	LABEL, saddle bag load limits	FLHRC
6	10900026	BAIL HEAD STUD (4)	FLHRC
7	14100254	MEDALLION, saddlebag lid (2)	FLHRC
8	90200684	SADDLEBAG, with 8126A, 90382-98, 90425-98, 90820-93D, 14100254 and 90200905 (right)	FLHRC
	90200685	SADDLEBAG, with 8126A, 90382-98, 90425-98, 90820-93D, 14100254 and 90200905 (left)	FLHRC
9	90200905	ISOLATOR, saddlebag (4)	FLHRC


GUARDS, SADDLEBAG



Index No.	Part No.	Description	Model(s)
1	10200217	SCREW (2)	ALL
2	3601	SCREW (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU

3	3684	SCREW (2)	FLHTCU, FLHTK, FLHTKL, FLTRU
3	3684	SCREW (6)	FLHR, FLHRC, FLHX, FLHXS, FLTRX, FLTRXS
4	4924	SCREW (2)	FLHX, FLHXS, FLTRX, FLTRXS
4	4924	SCREW (4)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
5	7531	LOCKNUT (2)	ALL
6	7601	LOCKNUT (4)	ALL
7	7686	LOCKNUT (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
8	60254-07	REFLECTOR (amber) (2)	FLHRC
9	10400034	NUT, clip (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
10	10900009A	RECEPTACLE (4)	FLHRC
11	11100068	CUSHION (2)	ALL
12	67900120	BRACKET, reflector (2)	FLHRC
13	90200499	SUPPORT, saddlebag, with 11100068 (right) (chrome)	ALL
	90200501	SUPPORT, saddlebag, with 11100068 (left) (chrome)	ALL
14	90200504	SUPPORT, saddlebag (right) (black)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
	90200505	SUPPORT, saddlebag (left) (black)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
15	90200506	GUARD (left) (chrome)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
	90200507	GUARD (right) (chrome)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
16	90200543	SCREW (2)	ALL
17	90200547	INSERT ASSEMBLY, saddlebag support (2)	FLHR, FLHRC, FLHX, FLHXS, FLTRX, FLTRXS
18	90200549	SUPPORT (left) (black)	FLHX, FLHXS, FLTRX, FLTRXS
	90200550	SUPPORT (right) (black)	FLHX, FLHXS, FLTRX, FLTRXS

LABELS




Index No.	Part No.	Description	Model(s)
1	13729-16	YEAR OF MANUFACTURING LABEL (Brazil)	FLHRC, FLHTK, FLHXS
2	13729-17	YEAR OF MANUFACTURING LABEL (Brazil)	FLHRC, FLHTK, FLHXS

3	14148-86	ENGINE GUARD LABEL	ALL
4	14272-06	SHIFT PATTERN LABEL (Japan)	FLHR, FLHTK, FLHTKL, FLTRU, FLTRXS
5	15342-06A	MIRROR WARNING LABEL	FLHX, FLHXS
6	15368-01A	LABEL BATTERY WARNING	ALL
	14263-04	LABEL BATTERY, WARNING, Portuguese (Brazil) (not shown)	FLHRC, FLHTK, FLHXS
7	15370-01A	MIRROR WARNING LABEL	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU
	15385-08	MIRROR WARNING LABEL, Portuguese (Brazil) (not shown)	FLHRC, FLHTK, FLHXS
8	29108-08	WARNING LABEL, air cleaner, (chrome) (Except Canada)	ALL
9	90820-93D	LABEL, saddlebag load limits	ALL
10	90821-74C	LABEL, TOUR-PAK, load limit	FLHTCU, FLHTK, FLHTKL, FLTRU
11	14000827	CLEAR OVERLAY, VIN label (Japan)	FLHR, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS

NOTE: When ordering any V.I.N., Emissions, or Noise Labels you must contact your local dealer with the V.I.N. number and model year of your motorcycle and the label type needed. Replacement V.I.N. and Emissions labels can only be ordered for warranty purposes through h-dnet Service eForm.

LOOSE PARTS (1 OF 3)




Index No.	Part No.	Description	Model(s)
1	99466-17	OWNER'S MANUAL (Domestic, Australia, England)	ALL
	69200336	MAIN FUSE, 50 A (red)	ALL

	90300043	KEY (set of 2) (specify key number)	ALL
	90300111	REMOTE CONTROL FOB (except Japan) (2)	ALL
	90300112	REMOTE CONTROL FOB (Japan) (2)	ALL
	94000084	ABS DVD (ABS models)	ALL
	94000326	OWNER'S KIT CONTENT (Domestic)	ALL
1	53598-88A	LINER, Tour-Pak, removable	FLHTCU
	58002-09A	AIR DEFLECTOR KIT, MID-FRAME (See NOTE)	FLHTCU, FLHTK, FLHTKL
	62241-08	INSERT, PEACE OFFICER (2) **RESTRICTED SALES PART**	FLHTK, FLHTKL
	62242-08	INSERT, FIREFIGHTER (2) **RESTRICTED SALES PART**	FLHTK, FLHTKL
	62243-08	INSERT, SPECIAL EDITION (2) **RESTRICTED SALES PART**	FLHTK, FLHTKL
	76503-08	ANTENNA MAST, AM/FM/WB/LW	FLHTCU, FLHTK, FLHTKL
	77117-10	HEADSET ASSEMBLY (Domestic, California, Canada)	FLHTCU, FLHTK, FLHTKL
	77117-10	HEADSET ASSEMBLY (HDI, Australia, Japan, Asia-Pacific, Brazil, England) (2)	FLHTK, FLHTKL
	92038-10	LINER, Tour-Pak, removable	FLHTK, FLHTKL
	99461-89	COVER, owner manual (Domestic, California, Canada, Australia)	FLHTCU, FLHTK, FLHTKL
	99517-17EN	BOOM! OWNER'S MANUAL KIT, English (Domestic, Australia, England)	FLHTCU, FLHTK, FLHTKL
	52300053	BACKREST ASSEMBLY, passenger (black)	FLHTCU, FLHTK, FLHTKL
	57400001	WINDSHIELD (clear) (Domestic)	FLHTCU, FLHTK
	57400001	WINDSHIELD (clear) (Brazil, Australia)	FLHTK
	57400002	WINDSHIELD (clear) (HDI, England, Japan)	FLHTK
	57400058	WIND DEFLECTOR (clear) (Asia-Pacific)	FLHTK, FLHTKL
	57400250	WINDSHIELD (clear) (Domestic, HDI, Australia, England, Japan)	FLHTKL
	90200488	LINER, saddlebag, removable (2)	FLHTCU
	90200489	LINER, saddlebag, removable (2)	FLHTK, FLHTKL
	3767B	BOLT (4)	FLHTK
	6703	WASHER (4)	FLHTK
	53000311	ADAPTER PLATE, Tour-Pak	FLHTK
	2731W	SCREW (2)	FLHTCU, FLHTK, FLHTKL
	59292-94	NUT, plastic (2)	FLHTCU, FLHTK, FLHTKL

ALLTOURINGNOTE 1: Left side cover is shipped loose. Refer to the Service Section of h-dnet.com for painted part numbers.FLHTCU,FLHTK,FLHTKLTOUR-PAK ADAPTER KIT (Asia-Pacific)LICENSE PLATE MOUNTING KIT
HARDWARENOTE: Order 58002-09A only if missing complete kit. Otherwise order individual components as needed. Refer to the COVERS AND AIR DEFLECTORS section in this parts manual.

LOOSE PARTS (2 OF 3)




Index No.	Part No.	Description	Model(s)
1	76503-08	ANTENNA MAST, AM/FM/WB/LW	FLTRX, FLTRXS
	99517-17EN	BOOM! OWNER'S MANUAL KIT, English (Domestic, Australia, England)	FLTRX, FLTRXS
	57400302	WINDSHIELD (Domestic, Australia)	FLTRX, FLTRXS

	57400303	WINDSHIELD (HDI, England, Japan, Asia-Pacific)	FLTRXS
	933	SCREW (4)	FLTRX, FLTRXS
	6054	WASHER (4)	FLTRX, FLTRXS
1	53598-88A	LINER, Tour-Pak, removable	FLTRU
	58002-09A	AIR DEFLECTOR KIT, MID-FRAME (See NOTE)	FLTRU
	76503-08	ANTENNA MAST, AM/FM/WB/LW	FLTRU
	77117-10	HEADSET ASSEMBLY (Domestic, California, Canada)	FLTRU
	77117-10	HEADSET ASSEMBLY (HDI, Japan, Asia-Pacific, England) (2)	FLTRU
	99461-89	COVER, owner manual (Domestic, California, Canada)	FLTRU
	99517-17EN	BOOM! OWNER'S MANUAL KIT, English (Domestic, California, Canada, England)	FLTRU
	52300053	BACKREST ASSEMBLY, passenger (black)	FLTRU
	57200065	WIND DEFLECTOR (right)	FLTRU
	57200066	WIND DEFLECTOR (left)	FLTRU
	57400260	WINDSHIELD (clear) (Asia-Pacific)	FLTRU
	57400262	WINDSHIELD (clear) (HDI, England, Japan)	FLTRU
	57400305	WINDSHIELD (clear) (Domestic)	FLTRU
	90200488	LINER, saddlebag, removable (2)	FLTRU
	3767B	BOLT (4)	FLTRU
	6703	WASHER (4)	FLTRU
	53000311	ADAPTER PLATE, Tour-Pak	FLTRU
	2731W	SCREW (2)	FLTRU
	59292-94	NUT, plastic (2)	FLTRU
	10200400	SCREW (4)	FLTRU
	57400308	TRIM, right (black)	FLTRU
	57400309	TRIM, left (black)	FLTRU

FLTRX,FLTRXS WINDSHIELD HARDWARE FLTRU TOUR-PAK ADAPTER KIT (Asia-Pacific) LICENSE PLATE MOUNTING KIT
HARDWARE WINDSHIELD TRIM KIT
NOTE: Order 58002-09A only if missing complete kit. Otherwise order individual components as needed. Refer to the COVERS AND AIR DEFLECTORS section in this parts manual.

LOOSE PARTS (3 OF 3)



Index No.	Part No.	Description	Model(s)
1	57668-10	WINDSHIELD ASSEMBLY, complete, low (clear) (Asia-Pacific)	FLHRC
	57994-94	WINDSHIELD ASSEMBLY, complete (FLHR - Domestic, Canada, California, Australia)	FLHR,

		(FLHRC - Brazil)	FLHRC
	58002-09A	AIR DEFLECTOR KIT, MID-FRAME (Brazil) (See NOTE)	FLHRC
	58325-06	WINDSHIELD ASSEMBLY, complete (HDI, England, Japan)	FLHR, FLHRC
	61400159	INSERT, handlebar cover	FLHR, FLHRC
1	58002-09A	AIR DEFLECTOR KIT, MID-FRAME (Brazil) (See NOTE)	FLHXS
	76503-08	ANTENNA MAST, AM/FM/WB/LW	FLHX, FLHXS
	99517-17EN	BOOM! OWNER'S MANUAL KIT, English (Domestic, Australia, England)	FLHX, FLHXS
	57400003	WIND DEFLECTOR (smoked) (Domestic)	FLHX, FLHXS
	57400003	WIND DEFLECTOR (smoked) (Brazil, Australia)	FLHXS
	57400004	WIND DEFLECTOR (smoked) (HDI, England, Japan)	FLHXS
	57400058	WIND DEFLECTOR (clear) (Asia-Pacific)	FLHXS

FLHR,FLHRCNOTE: Order 58002-09A only if missing complete kit. Otherwise order individual components as needed. Refer to the COVERS AND AIR DEFLECTORS section in this parts manual.FLHX,FLHXSNOTE: Order 58002-09A only if missing complete kit. Otherwise order individual components as needed. Refer to the COVERS AND AIR DEFLECTORS section in this parts manual.

Hardware List

Part No.	Description
10100062	LOCKNUT 7/16-20 flange (Grade F) (zinc)
10200042	SCREW No. 10-24 X 1-5/8 hex flange hd. full thread (Grade 5) (zinc)
10200052	SCREW 1/4-20 X 39/64 TORX SEMS socket button hd. , w/ lockpatch
10200059	SCREW 1/4-20 X 1-11/16 TORX socket button hd. matpoint (Grade 5) (black)
10200060	SCREW 1/4-20 X 2-5/8 TORX socket button hd. matpoint (Grade 5) (black)
10200061	SCREW No. 8-32 X 1/2 TORX SEMS pan hd. (zinc)
10200062	SCREW No. 8-32 X 3/8 TORX pan hd. (zinc)
10200063	SCREW No. 8 X 1/2 TORX SEMS pan hd. (stainless)
10200064	SCREW No. 8-32 X 1 TORX pan hd. (zinc)
10200065	SCREW No. 8-32 X 5/8 TORX SEMS pan hd., w/ lockpatch (stainless)
10200103	SCREW No. 8-32 X 1/2 TORX SEMS pan hd., w/ lockpatch (stainless)
10200105	SCREW No. 6-32 X 3/4 TORX pan hd. (black zinc)
10200112	SCREW 1/4-20 X 2 TORX button hd. SEMS (Grade 5) (black)
10200120	SCREW 1/8 X 18 X 1.00 hex cap
10200133	SCREW No. 8-16 X 9/16 TORX pan hd. (zinc)

10200134	SCREW 1/4-20 X 3/4 hex socket hd. (Grade 8) (zinc)
10200141	SCREW 1/4-20 X 1/2 hex socket button hd. (zinc)
10200142	SCREW 5/16-18 X 3/4 hex flange w/ internal hex SEMS, hardened (zinc)
10200147	SCREW No. 10-24 X 3/4 TORX socket button hd. SEMS (black)
10200154	SCREW No. 8 X 3/4 TORX SEMS pan hd. (stainless)
10200155	SCREW No. 8-16 X 1 TORX pan hd. (zinc)
10200156	SCREW No. 8-32 X 3/8 phillips round hd. (stainless steel)
10200205	SCREW No. 10 X 1/2 pan hd. TORX, hardened (zinc)
10200217	SCREW 5/16-18 X 1-1/4 TORX SEMS, w/ lockpatch (zinc)
10200223	SCREW No. 10-24 UNRC X 3/4 TORX truss hd. (zinc)
10200257	SCREW No. 8-32 X 1/2 TORX pan hd. T-20 (zinc)
10200258	SCREW 1/4-20 X 1-1/4 SEMS hex socket hd. (Grade 8) (zinc)
10200343	SCREW 5/16-18 X 3-1/4 flange (zinc)
10200350	SCREW 1/4-20 X 1-1/8 SEMS hex socket hd. (Grade 8) (zinc)
10200365	SCREW 1/4-20 X 1-1/16 TORX socket hd. SEMS (Grade 8) (zinc)
10200373	SCREW M6 X 1 X 18mm hex hd. (Grade 10.9) (zinc)
10200400	SCREW No. 10-32 X 1 socket button hd. (zinc)
10200408	SCREW 3/8-16 X 2 hex hd., w/ washer (Grade 8) (zinc)
10200414	SCREW 5/16-18 X 5/8 button hd. SEMS TORX T-40, w/ lockpatch (Grade 8) (zinc)
10200422	SCREW 1/4-20 X 5/8 button hd. SEMS TORX T-27, w/ lockpatch (zinc)
10200429	SCREW 3/8-16 X 2-1/2 hex socket hd. w/ scotch grip (Grade 8) (zinc)
10200442	SCREW No. 8-32 X 5/16 tri-lobe thread forming (zinc)
10200446	SCREW 1/4-20 X 1 hex flange, w/adhesive
10200463	SCREW 3/8-16 X 1-3/8 hex hd. w/ lockpatch (Grade 8) (zinc)
10200503	SCREW 5/16-18 X 1-1/4 12 pt. hd (Grade 8)
10200546	SCREW No. 10-24 X 5/8 hex serrated flange, w/scotch grip (zinc-nickel plate and seal)
10200569	SCREW
10500015	SCREW 5/16-18 X 1-7/8 SEMS hex socket hd.
10500017	SCREW No. 10 X 3/8 pan hd., TORX, plastite, hardened (zinc)

10500022	SCREW 5/16-18 X 1-1/2 SEMS hex socket hd. (Grade 8) (zinc)
10500036	SCREW 3/8-16 X 2 SEMS socket hd. (Grade 8.8) (black)
10500053	SCREW 1/4-20 X 3/8 TORX button hd., w/ lockpatch (zinc)
1062	SCREW 1/4-20 X 5/8 TORX hd. (Grade 8)
12600031	SCREW 5/16-18 X 1 hex socket hd. cap (Grade 8) (black)
12600032	SCREW 1/2-13 X 2 hex hd. cap lock patch(Grade 5)
12600049	SCREW No. 10-24 X 3/4 pan hd. torx, w/ lockpatch (Grade 8) (zinc)
1332	SCREW No. 5/16 X 2-1/4 socket button hd. w/lock patch (Grade 8)
1775	SCREW 1/4-20 X 4 hex socket hd. (Grade 8)
2445	SCREW 1/4-20 X 9/16 button hd.
2446	SCREW 1/4-20 X 5/8 TORX socket button hd.
2452	SCREW No. 12-24 X 13/16 pan hd., w/lockpatch
2478	SCREW No. 10-24 X 1/2 TORX button hd.
2479	SCREW 5/16-18 X 1-1/8 SEMS socket hd.
2482	SCREW 6-32 X 5/16 socket button hd. (stainless)
2531	SCREW No. 4-40 X 5/16 Pozidriv pan hd. (Grade 2)
2563	SCREW No. 10-24 X 5/8 TORX button hd.
2647B	SCREW No. 10-24 X 3/4 socket hd., self-locking
2692WB	SCREW No. 10-24 X 1/2 socket fillister hd. (Grade 8)
2708A	SCREW 5/16-18 X 1 socket hd.
2724	SCREW No. 10-16 X 1/2 (Grade 2) (chrome)
2731W	SCREW No. 10 X 3/8 Phillips truss hd., self-tapping
2921	SCREW No. 12 X 5/8 TORX pan hd.
29269-83A	SCREW 15/16-18 X 5/8 hex button hd., w/lockpatch
2933	SCREW No. 10-24 X 1/2 flat hd.
2952A	SCREW 1/4-20 X 1/2 SEMS truss hd.
2968	SCREW No. 8-32 X 3/4 TORX pan hd.
2995	SCREW No. 10-16 X 3/4 pan hd.
3022A	SCREW 1/4-20 X 5/8 socket fillister hd., w/lockpatch
3050	SCREW No. 10-24 X 1-3/8 TORX hd.

3057	SCREW 7/16-14 X 1-1/4 hex head w/washer, w/lock patch
3061	SCREW 1/4-20 X 5/8 SEMS hex hd.
3088	SCREW 1/4-20 X 1-1/2 socket button hd. (chrome)
3143	SCREW 3/8-16 X 1 hex socket hd., w/lock patch
3152	SCREW #10 X 1/2 TORX pan hd
3225	BOLT No. 6 X 5/8 long phillips pan hd. (zinc)
3249	SCREW 5/16-18 X 1-3/16 socket hd. (Grade 8)
3275	SCREW 5/16-18 X 3/4 socket hd. (Grade 8)
3514	SCREW No. 8-32 X 1 fillister hd. (Grade 5)
35241-06	NUT 1-3/4-20 X .350 X 2-1/4 hex hd.
35244-06	SCREW 5/16-18 X 1-1/4 hex flange hd.
35259-06	SCREW No. 10-24 X 1/2 hex hd. (Grade 8)
3536	BOLT 3/8-16 X 1-1/4 hex hd. (Grade 8)
3560WA	BOLT No. 10-24 X 3/8
3561WC	BOLT No. 10-24 X 3/8
3563	SCREW 1/4-20 X 3/8 hex flange hd. (Grade 5)
3576	SCREW 5/16-18 X 1/2 hex hd., w/washer.
3588	SCREW 1/4-20 X 1/2 hex flange hd.
3594	SCREW 1/4-20 X 5/8 knurled hd. (Grade 8)
3601	SCREW 1/4-20 X 1-1/4 knurled hd. (Grade 8)
3607	BOLT 1/2-13 X 2 hex hd. (Grade 5)
3612	SCREW No. 10-16 X 1/2 TORX pan hd., self-tapping
3622	SCREW No. 10-16 X 3/8 pan hd., self-tapping
3634	SCREW 5/16-18 X 1.0 self-tapping
3655A	SCREW 5/16-18 X 7/8 TORX pan hd., w/lockpatch (Grade 8)
3656	SCREW No. 8-32 X 3/8 TORX pan hd. (Grade 5)
36706-01K	BOLT M6 X 1.0 X 30 hex flange hd.
3676	SCREW 5/16-18 X 5/8 TORX pan hd.
3684	SCREW 5/16-18 X 1 TORX pan hd.

3699D	SCREW 3/8-16 X 2.0 hex flange hd. (Grade 8)
3767B	BOLT 1/4-20 X 5/8 hex hd. (Grade 5)
3787	BOLT 1/4-20 X 3/4 hex hd. (Grade 5)
3892	SCREW 1/4 X 5/8 self-tapping
3901	SCREW 1/4-20 X 1.0 hex flange hd. (Grade 5)
3910	SCREW 1/2-20 X 2-1/4 hex hd. full thread (Grade 5) (zinc)
3929	SCREW 5/16-18 X 1/2 hex hd.
3976	SCREW 1/4-20 X 1 hex flange hd. (Grade 5)
3983	SCREW 3/8-16 X 1-5/8 hex flange hd., w/washer (Grade 8)
3987	BOLT 5/16-18 X 3/4 hex hd. (Grade 5)
4132	SCREW 1/4-20 X 1-1/8 TORX button hd. (Grade 5) (black)
4194	SCREW No. 10-24 X 5/16 TORX pan hd. (Grade 5)
4240	SCREW No. 10-24 X 3/16 hex hd., w/washer
4312C	SCREW M6 X 1.0 X 14mm, SEMS flange hd. (stainless)
43567-92	SCREW 3/8-16 X 1 TORX pan hd., w/lockpatch
4419	SCREW 5/16-18 X 1-3/4 SEMS hex hd.
45500118	SCREW M14 X 1.25 X 25 hex socket cap (zinc)
45500132	SCREW M8 X 1.25 X 45 hex socket cap (Grade 8.8)
4597M	SCREW M10 X 1.5 X 30 hex socket hd.
4612	SCREW 10-24 X 3/4 TORX pan hd.
46509-01	WASHER 30 X 43 X 2.3
4688	SCREW 3/8-16 X 1-1/4 SEMS hex socket hd., w/ lock patch
4694	SCREW No. 8-32 X 3/8 TORX pan hd., w/lockpatch
4705	SCREW 1/4-20 X 11/16 SEMS socket hd., w/lockpatch
4706	SCREW 3/8-16 X 4 hex hd.
4718A	SCREW 1/4-20 X 1-1/2 knurled hd., w/lockpatch
4740A	SCREW 1/4-20 X 1-1/4 knurled hd., w/lockpatch (Grade 8)
4741A	SCREW 1/4-20 X 1 socket hd., w/lockpatch
4775	SCREW 3/8-16 X 1-1/4 hex hd. (Grade 5)
4790	SCREW No. 10-16 X 3/4 TORX hd., self-tapping

4813A	SCREW 1/4-20 X 1-3/8 knurled hd., w/lockpatch
4816A	SCREW 5/16-18 X 1-1/2 socket hd.
4820A	SCREW 1/4-20 X 2 socket hd.
4822A	SCREW 1/4-20 X 2-3/4 knurled hd., w/lockpatch
4856	SCREW No. 10-24 X 1/2 socket head (stainless)
4867	SCREW hex hd., socket
4916	SCREW 5/16-18 X 1.0 hex socket head shoulder
4924	SCREW 3/8-16 X 7/8 TORX button hd. (zinc plate) (Grade 5)
54321-85	NUT No. 8-32 X 1/2 X 1/8 (brass)
6019	WASHER 3/8 X 29/32 X 1/16
6026	WASHER 3/8 X 7/8 X 7/64
6036	WASHER 17/64 X 1 X 1/16
6054	WASHER 3/16 X 9/16 X 1/16 nylon (black)
6072	WASHER 3/8 X 1 1/4 X 5/64
6101	WASHER 17/64 X 27/64 X 1/16
6109	WASHER 5/16 X 11/16 X 1/8
6113	WASHER 1/2 X 13/16 X 1/32
6116	WASHER 5/16 X 16/16 X 1/8
6119	WASHER 1/4 X 9/16 X 1/16
6127	WASHER 13/32 X 13/16 X 5/64
6150W	WASHER 3/16 X 3/8 X 1/16
6220W	WASHER 1/4 X 7/16 X 1/32
6235	WASHER 1/4 X 23/32 X 1/16
6294	WASHER 3/8 X 1-1/8 X 7/32
6333	WASHER 5/16 X 7/8 X 5/64
6416	WASHER 3/8 X 1 X 5/64
6421	WASHER 21/64 X 1-1/2 X 1/16 offset 7/32
6497HW	WASHER 29/64 X 1-1/8 X 1/16
6532	WASHER 3/8 X 3/4 X 1/8


6590HW	WASHER 1/2 X 1-1/8 X 3/32
6594	WASHER 5/8 X 1-1/8 X 3/32
6702	WASHER 5/16 X 11/16 X 1/16
6703	WASHER 1/4 X 5/8 X 1/16
6762D	WASHER 11/16 X 29/32 X 1/32
67721-48	SCREW headlamp retainer ring
6789	WASHER No. 6 X 7/8 X .05
68026-99	SCREW No. 8-32 X 1 Phillips pan hd. (stainless)
68042-99	SCREW No. 8-32 X 3/8 TORX hd.
68120-00	SCREW No. 8-32 x 1-2 TORX hd., self-tapping
7036	WASHER 1/4 X 31/64 X 1/16
7038	LOCKWASHER 3/8
703B	SCREW 1/4-20 X 7/16 TORX socket button hd.
7041	LOCKWASHER 5/16
7129	LOCKWASHER 1/2 internal tooth
7130W	LOCKWASHER 3/8 internal tooth
7155	LOCKWASHER 5/16 internal tooth (black)
7330	ACORN NUT 5/16-24 (chrome)
7331	ACORN NUT 5/16-24
7415A	WASHER 11/32 X 7/8 X 1/8 rubber
7434	WASHER 1/4 X 1-29/64 X 1/16 nylon
7495	NUT M6 flange
7499	NUT 1/4-20 large flange
7531	LOCKNUT 5/16-18 X 9/32 X 1/2 flange
7549A	ACORN NUT 5/16-18 X 9/16 X 1/2
7576	NUT 5/16-18 UNC keps flange
7586	JAMNUT 9/32-28 X 1/4
7593	NUT 5/16-24 flange
7600	NUT No. 4-40 keps

7601	LOCKNUT 3/8-16 flange
7606	LOCKNUT No. 8-32 X 1/4 X 1/4 hex (chrome)
7624	LOCKNUT No. 10-24 X 1/4 X 3/8
76259-86	NUT hex jam
7629	NUT No. 10-32 X 3/8 keps
7651A	ACORN NUT No. 12-24 (Grade 2) (chrome)
7667	NUT 3/8-16 X 9/32 X 9/16 nylon insert
7686	LOCKNUT 1/4-20 X 5/16 X 7/16
7687	NUT 3/8-16 X 25/64 (Grade 2)
7716	LOCKNUT 1/4-20 X 7/16 flange
7792	NUT 1/4-20 X 1/4 (Grade 2)
780	SCREW 1/4-20 X 7/8 SEMS hex hd. (Grade 8)
7813A	NUT 5/8-18 X 9/16 X 15/16 (Grade 2)
7825	LOCKNUT 7/16-20 X 7/16 X 5/8
786A	BOLT 5/16-18 X 2-1/4 hex hd. (Grade 5)
7880	NUT 1/2-13 X 7/16 X 3/4 (Grade 2)
7888A	NUT No. 6-32 flange hd.
7889	NUT No. 6-32 keps
7900	CLIP NUT 1/4-20
791A	SCREW 3/8-18 X 2-1/4 hex flange hd. (Grade 5)
7992	ACORN NUT 5/16-18
8020	NUT M24 X 2.0 X 15
8108	SPEEDNUT 1/4-20
84850-92	NUT 3/4-24 X 5/32
856A	SCREW 5/16-24 X 1 socket hd. (Grade 8)
8972	WASHER 1-1/4 X 1-53/64 X 1/8
90200543	SCREW 3/8-16 X 2-1/2 TORX button hd. (zinc)
90844-80	ACORN NUT No. 10 X 3/8 flange (Grade 2)
923	SCREW 1/4-20 X 3/4 socket pan hd.
933	SCREW No. 10-32 X 15/16 Pozidriv truss hd. (Grade 2)

942	SCREW 1/4-20 X 3/4 TORX button hd., w/lockpatch (Grade 8)
946	SCREW 1/4-20 X 2-1/4 socket button hd., w/lockpatch (Grade 8)

[New Parts List](#)


ENGINE ASSEMBLY, AIR-COOLED



Index No.	Part No.	Description	Model(s)
1	16200248	ENGINE ASSEMBLY, complete	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX,

			FLTRXS
2	16200265	ENGINE ASSEMBLY, shortblock, with 91800064, crankcase, flywheel assembly, camshaft support plate assembly, balancer and cylinder studs (See Note)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
3	91800064	KIT, shortblock installation, with 25700729 upper end gasket kit, 25700746 inner primary gasket kit, camshaft sprocket, camshaft drive chain and camshaft tensioner	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS


ENGINE ASSEMBLY, TWIN-COOLED™



Index No.	Part No.	Description	Model(s)
1	16200249	ENGINE ASSEMBLY, complete	FLHTK, FLHTKL,

			FLTRU
2	16200265	ENGINE ASSEMBLY, shortblock, with 91800064, crankcase, flywheel assembly, camshaft support plate assembly, balancer and cylinder studs (See Note)	FLHTK, FLHTKL, FLTRU
3	91800064	KIT, shortblock installation, with 25700729 upper end gasket kit, 25700746 inner primary gasket kit, camshaft sprocket, camshaft drive chain and camshaft tensioner	FLHTK, FLHTKL, FLTRU


CYLINDERS, HEADS AND VALVES



Index No.	Part No.	Description	Model(s)
2	10200303	FLANGE NUT (dull silver) (8)	ALL
3	10900015	STUD, exhaust port (4)	ALL

4	16500326	GASKET, cylinder head (2)	ALL
5	16500332	GASKET, cylinder base (2)	ALL
6	16500388	CYLINDER HEAD, rear, with 65324-83B, 10900015, 18000016, 18000034, 18100043, 18100044, 18100045, 18100060 and 18400073, AIR-COOLED (black)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
	16500498	CYLINDER HEAD, rear, with 65324-83B, 10900015, 18000016, 18000034, 18100043, 18100044, 18100045, 18100060 and 18400073, TWIN-COOLED™ (black)	FLHTK, FLHTKL, FLTRU
	16500393	CYLINDER HEAD, front, with 65324-83B, 10900015, 18000016, 18000034, 18100043, 18100044, 18100045, 18100060 and 18400073, AIR-COOLED (black)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
	16500508	CYLINDER HEAD, front, with 65324-83B, 10900015, 18000016, 18000034, 18100043, 18100044, 18100045, 18100060 and 18400073, TWIN-COOLED™ (black)	FLHTK, FLHTKL, FLTRU
8	16800095	CYLINDER ASSEMBLY, front, with 16589-99A (black)	ALL
	16800100	CYLINDER ASSEMBLY, rear, with 16589-99A (black)	ALL
9	18000016	INTAKE VALVE (4)	ALL
10	18000034	EXHAUST VALVE (4)	ALL
11	18100043	VALVE SPRING (8)	ALL
12	18100044	SEAL, valve (8)	ALL
13	18100045	COLLAR, valve spring (8)	ALL
14	18100060	KEEPER, valve (16)	ALL
15	18400073	SOLENOID, auto compression release (ACR) (2)	ALL
16	25700729	GASKET KIT, top end	ALL
	25700730	GASKET KIT, engine overhaul	ALL


ROCKER ARM ASSEMBLY AND PUSHRODS



Index No.	Part No.	Description	Model(s)
1	3976	SCREW (2)	ALL
3	6762D	WASHER (4)	ALL
14	10200446	SCREW (8)	ALL

15	10200503	SCREW (8)	ALL
17	11900116	O-RING (2)	ALL
18	17300053	ROCKER ARM, rear intake, front exhaust (2)	ALL
19	17300055	ROCKER ARM, front intake, rear exhaust (2)	ALL
20	17300059	SHAFT, rocker arm (4)	ALL
21	17900030	PUSHROD, intake, 10.301 in long (light blue stripes) (2)	ALL
22	17900031	PUSHROD, exhaust, 10.531 in long (yellow stripes) (2)	ALL
23	17900034	ANTI-ROTATION DEVICE, rear cylinder	ALL
	17900035	ANTI-ROTATION DEVICE, front cylinder	ALL
24	25700362	GASKET, lifter cover (2)	ALL
25	25700372	GASKET, rocker arm cover (2)	ALL
26	25700409	ROCKER COVER (chrome) (2)	ALL
27	25700410	LIFTER COVER, front (chrome)	ALL
	25700411	LIFTER COVER, rear (chrome)	ALL
29	25700425	GASKET, rocker housing, lower (2)	ALL
30	25700488	COVER, pushrod (lower) (4)	ALL
31	25700731	GASKET KIT, camshaft service	ALL
32	29400183	BREATHING ASSEMBLY, rear, with 11900116	ALL
	29400210	BREATHING ASSEMBLY, front, with 11900116	ALL


COOLING SYSTEM, ENGINE, TWIN-COOLED™



Index No.	Part No.	Description	Model(s)
1	10200446	SCREW (2)	FLHTK, FLHTKL, FLTRU
3	11900090	O-RING, coolant manifold (4)	FLHTK, FLHTKL, FLTRU
4	26900117	BRACKET, coolant tube (2)	FLHTK, FLHTKL, FLTRU

5	26900133	COOLANT LINE ASSEMBLY, water, with 11900090 and 26900117	FLHTK, FLHTKL, FLTRU


COOLING SYSTEM, ENGINE, AIR-COOLED



Index No.	Part No.	Description	Model(s)
2	10200446	SCREW (4)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS

4	11900090	O-RING, coolant manifold (4)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
5	11900092	O-RING, transmission oil return	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
6	26900117	BRACKET, coolant tube (2)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
7	62700146	FITTING ASSEMBLY, transmission oil return, with 11900092	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
8	62800028	COOLANT LINE ASSEMBLY, oil, with 10800052, 11900090 and 26900117	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS


COOLANT DISTRIBUTION, TWIN-COOLED™



Index No.	Part No.	Description	Model(s)
1	10318	CLIP, wire retention	FLHTK, FLHTKL, FLTRU
4	10200414	SCREW (2)	FLHTK, FLHTKL, FLTRU
5	10200422	SCREW (2)	FLHTK, FLHTKL, FLTRU

7	12700091	BRACKET, voltage regulator	FLHTK, FLHTKL, FLTRU
8	26600048	PUMP, coolant	FLHTK, FLHTKL, FLTRU
9	26800077	COVER, coolant pump	FLHTK, FLHTKL, FLTRU
10	26900088	HOSE, outlet, water pump	FLHTK, FLHTKL, FLTRU


COOLANT DISTRIBUTION, AIR-COOLED



Index No.	Part No.	Description	Model(s)
1	10080	CLAMP	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS

6	10200414	SCREW (2)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
7	10200422	SCREW (4)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
9	12100113	GROMMET	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
10	12600016	CLIP, push-in (2)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
11	12700090	BRACKET, voltage regulator	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
12	26800092	COVER, oil cooler	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
13	62700143	HOSE, inlet, oil cooler	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
14	62700144	HOSE, outlet, oil cooler	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
15	62700196	OIL COOLER, with 12100113	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
16	69201286	COVER, electrical connector, with 12600016	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS


RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™



Index No.	Part No.	Description	Model(s)
34	26900114	HOSE, radiator to engine outlet	FLHTK, FLHTKL,

			FLTRU
35	26900115	HOSE, radiator to pump inlet	FLHTK, FLHTKL, FLTRU
40	69201548	WIRE HARNESS, twin cooling jumper, with 10147, 72063-06, 72111-06, 72168-07, 72177-07BK, 72484-08, 72486-08, 72607-08, 72608-08, 72609-08 and 72610-08 (left)	FLHTK, FLHTKL, FLTRU


PISTONS AND FLYWHEEL ASSEMBLY



Index No.	Part No.	Description	Model(s)
3	21900049	PISTON AND RINGS ASSEMBLY, with 22097-99, 22000060 and 22100006, standard (2)	ALL
4	22000060	PISTON RING SET, standard (2)	ALL
5	22100006	PISTON PIN (2)	ALL

6	24100057	FLYWHEEL ASSEMBLY KIT, with 11177A	ALL
7	35200027	BALANCER ASSEMBLY	ALL


CRANKCASE AND ENGINE OIL FILTER



Index No.	Part No.	Description	Model(s)
12	10200343	SCREW (12)	ALL
13	11000134	SEAL, oil	ALL
15	12400099	SPACER, front mount (2)	ALL

16	24100080	BEARING KIT, with 8972, 24605-07, 35114-02 and inner race	ALL
17	24400120	CRANKCASE SET, with 2, 5, 6, 7, 9, 11, 12, 15, 18, 20, 21 and 22 (black)	ALL
18	25700433	GASKET, piston jet (2)	ALL
19	29900041	SPACER, sprocket shaft	ALL
20	35200021	BEARING, balancer (2)	ALL
21	62700089	PISTON JET ASSEMBLY, front, with 25700433	ALL
22	62700117	PISTON JET ASSEMBLY, rear, with 25700433	ALL


CAMSHAFTS AND CAMSHAFT COVER



Index No.	Part No.	Description	Model(s)
4	4822A	SCREW (4)	ALL
16	11900103	O-RING	ALL

17	25400103	SPROCKET, camshaft drive, 34 teeth	ALL
18	25400133	CAMSHAFT SUPPORT PLATE, with 8873 and 16589-99A	ALL
19	25400190	CAMSHAFT	ALL
20	25400257	CAMSHAFT CHAIN AND FASTENER KIT, with 25566-06, 25673-06, 25675-06 and 25400103	ALL
21	25500013	CHAIN TENSIONER, camshaft drive chain	ALL
22	25600042	COVER, timer cover	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	25600049	COVER, timer cover	FLHTK, FLHTKL
23	25700367	CAMSHAFT COVER (chrome)	ALL
24	25700370	GASKET, camshaft cover	ALL
25	25700731	GASKET KIT, camshaft service	ALL
26	62400052	GEROTOR ASSEMBLY	ALL
27	62400055	GEROTOR ASSEMBLY, feed (TWIN-COOLED™)	FLHTK, FLHTKL, FLTRU
	62400126	GEROTOR ASSEMBLY, feed (AIR-COOLED)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
28	62400121	OIL PUMP ASSEMBLY, with 601, 8873, 26210-99, 62400052, 62400132 and body (AIR-COOLED) Also order 62400126	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
	62400124	OIL PUMP ASSEMBLY, with 601, 8873, 26210-99, 62400052, 62400132 and body (TWIN-COOLED™) Also order 62400055	FLHTK, FLHTKL, FLTRU
29	62400125	COVER, oil pump assembly	ALL
30	62400132	RELIEF VALVE, oil pump bypass	ALL


ENGINE MOUNTS AND STABILIZER LINK



Index No.	Part No.	Description	Model(s)
4	10100062	LOCKNUT	ALL
5	10200393	SCREW	ALL
6	10200408	SCREW (2)	ALL

8	16300005	ENGINE MOUNT, front (2)	ALL
9	16400041	BRACKET, tie link	ALL
10	16400042	END CAP, front mount	ALL


INDUCTION MODULE, FUEL



Index No.	Part No.	Description	Model(s)
3	10200373	SCREW (5)	ALL
4	12100069	PLUG, purge tube cap	ALL
5	16400049	BRACKET, induction module	ALL

6	27200025	MANIFOLD THROTTLE BODY INTAKE KIT, with 27300122, 27400019 and 91800058	ALL
7	27300082	GASKET, throttle body to manifold	ALL
8	27300086	FLANGE, intake (2)	ALL
9	27300087	SEAL, intake (2)	ALL
10	27300121	INTAKE MANIFOLD ASSEMBLY, with 27300082	ALL
11	27300122	THROTTLE BODY ASSEMBLY, with 12100069	ALL
12	27400015	FUEL INJECTOR ASSEMBLY, with O-rings (2)	ALL
13	27400019	FUEL RAIL KIT	ALL
14	32700065	SENSOR, temperature manifold absolute pressure, with O-ring	ALL
15	61200022	FUEL LINE	ALL
16	91800058	HARDWARE KIT, induction module	ALL


AIR CLEANER



Index No.	Part No.	Description	Model(s)
2	29108-08	WARNING LABEL, air cleaner (chrome) (Domestic, California)	ALL

5	29000106	SEAL, air cleaner cover	ALL
6	29000108	GASKET, induction module to backplate	ALL
7	29000120	BACKPLATE ASSEMBLY (Domestic)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	29000121	BACKPLATE ASSEMBLY (HDI)	FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
8	29400211	BREATHER HOSE	ALL
9	29400212	FILTER ELEMENT	ALL
10	29000216	COVER KIT, air cleaner, with 29108-08	ALL
11	61300467	INSERT, air cleaner cover	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	61300501	INSERT, air cleaner cover	FLHTK, FLHTKL


ALTERNATOR AND REGULATOR



Index No.	Part No.	Description	Model(s)
5	29900038	ROTOR ASSEMBLY	ALL
6	29900041	SPACER, sprocket shaft	ALL
7	29900042	STATOR ASSEMBLY, 3-phase, 50 A	ALL

8	69201423	DC LEAD ASSEMBLY, voltage regulator (from main wiring harness)	ALL
9	74700025	VOLTAGE REGULATOR ASSEMBLY	ALL


ELECTRONIC CONTROL MODULE (ECM) AND COIL



Index No.	Part No.	Description	Model(s)
6	31600012	SPARK PLUG, M10 (4)	ALL
7	31600017	IGNITION COIL	ALL
8	31600018	SPARK PLUG CABLE, right front cylinder, with 10177	ALL

9	31600023	SPARK PLUG CABLE, right rear cylinder, with 10177	ALL
10	31600078	SPARK PLUG CABLE, left front cylinder, with 10177	ALL
11	31600079	SPARK PLUG CABLE, left rear cylinder, with 10177	ALL
14	69201178	BRACKET, battery hold down	ALL


SENSORS AND SWITCHES, ENGINE



Index No.	Part No.	Description	Model(s)
7	32700048	SENSOR, crankshaft position, with 11289A, 74194-98 and 69201302	ALL


8	32700054	SENSOR, engine temperature, with 10177, 69201299, 69201300 and 69201301	ALL
9	32700065	SENSOR, temperature manifold absolute pressure (TMAP), with O-ring	ALL
10	62700141	CHECK VALVE, oil pressure, with 11900010 (AIR-COOLED)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
12	69200840	SENSOR, knock (2)	ALL
13	69201299	HOUSING, socket, two-way, key B	ALL
14	69201300	TERMINAL, socket, 20 AWG (2)	ALL
15	69201301	WIRE SEAL, 22 AWG (green) (2)	ALL
16	69201302	CONNECTOR ANCHOR	ALL
17	71400112	OIL PRESSURE SWITCH	ALL

STARTER MOTOR



Index No.	Part No.	Description	Model(s)
3	31400053	STARTER ASSEMBLY COMPLETE (black)	ALL


SHIFTER, GEAR



Index No.	Part No.	Description	Model(s)
6	7330	ACORN NUT	ALL
12	33719-	SHIFTER ROD	ALL

	79B		
30	33600088	LEVER, gear shifter	ALL
31	33600091	SHAFT	ALL
32	33900172	SHIFTER CAMSHAFT ASSEMBLY, with 11389, 11575 and bearing	ALL
33	33900175	LEVER, shifter rod	ALL
34	35000198	GEAR PACK, FORKS AND DRUM SUBASSEMBLY, with 8, 9, 10, 11, 20, 21, 22, 23, 24, 25, 26, 27, 28, 32, 7340, 35260-06B, input shaft, countershaft and gears (black)	ALL


TRANSMISSION BEARINGS AND COVERS



Index No.	Part No.	Description	Model(s)
19	35260-06B	BEARING HOUSING ASSEMBLY, with 221, 8970A, 16583-00A, 35087-99A and 11000010 (black)	ALL

22	37065-06A	DIPSTICK (chrome)	ALL
23	11000010	BEARING	ALL
25	11900092	O-RING	ALL
26	24400215	GASKET	ALL
28	25800048	INSERT, side cover, six speed	FLHTK, FLHTKL
	25800049	INSERT, side cover, six speed	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
29	25800054	SIDE COVER, transmission, with 25800109 and 25800110 (chrome)	ALL
30	25800056	SIDE COVER ASSEMBLY, transmission, with 25800048 and 25800054 (chrome)	FLHTK, FLHTKL
	25800057	SIDE COVER ASSEMBLY, transmission, with 25800049 and 25800054 (chrome)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
31	25800109	TRIM, rubber	ALL
32	25800110	TAPE, foam	ALL
33	37200131	SECONDARY CLUTCH ACTUATOR, with 4890	ALL
34	62700146	FITTING ASSEMBLY, transmission oil return, with 11900092 (AIR-COOLED)	FLHR, FLHRC, FLHTCU, FLHX, FLHXS, FLTRX, FLTRXS
35	62700150	PLUG, transmission, with 11900092 (TWIN-COOLED™)	FLHTK, FLHTKL, FLTRU


TRANSMISSION HOUSING, TOP COVER AND OIL PAN



Index No.	Part No.	Description	Model(s)
11	60328-98B	PLUG, magnetic, with 11105 (2)	ALL

15	24400180	OIL PAN ASSEMBLY, with 60328-98B (black)	ALL
17	25700453	GASKET, upper cover	ALL
18	34700084	TRANSMISSION CASE SUBASSEMBLY, with 3594, 8963, 8967A, 9701A, 11161, 12074, 16574-99A, 35082-07, 35122-06, 35186-06, 35241-06, 35242-06, 66290-06, 11000101 and 35000152 (black)	ALL
19	34800025	TRANSMISSION COVER, top, with 62372-09 (chrome)	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLTRU
	34800038	TRANSMISSION COVER, top, with 62372-09 (black)	FLHX, FLHXS, FLTRX, FLTRXS
20	62700136	DIPSTICK ASSEMBLY, with 11120 (black cap)	ALL


TRANSMISSION GEARS



Index No.	Part No.	Description	Model(s)
9	11082A	SECURING SEGMENT (6)	ALL
27	35600103	GEAR ASSEMBLY, countershaft-first	ALL

28	35000198	GEAR PACK, FORKS AND DRUM SUBASSEMBLY, with 1, 2, 3, 4, 7, 8, 9, 11, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 35260-06B, shifter camshaft and forks (black)	ALL


CLUTCH



Index No.	Part No.	Description	Model(s)
8	37000032A	PRESSURE PLATE, clutch	ALL
13	37000168	BEARING, ball, double-row	ALL
14	37000169	RETAINING RING, internal	ALL

16	37000219	SEAT (3)	ALL
17	37000218	PUSHROD, clutch release	ALL
18	37000254	CLUTCH ASSEMBLY, complete, with 3, 6, 8, 9, 10, 11, 12, 13, 14, 16, 19 and 20	ALL
19	37000258	CLUTCH DISKS KIT	ALL
20	37000270	COIL SPRING (3)	ALL


PRIMARY HOUSING



Index No.	Part No.	Description	Model(s)
4	1775	SCREW (4)	ALL
6	4820A	SCREW	ALL


15	11000139	BUSHING	ALL
16	25700378	GASKET, primary cover	ALL
18	25700418	COVER, primary (chrome)	ALL
19	25700455	GASKET, primary housing to case	ALL
20	25700650	SLEEVE, damper	ALL
21	25700746	GASKET KIT, inner primary	ALL
22	36500052	INNER PRIMARY HOUSING, with 9231, 12052A, 16583-00A, 60328-98B, 60678-85 and 11000139 (black)	ALL
23	36500075	CHAIN TENSIONER ASSEMBLY	ALL

BELT, CHAINS AND SPROCKETS



Index No.	Part No.	Description	Model(s)
14	35000152	SPROCKET, transmission, 32 teeth	ALL
16	40100064	THRUST WASHER	ALL
17	40100076	ENGINE SPROCKET KIT, compensator assembly	ALL


CLUTCH CONTROL



Index No.	Part No.	Description	Model(s)
11	12100077	GROMMET	ALL
13	36700128	MASTER CYLINDER ASSEMBLY, clutch, with 36700130, 36700132,	ALL


		36700133 and 41700367 (black)	
14	36700130	MASTER CYLINDER COVER KIT, with 42856-06, 42858-06A and 36700131	ALL
15	36700131	GASKET, cover, master cylinder	ALL
16	36700132	REBUILD KIT, master cylinder	ALL
17	36700133	LEVER ASSEMBLY, hand, with 42860-06B and bushing (polished)	ALL
18	37200128	LINE ASSEMBLY, hydraulic clutch, with 12100077	FLTRX, FLTRXS
	37200129	LINE ASSEMBLY, hydraulic clutch, with 12100077	FLHR, FLHRC, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS
	37200146	LINE ASSEMBLY, hydraulic clutch, with 12100077	FLTRU

MIRRORS



Index No.	Part No.	Description	Model(s)
4	8135B	PUSHNUT (2)	FLHX, FLHXS
8	57300063	FAIRING PLUG KIT, with 8135B	FLHX, FLHXS


BRAKE LINES, FRONT - ABS



Index No.	Part No.	Description	Model(s)
15	41800542	BRAKE LINE, front, ABS (right)	FLTRU, FLTRX, FLTRXS
	41800543	BRAKE LINE, front, ABS (right)	FLHR, FLHRC
	41800544	BRAKE LINE, front, ABS (right)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS


16	41800545	BRAKE LINE, front, ABS (left)	FLTRU, FLTRX, FLTRXS
	41800546	BRAKE LINE, front, ABS (left)	FLHR, FLHRC
	41800547	BRAKE LINE, front, ABS (left)	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS

BRAKE LINES AND MODULE, REAR - ABS




Index No.	Part No.	Description	Model(s)
14	41100061	ABS MODULE (EHC)	ALL
18	41800541	BRAKE LINE, ABS module to caliper	ALL
19	69201417	CADDY, ABS module	ALL

WHEELS, FRONT



Index No.	Part No.	Description	Model(s)
27	95594-84B	WEIGHT, 5 g (black) (10)	FLHR, FLHTCU, FLHTK, FLHX, FLHXS, FLTRX, FLTRXS


FORK, FRONT, LEFT AND RIGHT - STANDARD



Index No.	Part No.	Description	Model(s)
10	45400102	FORK ASSEMBLY, complete (left)	FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	45400181	FORK ASSEMBLY, complete (left)	FLHR, FLHRC

11	45400103	FORK ASSEMBLY, complete (right)	FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	45400182	FORK ASSEMBLY, complete (right)	FLHR, FLHRC
17	45500337	SPRING, fork (2)	FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	45500456	SPRING, fork (2)	FLHR, FLHRC
18	45500339	DAMPER TUBE, with 22000031 (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
19	45500341	FORK PIPE ASSEMBLY, with 45500424 (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
20	45500396	SPRING, rebound (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
21	45500397	OIL LOCK PIECE (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
22	45500398	COLLAR, spring (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
23	45500421	BUSHING GUIDE (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
24	45500424	BUSHING, slider (2)	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS


FORK, FRONT, LEFT AND RIGHT - LOW



Index No.	Part No.	Description	Model(s)
10	45400104	FORK ASSEMBLY, complete (right)	FLHTKL
11	45400105	FORK ASSEMBLY, complete (left)	FLHTKL
17	45500338	SPRING, fork (2)	FLHTKL

18	45500340	DAMPER TUBE, with 22000031	FLHTKL
19	45500341	FORK PIPE ASSEMBLY, with 45500424 (2)	FLHTKL
20	45500396	SPRING, rebound (2)	FLHTKL
21	45500397	OIL LOCK PIECE (2)	FLHTKL
22	45500398	COLLAR, spring (2)	FLHTKL
23	45500421	BUSHING GUIDE (2)	FLHTKL
24	45500424	BUSHING, slider (2)	FLHTKL


SHOCK ABSORBERS, REAR



Index No.	Part No.	Description	Model(s)
2	6590HW	WASHER (4)	ALL
4	54000093	REAR SHOCK ABSORBER (right)	FLHR, FLHRC, FLHTCU, FLHTK, FLTRU
	54000114	REAR SHOCK ABSORBER (right)	FLHTKL, FLHX, FLHXS, FLTRX, FLTRXS

5	54000094	REAR SHOCK ABSORBER, with 54000141 (left)	FLHTCU, FLHTK, FLTRU
	54000095	REAR SHOCK ABSORBER, with 54000141 (left)	FLHR, FLHRC
	54000096	REAR SHOCK ABSORBER, with 54000141 (left)	FLHX, FLHXS, FLTRX, FLTRXS
	54000113	REAR SHOCK ABSORBER, with 54000141 (left)	FLHTKL


FRAME AND JIFFY STAND



Index No.	Part No.	Description	Model(s)
23	10200546	SCREW	ALL
24	10800025A	CLIP, conduit, anchored (2)	ALL

25	12200147A	CLIP, retaining	ALL
27	12600197	FASTENER, anchored (2)	ALL
30	47000088BHP	FRAME, main, with bearing cups (Also order 45700009)	ALL
32	50000097	BRACKET, jiffy stand leg	FLHR, FLHRC, FLHTCU, FLHTK, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	50000141A	BRACKET, jiffy stand leg	FLHTKL


COVERS AND AIR DEFLECTORS



Index No.	Part No.	Description	Model(s)
5	58167-09A	DEFLECTOR, air (right)	FLHTCU, FLHTK, FLHTKL, FLTRU


5	58167-09A	DEFLECTOR, air (right) (Brazil)	FLHRC, FLHXS
7	57200066	WIND DEFLECTOR (left)	FLTRU
8	69200202A	WIRE TROUGH (main harness)	ALL
9	69200203A	COVER, wire trough, with 15368-01A and 69201459 (main harness)	ALL
10	69201459	BRACKET	ALL

FRAME AND FORK, REAR AND TOUR-PAK SUPPORT




Index No.	Part No.	Description	Model(s)
10	47549-09A	REAR FORK, with 9208, 11779 and 48489-02	ALL

FOOTBOARDS, OPERATOR




Index No.	Part No.	Description	Model(s)
13	10200429	SCREW (2)	ALL
15	47200302A	BRACKET, front footboard (2)	ALL

FENDERS, FRONT




Index No.	Part No.	Description	Model(s)
23	59600011	FRONT FENDER TIP	FLHTCU

FENDERS, REAR (2 OF 2)




Index No.	Part No.	Description	Model(s)
38	59600029	FENDER TIP, rear (Domestic)	FLHTCU, FLHTK, FLHTKL, FLTRU

LICENSE PLATE BRACKETS



Index No.	Part No.	Description	Model(s)
11	11100195	CUSHION (HDI)	FLHR, FLHRC
14	67900445	LICENSE PLATE BRACKET, with 59259-90 and 11100195 (HDI)	FLHR, FLHRC


FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX
AND FLTRXS



Index No.	Part No.	Description	Model(s)
4	11323A	O-RING, check valve to tank	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX,


			FLTRXS
8	62228-08C	CHECK VALVE, assembly, with 10396 and 11323A	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
11	61200022	FUEL LINE, tank to intake	FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS

FUEL TANK - FLHR AND FLHRC




Index No.	Part No.	Description	Model(s)
4	11323A	O-RING, check valve to tank	FLHR, FLHRC
10	62228-08C	CHECK VALVE, assembly, with 10396 and 11323A	FLHR, FLHRC
14	61200022	FUEL LINE, tank to intake	FLHR, FLHRC

CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2)




Index No.	Part No.	Description	Model(s)
31	14100855	INSERT, console panel (Domestic)	FLHX, FLHXS

INSTRUMENTS, FUEL TANK - FLHR AND FLHRC



Index No.	Part No.	Description	Model(s)
24	70900167B	SPEEDOMETER, mph (Domestic, California)	FLHR
	70900168A	SPEEDOMETER, km/h (Canada, HDI, Australia, Japan, Asia-Pacific)	FLHR
	70900168A	SPEEDOMETER, km/h (HDI, Brazil)	FLHRC


INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS



Index No.	Part No.	Description	Model(s)
11	70900118B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California)	FLHTK, FLHTKL

	70900119A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Brazil, Canada, HDI, Australia, Japan, Asia-Pacific)	FLHTK, FLHTKL
	70900120A	INSTRUMENT CLUSTER, dual - mph/km/h, with 12100020 and 12400034 (England)	FLHTK, FLHTKL
	70900121B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California) (black)	FLHTCU
	70900122A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Canada, HDI, Australia, Japan, Asia-Pacific) (black)	FLHTCU
	70900124B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California) (silver)	FLHX, FLHXS
	70900125A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Brazil, Canada, HDI, Australia, Japan, Asia-Pacific) (silver)	FLHX, FLHXS
	70900126A	INSTRUMENT CLUSTER, dual - mph/km/h, with 12100020 and 12400034 (England) (silver)	FLHXS


INSTRUMENTS - FLTRU, FLTRX AND FLTRXS



Index No.	Part No.	Description	Model(s)
10	70900121B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California) (black)	FLTRU
	70900122A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Canada, HDI, Japan, Asia-	FLTRU


		Pacific) (black)	
	70900123A	INSTRUMENT CLUSTER, dual - mph/km/h, with 12100020 and 12400034 (England) (black)	FLTRU
	70900124B	INSTRUMENT CLUSTER, mph, with 12100020 and 12400034 (Domestic, California) (silver)	FLTRX, FLTRXS
	70900125A	INSTRUMENT CLUSTER, km/h, with 12100020 and 12400034 (Canada, HDI, Australia, Japan, Asia-Pacific) (silver)	FLTRX, FLTRXS
	70900126A	INSTRUMENT CLUSTER, dual - mph/km/h, with 12100020 and 12400034 (England) (silver)	FLTRXS

EVAPORATIVE EMISSIONS COMPONENTS




Index No.	Part No.	Description	Model(s)
8	60800026	TUBE, solenoid to induction module	ALL

NACELLE AND HEADLAMP - FLHR AND FLHRC




Index No.	Part No.	Description	Model(s)
25	71455-11	HOLE PLUG (black)	FLHR, FLHRC

WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)




Index No.	Part No.	Description	Model(s)
31	67700060	HEADLAMP, LED, with 67721-48, 67726-08 and 67700204	FLHTCU, FLHTK, FLHTKL

WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)




Index No.	Part No.	Description	Model(s)
	57400302	WINDSHIELD (dark smoke) (Domestic, Australia)	FLTRX, FLTRXS

SWITCHES, HANDLEBAR, LEFT



Index No.	Part No.	Description	Model(s)
16	71500419	SWITCH PACK, left hand control, with 71500044, 71500047, 71500048 and 71500053	FLHR, FLHRC


EXHAUST SYSTEM



Index No.	Part No.	Description	Model(s)
15	65724-85A	MOUNT, rubber (2)	ALL

23	10900015	STUD, exhaust	ALL
24	32700046	SENSOR, oxygen (O2), front, with 10177, 11936, 72344-10, 72444-07GY and 73307-10	ALL
25	64900235	MUFFLER (left) (chrome) (Domestic, Canada, California)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	64900237	MUFFLER (left) (chrome) (Asia-Pacific, Brazil)	FLHR, FLHTK, FLHXS, FLTRU, FLTRXS
	64900239	MUFFLER (left) (chrome) (Australia, England, HDI, Japan)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
26	64900236	MUFFLER (right) (chrome) (Domestic, Canada, California)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	64900238	MUFFLER (right) (chrome) (Asia-Pacific, Brazil)	FLHR, FLHTK, FLHXS, FLTRU, FLTRXS
	64900240	MUFFLERY (right) (chrome) (Australia, England, HDI, Japan)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
27	65400176	SHIELD, exhaust pipe, front	ALL
28	65400177	EXHAUST SHIELD ASSEMBLY, rear header pipe	ALL
29	65400178	EXHAUST SHIELD ASSEMBLY, catalytic converter	ALL
30	65400179	SHIELD, left exhaust pipe, rear	ALL
31	65500042	BRACKET, muffler strap, male	ALL
32	65500043	BRACKET, muffler strap, female	ALL
33	65600176	HEADER ASSEMBLY, catalytic (Domestic, Canada, California) (chrome)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS
	65600177	HEADER ASSEMBLY, catalytic (Australia, England, Japan, HDI, Asia-Pacific, Brazil) (chrome)	FLHR, FLHRC, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
34	65600178	CROSSOVER PIPE ASSEMBLY (chrome)	ALL
35	65900012	CLAMP, muffler (2)	ALL
36	65900015	CLAMP, muffler	ALL


WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
11	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHX
14	69201287	BRACKET, mounting, electrical connector	FLHX


15	69201459	BRACKET	FLHX

WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHX
6	72098-06	HOUSING, two-way socket (gray)	FLHX


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHX
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHX
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHX
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHX
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHX
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHX
14	69201390	HOUSING, two-way socket (2)	FLHX
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHX
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHX
17	69201393	HOUSING, two-way socket (black)	FLHX
18	69201394	HOUSING, six-way socket	FLHX
19	69201395	SECONDARY LOCK, six-way socket	FLHX
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHX
21	69201397	HOUSING, two-way pin	FLHX
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHX
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHX
24	69201416	CPA, six-way socket	FLHX
25	69201441	HOUSING, four-way socket	FLHX
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHX

WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
13	69201415	HOUSING, 18-way socket (brown)	FLHX
14	69201440	HOUSING, 18-way socket (gray)	FLHX

WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8)




Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX

WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
4	72065-06A	HOUSING, three-way socket	FLHX
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHX

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHX
20	72589-09	HOUSING, three-way socket	FLHX
30	12500014	CABLE STRAP (2)	FLHX
32	69201396	TERMINAL, socket, 20 AWG (2)	FLHX
33	69201400	HOUSING, two-way socket, CPA (black)	FLHX
34	69201401	SECONDARY LOCK, two-way socket	FLHX
35	69201404	RETAINER, anchored	FLHX
36	69201405	RESISTOR PACK	FLHX
37	69201423	DC LEAD ASSEMBLY, two-way socket	FLHX
38	72232-96	SEAL PIN (2)	FLHX
39	12500018	CABLE STRAP	FLHX


WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201125	MAIN WIRING HARNESS - NON-ABS	FLHX
24	72330-95	FUSE, 15 A (blue)	FLHX
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHX

47	69201307	BOOT, battery positive	FLHX
48	69201411	COVER, fuse block	FLHX


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
11	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHX, FLHXS
14	69201287	BRACKET, mounting, electrical connector	FLHX, FLHXS


15	69201459	BRACKET	FLHX, FLHXS

WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHX, FLHXS
6	72098-06	HOUSING, two-way socket (gray)	FLHX, FLHXS


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHX, FLHXS
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHX, FLHXS
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHX, FLHXS
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHX, FLHXS
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHX, FLHXS
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHX, FLHXS
14	69201390	HOUSING, two-way socket (2)	FLHX, FLHXS
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHX, FLHXS
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHX, FLHXS
17	69201393	HOUSING, two-way socket (black)	FLHX, FLHXS
18	69201394	HOUSING, six-way socket	FLHX, FLHXS
19	69201395	SECONDARY LOCK, six-way socket	FLHX, FLHXS
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHX, FLHXS
21	69201397	HOUSING, two-way pin	FLHX, FLHXS
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHX, FLHXS
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHX, FLHXS
24	69201416	CPA, six-way socket	FLHX, FLHXS
25	69201441	HOUSING, four-way socket	FLHX, FLHXS
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHX, FLHXS

WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
14	69201440	HOUSING, 18-way socket (gray)	FLHX, FLHXS

WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8)




Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS

WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
4	72065-06A	HOUSING, three-way socket	FLHX, FLHXS
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHX, FLHXS

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHX, FLHXS
20	72589-09	HOUSING, three-way socket	FLHX, FLHXS
30	12500014	CABLE STRAP (2)	FLHX, FLHXS
41	69201396	TERMINAL, socket, 20 AWG (2)	FLHX, FLHXS
42	69201400	HOUSING, two-way socket, CPA (black)	FLHX, FLHXS
43	69201401	SECONDARY LOCK, two-way socket	FLHX, FLHXS
44	69201404	RETAINER, anchored	FLHX, FLHXS
45	69201405	RESISTOR PACK	FLHX, FLHXS
46	69201423	DC LEAD ASSEMBLY, two-way socket	FLHX, FLHXS
47	72232-96	SEAL PIN (2)	FLHX, FLHXS
48	12500018	CABLE STRAP	FLHX, FLHXS


WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201121	MAIN WIRING HARNESS - ABS	FLHX, FLHXS
24	72330-95	FUSE, 15 A (blue)	FLHX, FLHXS
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHX, FLHXS


47	69201307	BOOT, battery positive	FLHX, FLHXS
48	69201411	COVER, fuse block	FLHX, FLHXS

WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8)




Index No.	Part No.	Description	Model(s)
14	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHTCU
16	69201287	BRACKET, mounting, electrical connector	FLHTCU
17	69201459	BRACKET	FLHTCU

WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHTCU
6	72098-06	HOUSING, two-way socket (gray)	FLHTCU


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHTCU
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHTCU
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHTCU
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHTCU
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHTCU
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHTCU
14	69201390	HOUSING, two-way socket (2)	FLHTCU
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHTCU
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHTCU
17	69201393	HOUSING, two-way socket (black)	FLHTCU
18	69201394	HOUSING, six-way socket	FLHTCU
19	69201395	SECONDARY LOCK, six-way socket	FLHTCU
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHTCU
21	69201397	HOUSING, two-way pin	FLHTCU
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHTCU
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHTCU
24	69201416	CPA, six-way socket	FLHTCU
25	69201441	HOUSING, four-way socket	FLHTCU
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHTCU

WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
13	69201415	HOUSING, 18-way socket (brown)	FLHTCU
14	69201440	HOUSING, 18-way socket (gray)	FLHTCU

WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8)




Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU

WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
4	72065-06A	HOUSING, three-way socket	FLHTCU
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHTCU

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHTCU
20	72589-09	HOUSING, three-way socket	FLHTCU
30	12500014	CABLE STRAP (2)	FLHTCU
41	69201396	TERMINAL, socket, 20 AWG (2)	FLHTCU
42	69201400	HOUSING, two-way socket, CPA (black)	FLHTCU
43	69201401	SECONDARY LOCK, two-way socket	FLHTCU
44	69201404	RETAINER, anchored	FLHTCU
45	69201405	RESISTOR PACK	FLHTCU
46	69201423	DC LEAD ASSEMBLY, two-way socket	FLHTCU
47	72232-96	SEAL PIN (2)	FLHTCU
48	12500018	CABLE STRAP	FLHTCU


WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201120	MAIN WIRING HARNESS - ABS	FLHTCU
24	72330-95	FUSE, 15 A (blue)	FLHTCU
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHTCU


47	69201307	BOOT, battery positive	FLHTCU
48	69201411	COVER, fuse block	FLHTCU

WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8)




Index No.	Part No.	Description	Model(s)
14	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHTK, FLHTKL
16	69201287	BRACKET, mounting, electrical connector	FLHTK, FLHTKL
17	69201459	BRACKET	FLHTK, FLHTKL

WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHTK, FLHTKL
6	72098-06	HOUSING, two-way socket (gray)	FLHTK, FLHTKL


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHTK, FLHTKL
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHTK, FLHTKL
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHTK, FLHTKL
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHTK, FLHTKL
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHTK, FLHTKL
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHTK, FLHTKL
14	69201390	HOUSING, two-way socket (2)	FLHTK, FLHTKL
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHTK, FLHTKL
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHTK, FLHTKL
17	69201393	HOUSING, two-way socket (black)	FLHTK, FLHTKL
18	69201394	HOUSING, six-way socket	FLHTK, FLHTKL
19	69201395	SECONDARY LOCK, six-way socket	FLHTK, FLHTKL
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHTK, FLHTKL
21	69201397	HOUSING, two-way pin	FLHTK, FLHTKL
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHTK, FLHTKL
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHTK, FLHTKL
24	69201416	CPA, six-way socket	FLHTK, FLHTKL
25	69201441	HOUSING, four-way socket	FLHTK, FLHTKL
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHTK, FLHTKL

WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
13	69201410	HOUSING, 18-way socket (brown)	FLHTK, FLHTKL
14	69201414	HOUSING, 18-way socket (gray)	FLHTK, FLHTKL

WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8)




Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL

WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
4	72065-06A	HOUSING, three-way socket	FLHTK, FLHTKL
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHTK, FLHTKL

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHTK, FLHTKL
20	72589-09	HOUSING, three-way socket	FLHTK, FLHTKL
28	12500014	CABLE STRAP (2)	FLHTK, FLHTKL
40	69201301	WIRE SEAL, 20-22 AWG (green) (3)	FLHTK, FLHTKL
41	69201396	TERMINAL, socket, 20 AWG (2)	FLHTK, FLHTKL
42	69201400	HOUSING, two-way socket, CPA (black)	FLHTK, FLHTKL
43	69201401	SECONDARY LOCK, two-way socket	FLHTK, FLHTKL
44	69201404	RETAINER, anchored	FLHTK, FLHTKL
45	69201405	RESISTOR PACK	FLHTK, FLHTKL
46	69201406	HOUSING, three-way socket	FLHTK, FLHTKL
47	69201407	TERMINAL, socket, 20 AWG (3)	FLHTK, FLHTKL
48	69201423	DC LEAD ASSEMBLY, two-way socket	FLHTK, FLHTKL
49	12500018	CABLE STRAP	FLHTK, FLHTKL


WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201119	MAIN WIRING HARNESS - ABS	FLHTK, FLHTKL
24	72330-95	FUSE, 15 A (blue)	FLHTK, FLHTKL
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHTK, FLHTKL

47	69201307	BOOT, battery positive	FLHTK, FLHTKL
48	69201411	COVER, fuse block	FLHTK, FLHTKL


WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
13	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHR
14	69200284A	BRACKET, mounting	FLHR


17	69201287	BRACKET, mounting, electrical connector	FLHR
18	69201459	BRACKET	FLHR

WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHR
6	72098-06	HOUSING, two-way socket (gray)	FLHR


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHR
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHR
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHR
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHR
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHR
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHR
14	69201390	HOUSING, two-way socket (2)	FLHR
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHR
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHR
17	69201393	HOUSING, two-way socket (black)	FLHR
18	69201394	HOUSING, six-way socket	FLHR
19	69201395	SECONDARY LOCK, six-way socket	FLHR
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHR
21	69201397	HOUSING, two-way pin	FLHR
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHR
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHR
24	69201416	CPA, six-way socket	FLHR
25	69201441	HOUSING, four-way socket	FLHR
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHR

WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
12	69201415	HOUSING, 18-way socket (brown)	FLHR
13	69201440	HOUSING, 18-way socket (gray)	FLHR

WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8)




Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR

WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
4	72065-06A	HOUSING, three-way socket	FLHR
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHR

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHR
20	72589-09	HOUSING, three-way socket	FLHR
30	12500014	CABLE STRAP (2)	FLHR
32	69201396	TERMINAL, socket, 20 AWG (2)	FLHR
33	69201400	HOUSING, two-way socket, CPA (black)	FLHR
34	69201401	SECONDARY LOCK, two-way socket	FLHR
35	69201404	RETAINER, anchored	FLHR
36	69201405	RESISTOR PACK	FLHR
37	69201423	DC LEAD ASSEMBLY, two-way socket	FLHR
38	72232-96	SEAL PIN (2)	FLHR
39	12500018	CABLE STRAP	FLHR


WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201126	MAIN WIRING HARNESS - NON-ABS	FLHR
23	72330-95	FUSE, 15 A (blue)	FLHR
44	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHR

45	69201307	BOOT, battery positive	FLHR
46	69201411	COVER, fuse block	FLHR


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
13	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLHR, FLHRC
14	69200284A	BRACKET, mounting	FLHR, FLHRC


17	69201287	BRACKET, mounting, electrical connector	FLHR, FLHRC
18	69201459	BRACKET	FLHR, FLHRC

WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLHR, FLHRC
6	72098-06	HOUSING, two-way socket (gray)	FLHR, FLHRC


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLHR, FLHRC
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLHR, FLHRC
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLHR, FLHRC
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLHR, FLHRC
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLHR, FLHRC
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLHR, FLHRC
14	69201390	HOUSING, two-way socket (2)	FLHR, FLHRC
15	69201391	TERMINAL, socket, 20 AWG (4)	FLHR, FLHRC
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLHR, FLHRC
17	69201393	HOUSING, two-way socket (black)	FLHR, FLHRC
18	69201394	HOUSING, six-way socket	FLHR, FLHRC
19	69201395	SECONDARY LOCK, six-way socket	FLHR, FLHRC
20	69201396	TERMINAL, socket, 20 AWG (4)	FLHR, FLHRC
21	69201397	HOUSING, two-way pin	FLHR, FLHRC
22	69201398	TERMINAL, pin, 20 AWG (2)	FLHR, FLHRC
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLHR, FLHRC
24	69201416	CPA, six-way socket	FLHR, FLHRC
25	69201441	HOUSING, four-way socket	FLHR, FLHRC
26	69201442	TERMINAL, socket, 18 AWG (4)	FLHR, FLHRC

WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
13	69201415	HOUSING, 18-way socket (brown)	FLHR, FLHRC
14	69201440	HOUSING, 18-way socket (gray)	FLHR, FLHRC

WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8)




Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC

WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
4	72065-06A	HOUSING, three-way socket	FLHR, FLHRC
5	72127-06	SECONDARY LOCK, three-way (gray)	FLHR, FLHRC

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLHR, FLHRC
20	72589-09	HOUSING, three-way socket	FLHR, FLHRC
30	12500014	CABLE STRAP (2)	FLHR, FLHRC
41	69201396	TERMINAL, socket, 20 AWG (2)	FLHR, FLHRC
42	69201400	HOUSING, two-way socket, CPA (black)	FLHR, FLHRC
43	69201401	SECONDARY LOCK, two-way socket	FLHR, FLHRC
44	69201404	RETAINER, anchored	FLHR, FLHRC
45	69201405	RESISTOR PACK	FLHR, FLHRC
46	69201423	DC LEAD ASSEMBLY, two-way socket	FLHR, FLHRC
47	72232-96	SEAL PIN (2)	FLHR, FLHRC
48	12500018	CABLE STRAP	FLHR, FLHRC


WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201122	MAIN WIRING HARNESS - ABS	FLHR, FLHRC
23	72330-95	FUSE, 15 A (blue)	FLHR, FLHRC
44	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLHR, FLHRC

45	69201307	BOOT, battery positive	FLHR, FLHRC
46	69201411	COVER, fuse block	FLHR, FLHRC


WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
19	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLTRX
23	69201287	BRACKET, mounting, electrical connector	FLTRX


24	69201459	BRACKET	FLTRX

WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLTRX
6	72098-06	HOUSING, two-way socket (gray)	FLTRX


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLTRX
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLTRX
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLTRX
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLTRX
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLTRX
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLTRX
14	69201390	HOUSING, two-way socket (2)	FLTRX
15	69201391	TERMINAL, socket, 20 AWG (4)	FLTRX
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLTRX
17	69201393	HOUSING, two-way socket (black)	FLTRX
18	69201394	HOUSING, six-way socket	FLTRX
19	69201395	SECONDARY LOCK, six-way socket	FLTRX
20	69201396	TERMINAL, socket, 20 AWG (4)	FLTRX
21	69201397	HOUSING, two-way pin	FLTRX
22	69201398	TERMINAL, pin, 20 AWG (2)	FLTRX
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLTRX
24	69201416	CPA, six-way socket	FLTRX
25	69201441	HOUSING, four-way socket	FLTRX
26	69201442	TERMINAL, socket, 18 AWG (4)	FLTRX

WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
13	69201415	HOUSING, 18-way socket (brown)	FLTRX
14	69201440	HOUSING, 18-way socket (gray)	FLTRX

WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8)




Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX

WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
4	72065-06A	HOUSING, three-way socket	FLTRX
5	72127-06	SECONDARY LOCK, three-way (gray)	FLTRX

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLTRX
20	72589-09	HOUSING, three-way socket	FLTRX
30	12500014	CABLE STRAP (2)	FLTRX
32	69201396	TERMINAL, socket, 20 AWG (2)	FLTRX
33	69201400	HOUSING, two-way socket, CPA (black)	FLTRX
34	69201401	SECONDARY LOCK, two-way socket	FLTRX
35	69201404	RETAINER, anchored	FLTRX
36	69201405	RESISTOR PACK	FLTRX
37	69201423	DC LEAD ASSEMBLY, two-way socket	FLTRX
38	72232-96	SEAL PIN (2)	FLTRX
39	12500018	CABLE STRAP	FLTRX


WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201127	MAIN WIRING HARNESS - NON-ABS	FLTRX
24	72330-95	FUSE, 15 A (blue)	FLTRX
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLTRX

47	69201307	BOOT, battery positive	FLTRX
48	69201411	COVER, fuse block	FLTRX


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
19	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLTRX, FLTRXS
23	69201287	BRACKET, mounting, electrical connector	FLTRX, FLTRXS


24	69201459	BRACKET	FLTRX, FLTRXS

WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLTRX, FLTRXS
6	72098-06	HOUSING, two-way socket (gray)	FLTRX, FLTRXS


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLTRX, FLTRXS
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLTRX, FLTRXS
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLTRX, FLTRXS
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLTRX, FLTRXS
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLTRX, FLTRXS
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLTRX, FLTRXS
14	69201390	HOUSING, two-way socket (2)	FLTRX, FLTRXS
15	69201391	TERMINAL, socket, 20 AWG (4)	FLTRX, FLTRXS
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLTRX, FLTRXS
17	69201393	HOUSING, two-way socket (black)	FLTRX, FLTRXS
18	69201394	HOUSING, six-way socket	FLTRX, FLTRXS
19	69201395	SECONDARY LOCK, six-way socket	FLTRX, FLTRXS
20	69201396	TERMINAL, socket, 20 AWG (4)	FLTRX, FLTRXS
21	69201397	HOUSING, two-way pin	FLTRX, FLTRXS
22	69201398	TERMINAL, pin, 20 AWG (2)	FLTRX, FLTRXS
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLTRX, FLTRXS
24	69201416	CPA, six-way socket	FLTRX, FLTRXS
25	69201441	HOUSING, four-way socket	FLTRX, FLTRXS
26	69201442	TERMINAL, socket, 18 AWG (4)	FLTRX, FLTRXS

WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
13	69201415	HOUSING, 18-way socket (brown)	FLTRX, FLTRXS
14	69201440	HOUSING, 18-way socket (gray)	FLTRX, FLTRXS

WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
4	72065-06A	HOUSING, three-way socket	FLTRX, FLTRXS
5	72127-06	SECONDARY LOCK, three-way (gray)	FLTRX, FLTRXS

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLTRX, FLTRXS
20	72589-09	HOUSING, three-way socket	FLTRX, FLTRXS
30	12500014	CABLE STRAP (2)	FLTRX, FLTRXS
41	69201396	TERMINAL, socket, 20 AWG (2)	FLTRX, FLTRXS
42	69201400	HOUSING, two-way socket, CPA (black)	FLTRX, FLTRXS
43	69201401	SECONDARY LOCK, two-way socket	FLTRX, FLTRXS
44	69201404	RETAINER, anchored	FLTRX, FLTRXS
45	69201405	RESISTOR PACK	FLTRX, FLTRXS
46	69201423	DC LEAD ASSEMBLY, two-way socket	FLTRX, FLTRXS
47	72232-96	SEAL PIN (2)	FLTRX, FLTRXS
48	12500018	CABLE STRAP	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201124	MAIN WIRING HARNESS - ABS	FLTRX, FLTRXS
24	72330-95	FUSE, 15 A (blue)	FLTRX, FLTRXS
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLTRX, FLTRXS

47	69201307	BOOT, battery positive	FLTRX, FLTRXS
48	69201411	COVER, fuse block	FLTRX, FLTRXS


WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
18	69200203A	COVER, wire trough, with 15368-01A and 69201459	FLTRU
22	69201287	BRACKET, mounting, electrical connector	FLTRU


23	69201459	BRACKET	FLTRU

WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU


WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
3	72008-05	TERMINAL, socket, 20-22 AWG (4)	FLTRU
6	72098-06	HOUSING, two-way socket (gray)	FLTRU


7	72099-06	WIRE SEAL, 16-18 AWG (blue) (4)	FLTRU
8	72110-06	TERMINAL, socket, 16-18 AWG (4)	FLTRU
9	72145-06	SECONDARY LOCK, two-way socket (blue) (2)	FLTRU
11	72499-07	WIRE SEAL, 20-22 AWG (yellow) (6)	FLTRU
12	72569-08	TERMINAL, socket, 20-22 AWG (silver) (2)	FLTRU
13	69201301	WIRE SEAL, 20-22 AWG (green) (2)	FLTRU
14	69201390	HOUSING, two-way socket (2)	FLTRU
15	69201391	TERMINAL, socket, 20 AWG (4)	FLTRU
16	69201392	WIRE SEAL, 20 AWG (blue) (4)	FLTRU
17	69201393	HOUSING, two-way socket (black)	FLTRU
18	69201394	HOUSING, six-way socket	FLTRU
19	69201395	SECONDARY LOCK, six-way socket	FLTRU
20	69201396	TERMINAL, socket, 20 AWG (4)	FLTRU
21	69201397	HOUSING, two-way pin	FLTRU
22	69201398	TERMINAL, pin, 20 AWG (2)	FLTRU
23	69201412	WIRE SEAL, 16-18 AWG (yellow) (4)	FLTRU
24	69201416	CPA, six-way socket	FLTRU
25	69201441	HOUSING, four-way socket	FLTRU
26	69201442	TERMINAL, socket, 18 AWG (4)	FLTRU

WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)




Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
13	69201410	HOUSING, 18-way socket (brown)	FLTRU
14	69201414	HOUSING, 18-way socket (gray)	FLTRU

WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8)




Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU

WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU


WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
4	72065-06A	HOUSING, three-way socket	FLTRU
5	72127-06	SECONDARY LOCK, three-way (gray)	FLTRU

15	72499-07	WIRE SEAL, 20-22 AWG (green) (2)	FLTRU
20	72589-09	HOUSING, three-way socket	FLTRU
28	12500014	CABLE STRAP (2)	FLTRU
40	69201301	WIRE SEAL, 20-22 AWG (green) (3)	FLHX
41	69201396	TERMINAL, socket, 20 AWG (2)	FLTRU
42	69201400	HOUSING, two-way socket, CPA (black)	FLTRU
43	69201401	SECONDARY LOCK, two-way socket	FLTRU
44	69201404	RETAINER, anchored	FLTRU
45	69201405	RESISTOR PACK	FLTRU
46	69201406	HOUSING, three-way socket	FLTRU
47	69201407	TERMINAL, socket, 20 AWG (3)	FLTRU
48	69201423	DC LEAD ASSEMBLY, two-way socket	FLTRU
49	12500018	CABLE STRAP	FLTRU


WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)



Index No.	Part No.	Description	Model(s)
	69201123	MAIN WIRING HARNESS - ABS	FLTRU
24	72330-95	FUSE, 15 A (blue)	FLTRU
46	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	FLTRU

47	69201307	BOOT, battery positive	FLTRU
48	69201411	COVER, fuse block	FLTRU


BATTERY



Index No.	Part No.	Description	Model(s)
13	66000116	CABLE ASSEMBLY, starter to ground, with 72242-94	ALL
15	69201130	WIRE HARNESS, battery positive to starter, with 73304-04, 73305-04 and 69201307	ALL
16	69201178	BRACKET, battery hold down	ALL


17	69201307	BOOT, battery positive	ALL

HORN



Index No.	Part No.	Description	Model(s)
12	14100764	INSERT, horn	ALL
13	61300523	COVER, horn (chrome)	ALL
14	69000083	BRACKET ASSEMBLY, horn mount	ALL


SWITCHES



Index No.	Part No.	Description	Model(s)
17	41000341A	BODY CONTROL MODULE (BCM) with security (Domestic, HDI)	ALL

	41000342A	BODY CONTROL MODULE (BCM) with security (Japan)	FLHR, FLHTK, FLHTKL, FLHXS, FLTRU, FLTRXS
	41000351A	BODY CONTROL MODULE (BCM)	FLHR, FLHTCU, FLHX, FLTRX
25	90300111	REMOTE CONTROL FOB, with 66373-06 (except Japan) (2)	ALL
	90300112	REMOTE CONTROL FOB, with 66373-06 (Japan) (2)	ALL


SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)



Index No.	Part No.	Description	Model(s)
20	76000076B	RADIO, premium, with navigation, with 12600070, 12600071, 12600073 and 76000252 (Domestic, California, Canada) (See NOTE 1)	FLHTCU, FLHTK, FLHTKL, FLHXS

	76000231B	RADIO, premium, with navigation, with 12600070, 12600071, 12600073 and 76000252 (England, HDI) (See NOTE 2)	FLHTK, FLHTKL, FLHXS
	76000232B	RADIO, premium, with 12600070, 12600071, 12600073 and 76000252 (Australia, HDI, Japan, Asia-Pacific, Brazil) (See NOTE 3)	FLHTK, FLHTKL, FLHXS
	76000075B	RADIO, standard, with 12600070 and 12600071 (Domestic, California, Canada)	FLHTCU, FLHX
	76000230B	RADIO, standard, with 12600070 and 12600071 (Canada)	FLHTCU, FLHX


SADDLEBAGS (1 OF 2)



Index No.	Part No.	Description	Model(s)
9	10200533	SCREW, single sided lever (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS

10	10400034	NUT, clip (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS


SADDLEBAGS (2 OF 2)



Index No.	Part No.	Description	Model(s)
	90200983DZP	FACEPLATE (left) (billet silver)	FLTRX
	90200984DZP	FACEPLATE (right) (billet silver)	FLTRX


27	90201540	KIT, SADDLEBAG MOUNT, with 10200533 and 10400034 (set of 4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS

GUARDS, SADDLEBAG




Index No.	Part No.	Description	Model(s)
9	10400034	NUT, clip (4)	FLHR, FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX, FLTRXS

LABELS



Index No.	Part No.	Description	Model(s)
2	13729-17	YEAR OF MANUFACTURING LABEL (Brazil)	FLHRC, FLHTK, FLHXS
8	29108-08	WARNING LABEL, air cleaner, (chrome) (Except Canada)	ALL


LOOSE PARTS (1 OF 3)



Index No.	Part No.	Description	Model(s)
1	99466-17	OWNER'S MANUAL (Domestic, Australia, England)	ALL
	90300111	REMOTE CONTROL FOB (except Japan) (2)	ALL
	90300112	REMOTE CONTROL FOB (Japan) (2)	ALL

	58002-09A	AIR DEFLECTOR KIT, MID-FRAME (See NOTE)	FLHTCU, FLHTK, FLHTKL
	99517-17EN	BOOM! OWNER'S MANUAL KIT, English (Domestic, Australia, England)	FLHTCU, FLHTK, FLHTKL


LOOSE PARTS (2 OF 3)



Index No.	Part No.	Description	Model(s)
	99517-17EN	BOOM! OWNER'S MANUAL KIT, English (Domestic, Australia, England)	FLTRX, FLTRXS
	57400302	WINDSHIELD (Domestic, Australia)	FLTRX, FLTRXS
	57400303	WINDSHIELD (HDI, England, Japan, Asia-Pacific)	FLTRXS

	58002-09A	AIR DEFLECTOR KIT, MID-FRAME (See NOTE)	FLTRU
	99517-17EN	BOOM! OWNER'S MANUAL KIT, English (Domestic, California, Canada, England)	FLTRU

LOOSE PARTS (3 OF 3)



Index No.	Part No.	Description	Model(s)
	58002-09A	AIR DEFLECTOR KIT, MID-FRAME (Brazil) (See NOTE)	FLHRC
1	58002-09A	AIR DEFLECTOR KIT, MID-FRAME (Brazil) (See NOTE)	FLHXS
	99517-17EN	BOOM! OWNER'S MANUAL KIT, English (Domestic, Australia, England)	FLHX, FLHXS

Numerical Index

10006	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ BRAKE LINE, FRONT - NON-ABS BRAKE LINES, FRONT - ABS FENDERS, REAR (1 OF 2) HANDLEBAR HANDLEBAR THROTTLE CONTROL TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
10039	ALTERNATOR AND REGULATOR CLUTCH CONTROL FRAME AND JIFFY STAND FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC EXHAUST SYSTEM
10053	FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2)
10065	BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS FENDERS, FRONT CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)

FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8)
WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)
WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)

	WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) SWITCHES SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
10076	BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
10080	COOLANT DISTRIBUTION, AIR-COOLED
10100033	FAIRING LOWERS, AIR COOLED - FLHTCU
10100062	ENGINE MOUNTS AND STABILIZER LINK
10103	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
10147	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ WHEELS, REAR WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
10177	ALTERNATOR AND REGULATOR ELECTRONIC CONTROL MODULE (ECM) AND COIL SENSORS AND SWITCHES, ENGINE FRAME AND JIFFY STAND FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) EXHAUST SYSTEM WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8)

	WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
10183	FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
10184	FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
10200042	FORK BRACKETS, FRONT
10200052	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
10200059	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
10200060	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
10200061	TOUR-PAK (BOTTOM) TOUR-PAK (COVER)
10200062	TOUR-PAK (BOTTOM) TOUR-PAK (COVER) SADDLEBAGS (1 OF 2)
10200063	SADDLEBAGS (1 OF 2)
10200064	SADDLEBAGS (1 OF 2)
10200065	SADDLEBAGS (1 OF 2)
10200103	SADDLEBAGS (1 OF 2)
10200105	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
10200112	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
10200120	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
10200133	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
10200134	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
10200141	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3) FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
10200142	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
10200147	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS

10200154	TOUR-PAK (COVER)
10200155	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
10200156	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
10200205	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
10200217	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT GUARDS, SADDLEBAG
10200223	BRAKE LINE, FRONT - NON-ABS BRAKE LINES, FRONT - ABS FORK BRACKETS, FRONT
10200257	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
10200258	ROCKER ARM ASSEMBLY AND PUSHRODS
10200303	CYLINDERS, HEADS AND VALVES
10200308	ROCKER ARM ASSEMBLY AND PUSHRODS
10200343	CRANKCASE AND ENGINE OIL FILTER
10200350	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
10200365	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
10200373	INDUCTION MODULE, FUEL
10200393	ENGINE MOUNTS AND STABILIZER LINK
10200400	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
10200408	ENGINE MOUNTS AND STABILIZER LINK
10200414	COOLANT DISTRIBUTION, TWIN-COOLED™ COOLANT DISTRIBUTION, AIR-COOLED
10200422	COOLANT DISTRIBUTION, TWIN-COOLED™ COOLANT DISTRIBUTION, AIR-COOLED ALTERNATOR AND REGULATOR
10200429	FOOTBOARDS, OPERATOR
10200442	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2)
10200446	ROCKER ARM ASSEMBLY AND PUSHRODS COOLING SYSTEM, ENGINE, TWIN-COOLED™ COOLING SYSTEM, ENGINE, AIR-COOLED
10200463	ENGINE MOUNTS AND STABILIZER LINK
10200503	ROCKER ARM ASSEMBLY AND PUSHRODS
10200533	SADDLEBAGS (1 OF 2)
10200546	FRAME AND JIFFY STAND
10200569	EXHAUST SYSTEM
10264	CLUTCH CONTROL FRAME AND JIFFY STAND
10318	COOLANT DISTRIBUTION, TWIN-COOLED™ COOLANT DISTRIBUTION, AIR-COOLED
10334	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
10340B	BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
10344	COOLANT DISTRIBUTION, TWIN-COOLED™ COOLANT DISTRIBUTION, AIR-COOLED RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
10354	COOLANT DISTRIBUTION, AIR-COOLED

10395	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
10396	FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC
10400034	SADDLEBAGS (1 OF 2) GUARDS, SADDLEBAG
10500015	FENDERS, FRONT
10500017	FENDERS, REAR (2 OF 2) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
10500022	FORK BRACKETS, FRONT
10500031	BELT, CHAINS AND SPROCKETS
10500036	FORK BRACKETS, FRONT
10500053	FOOTBOARDS, OPERATOR
10500069	ROCKER ARM ASSEMBLY AND PUSHRODS
10600007	BRAKE LINES, FRONT - ABS BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
1062	PRIMARY HOUSING BRAKE LINES AND MODULE, REAR - ABS FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
10800023	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
10800025A	FRAME AND JIFFY STAND
10800028	BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
10800052	COOLING SYSTEM, ENGINE, TWIN-COOLED™ COOLING SYSTEM, ENGINE, AIR-COOLED COOLANT DISTRIBUTION, TWIN-COOLED™ COOLANT DISTRIBUTION, AIR-COOLED RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
10800078	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
10900005	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3) FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
10900009A	GUARDS, SADDLEBAG
10900015	CYLINDERS, HEADS AND VALVES EXHAUST SYSTEM
10900026	SADDLEBAGS - FLHRC
10991A	TRANSMISSION GEARS
11000010	TRANSMISSION BEARINGS AND COVERS
11000050	BRAKE CONTROL, REAR
11000101	SHIFTER, GEAR TRANSMISSION BEARINGS AND COVERS
11000134	CRANKCASE AND ENGINE OIL FILTER
11000139	PRIMARY HOUSING
11036	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
11061A	TRANSMISSION GEARS
11081A	TRANSMISSION GEARS
11082A	TRANSMISSION GEARS
11100038	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
11100050	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)

11100051	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
11100057	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
11100066	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
11100068	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT GUARDS, SADDLEBAG
11100115	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
11100152	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
11100195	LICENSE PLATE BRACKETS
11105	TRANSMISSION HOUSING, TOP COVER AND OIL PAN PRIMARY HOUSING
11120	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
11132A	ROCKER ARM ASSEMBLY AND PUSHRODS TRANSMISSION BEARINGS AND COVERS
11143	CLUTCH
11145A	ROCKER ARM ASSEMBLY AND PUSHRODS
11150	SHIFTER, GEAR
11161	TRANSMISSION BEARINGS AND COVERS
11177A	PISTONS AND FLYWHEEL ASSEMBLY
11201	TRANSMISSION GEARS
11207A	TRANSMISSION GEARS
11289A	SENSORS AND SWITCHES, ENGINE TRANSMISSION HOUSING, TOP COVER AND OIL PAN
11293	ROCKER ARM ASSEMBLY AND PUSHRODS CAMSHAFTS AND CAMSHAFT COVER
11304	FOOTBOARDS AND FOOTPEGS, PASSENGER
11323A	FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC
11389	SHIFTER, GEAR
11437	FENDERS, FRONT
11519	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
11543	ANTENNAS
11575	SHIFTER, GEAR
11599A	TRANSMISSION GEARS
11600001	BRAKE LINES, FRONT - ABS BRAKE LINES AND MODULE, REAR - ABS
11600009	BRAKE LINES, FRONT - ABS BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
11650	COVERS AND AIR DEFLECTORS
11668	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
11686	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC

11687	FENDERS, REAR (1 OF 2)
11692	COOLANT DISTRIBUTION, TWIN-COOLED™ COOLANT DISTRIBUTION, AIR-COOLED
11700005	FAIRING LOWERS, AIR COOLED - FLHTCU
11779	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)
11843	BELT, CHAINS AND SPROCKETS WHEELS, REAR
11848	WHEELS, REAR
11891	FENDERS, REAR (1 OF 2)
11900010	CRANKCASE AND ENGINE OIL FILTER SENSORS AND SWITCHES, ENGINE
11900021	BRAKE CONTROL, REAR
11900090	COOLING SYSTEM, ENGINE, TWIN-COOLED™ COOLING SYSTEM, ENGINE, AIR-COOLED
11900092	COOLING SYSTEM, ENGINE, AIR-COOLED TRANSMISSION BEARINGS AND COVERS
11900103	CAMSHAFTS AND CAMSHAFT COVER
11900116	ROCKER ARM ASSEMBLY AND PUSHRODS
11902	BRAKE CONTROL, REAR
11936	EXHAUST SYSTEM
12000005	FAIRING LOWERS, AIR COOLED - FLHTCU
12052A	PRIMARY HOUSING
12074	TRANSMISSION BEARINGS AND COVERS
12077	TRANSMISSION GEARS
12100007	BRAKE LINES AND MODULE, REAR - ABS
12100017	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
12100018	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
12100020	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
12100023	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
12100034	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
12100069	INDUCTION MODULE, FUEL
12100077	CLUTCH CONTROL
12100113	COOLANT DISTRIBUTION, AIR-COOLED
12102	BRAKE CONTROL, REAR
12200025	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
12200064	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
12200092	FENDERS, FRONT
12200147A	FRAME AND JIFFY STAND

12400034	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
12400099	CRANKCASE AND ENGINE OIL FILTER
12400100	LICENSE PLATE BRACKETS
12500002	WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
12500014	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
12500018	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
12600016	COOLANT DISTRIBUTION, AIR-COOLED
12600031	FOOTBOARDS AND FOOTPEGS, PASSENGER
12600032	HANDLEBAR
12600049	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
12600067	FRAME AND JIFFY STAND INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS
12600070	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
12600071	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
12600073	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
12600197	FRAME AND JIFFY STAND
12700090	COOLANT DISTRIBUTION, AIR-COOLED
12700091	COOLANT DISTRIBUTION, TWIN-COOLED™
1332	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
13729-16	LABELS
13729-17	LABELS
14000827	FRAME AND JIFFY STAND LABELS
14100073	FUEL TANK TRIM
14100074	FUEL TANK TRIM

14100075	FUEL TANK TRIM
14100076	FUEL TANK TRIM
14100079	FUEL TANK TRIM
14100080	FUEL TANK TRIM
14100083	INTERCOM CONTROL POD
14100085	INTERCOM CONTROL POD
14100087	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
14100158	SWITCHES
14100230	FENDERS, FRONT
14100231	FENDERS, FRONT
14100232	FENDERS, FRONT
14100254	SADDLEBAGS - FLHRC
14100279	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2)
14100587	FUEL TANK TRIM
14100588	FUEL TANK TRIM
14100615	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2)
14100764	HORN
14100765	FUEL TANK TRIM
14100766	FUEL TANK TRIM
14100855	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2)
14148-86	LABELS
14263-04	BATTERY LABELS
14272-06	LABELS
15341-08	INTERCOM CONTROL POD
15342-06A	LABELS
15346-98A	NACELLE AND HEADLAMP - FLHR AND FLHRC
15368-01A	BATTERY LABELS
15370-01A	LABELS
15385-08	LABELS
16200248	ENGINE ASSEMBLY, AIR-COOLED
16200249	ENGINE ASSEMBLY, TWIN-COOLED™
16200265	ENGINE ASSEMBLY, AIR-COOLED ENGINE ASSEMBLY, TWIN-COOLED™
16219-09	ENGINE MOUNTS AND STABILIZER LINK
16300005	ENGINE MOUNTS AND STABILIZER LINK
16400005	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
16400041	ENGINE MOUNTS AND STABILIZER LINK
16400042	ENGINE MOUNTS AND STABILIZER LINK
16400049	INDUCTION MODULE, FUEL
16500326	CYLINDERS, HEADS AND VALVES
16500332	CYLINDERS, HEADS AND VALVES
16500388	CYLINDERS, HEADS AND VALVES
16500393	CYLINDERS, HEADS AND VALVES
16500498	CYLINDERS, HEADS AND VALVES
16500508	CYLINDERS, HEADS AND VALVES

16574-99A	CRANKCASE AND ENGINE OIL FILTER TRANSMISSION HOUSING, TOP COVER AND OIL PAN
16583-00A	TRANSMISSION BEARINGS AND COVERS PRIMARY HOUSING
16589-99A	CYLINDERS, HEADS AND VALVES CRANKCASE AND ENGINE OIL FILTER CAMSHAFTS AND CAMSHAFT COVER
16800063	CYLINDERS, HEADS AND VALVES
16800095	CYLINDERS, HEADS AND VALVES
16800100	CYLINDERS, HEADS AND VALVES
17300053	ROCKER ARM ASSEMBLY AND PUSHRODS
17300055	ROCKER ARM ASSEMBLY AND PUSHRODS
17300059	ROCKER ARM ASSEMBLY AND PUSHRODS
17369-06	PRIMARY HOUSING
1775	PRIMARY HOUSING
17900030	ROCKER ARM ASSEMBLY AND PUSHRODS
17900031	ROCKER ARM ASSEMBLY AND PUSHRODS
17900034	ROCKER ARM ASSEMBLY AND PUSHRODS
17900035	ROCKER ARM ASSEMBLY AND PUSHRODS
17945-36B	ROCKER ARM ASSEMBLY AND PUSHRODS
17947-36	ROCKER ARM ASSEMBLY AND PUSHRODS
17948-99	ROCKER ARM ASSEMBLY AND PUSHRODS
17968-99	ROCKER ARM ASSEMBLY AND PUSHRODS
18000016	CYLINDERS, HEADS AND VALVES
18000034	CYLINDERS, HEADS AND VALVES
18100043	CYLINDERS, HEADS AND VALVES
18100044	CYLINDERS, HEADS AND VALVES
18100045	CYLINDERS, HEADS AND VALVES
18100060	CYLINDERS, HEADS AND VALVES
18400073	CYLINDERS, HEADS AND VALVES
18538-99C	ROCKER ARM ASSEMBLY AND PUSHRODS
21900049	PISTONS AND FLYWHEEL ASSEMBLY
22000031	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
22000060	PISTONS AND FLYWHEEL ASSEMBLY
22097-99	PISTONS AND FLYWHEEL ASSEMBLY
221	TRANSMISSION BEARINGS AND COVERS
22100006	PISTONS AND FLYWHEEL ASSEMBLY
24100057	PISTONS AND FLYWHEEL ASSEMBLY
24100080	CRANKCASE AND ENGINE OIL FILTER
24400120	CRANKCASE AND ENGINE OIL FILTER
24400180	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
24400215	TRANSMISSION BEARINGS AND COVERS
2445	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
2446	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
2452	WINDSHIELD - FLHR AND FLHRC

24605-07	CRANKCASE AND ENGINE OIL FILTER
24754-75A	PRIMARY HOUSING
2478	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
2479	BRAKE CONTROL, REAR
2482	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
2531	FENDERS, FRONT
25400103	CAMSHAFTS AND CAMSHAFT COVER
25400133	CAMSHAFTS AND CAMSHAFT COVER
25400190	CAMSHAFTS AND CAMSHAFT COVER
25400257	CAMSHAFTS AND CAMSHAFT COVER
25500013	CAMSHAFTS AND CAMSHAFT COVER
25566-06	CAMSHAFTS AND CAMSHAFT COVER
25600042	CAMSHAFTS AND CAMSHAFT COVER
25600049	CAMSHAFTS AND CAMSHAFT COVER
2563	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3) FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
25673-06	CAMSHAFTS AND CAMSHAFT COVER
25675-06	CAMSHAFTS AND CAMSHAFT COVER
25700178	TRANSMISSION BEARINGS AND COVERS
25700362	ROCKER ARM ASSEMBLY AND PUSHRODS
25700367	CAMSHAFTS AND CAMSHAFT COVER
25700370	CAMSHAFTS AND CAMSHAFT COVER
25700372	ROCKER ARM ASSEMBLY AND PUSHRODS
25700378	PRIMARY HOUSING
25700388	PRIMARY HOUSING
25700409	ROCKER ARM ASSEMBLY AND PUSHRODS
25700410	ROCKER ARM ASSEMBLY AND PUSHRODS
25700411	ROCKER ARM ASSEMBLY AND PUSHRODS
25700414	ROCKER ARM ASSEMBLY AND PUSHRODS
25700418	PRIMARY HOUSING
25700425	ROCKER ARM ASSEMBLY AND PUSHRODS
25700433	CRANKCASE AND ENGINE OIL FILTER
25700452	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
25700453	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
25700455	PRIMARY HOUSING
25700488	ROCKER ARM ASSEMBLY AND PUSHRODS
25700489	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
25700650	PRIMARY HOUSING
25700729	CYLINDERS, HEADS AND VALVES
25700730	CYLINDERS, HEADS AND VALVES
25700731	ROCKER ARM ASSEMBLY AND PUSHRODS CAMSHAFTS AND CAMSHAFT COVER

25700746	PRIMARY HOUSING
25729-06	CAMSHAFTS AND CAMSHAFT COVER
25731-06	CAMSHAFTS AND CAMSHAFT COVER
25734-06	CAMSHAFTS AND CAMSHAFT COVER
25736-06	CAMSHAFTS AND CAMSHAFT COVER
25737-06	CAMSHAFTS AND CAMSHAFT COVER
25738-06	CAMSHAFTS AND CAMSHAFT COVER
25800048	TRANSMISSION BEARINGS AND COVERS
25800049	TRANSMISSION BEARINGS AND COVERS
25800054	TRANSMISSION BEARINGS AND COVERS
25800056	TRANSMISSION BEARINGS AND COVERS
25800057	TRANSMISSION BEARINGS AND COVERS
25800109	TRANSMISSION BEARINGS AND COVERS
25800110	TRANSMISSION BEARINGS AND COVERS
26210-99	CAMSHAFTS AND CAMSHAFT COVER
26352-95A	CRANKCASE AND ENGINE OIL FILTER
2647B	NACELLE AND HEADLAMP - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) SWITCHES
26600048	COOLANT DISTRIBUTION, TWIN-COOLED™
26780-05A	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26800005	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26800006	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26800007A	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26800008	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
26800009	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
26800019A	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26800020A	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26800021	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26800077	COOLANT DISTRIBUTION, TWIN-COOLED™
26800092	COOLANT DISTRIBUTION, AIR-COOLED
26900008	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900009	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900010	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900014	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900016	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900017	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900018	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900088	COOLANT DISTRIBUTION, TWIN-COOLED™
26900114	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900115	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
26900117	COOLING SYSTEM, ENGINE, TWIN-COOLED™ COOLING SYSTEM, ENGINE, AIR-COOLED
26900133	COOLING SYSTEM, ENGINE, TWIN-COOLED™
2692WB	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
2708A	FRAME AND JIFFY STAND

	FOOTBOARDS AND FOOTPEGS, PASSENGER HANDLEBAR
27200025	INDUCTION MODULE, FUEL
2724	TOUR-PAK (BOTTOM)
27291-09A	FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC EVAPORATIVE EMISSIONS COMPONENTS
27297-09A	EVAPORATIVE EMISSIONS COMPONENTS
27298-09A	EVAPORATIVE EMISSIONS COMPONENTS
27300082	INDUCTION MODULE, FUEL
27300086	INDUCTION MODULE, FUEL
27300087	INDUCTION MODULE, FUEL
27300121	INDUCTION MODULE, FUEL
27300122	INDUCTION MODULE, FUEL
2731W	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
27400015	INDUCTION MODULE, FUEL
27400019	INDUCTION MODULE, FUEL
27440-09A	FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC
27444-00Y	STARTER MOTOR
27715-07	EVAPORATIVE EMISSIONS COMPONENTS
27809-10	EXHAUST SYSTEM
29000106	AIR CLEANER
29000108	AIR CLEANER
29000120	AIR CLEANER
29000121	AIR CLEANER
29000216	AIR CLEANER
29108-08	AIR CLEANER LABELS
29200003	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
29200007	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
29200034	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
29200035	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
29200039	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
29200041BYM	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200041DH	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200061	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200062	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200063	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200071	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200072	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200073	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200075	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200078	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200080	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
29200081	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)

2921	WINDSHIELD - FLHR AND FLHRC
29269-83A	AIR CLEANER
2933	NACELLE AND HEADLAMP - FLHR AND FLHRC
29400183	ROCKER ARM ASSEMBLY AND PUSHRODS
29400210	ROCKER ARM ASSEMBLY AND PUSHRODS
29400211	AIR CLEANER
29400212	AIR CLEANER
29465-08A	INDUCTION MODULE, FUEL AIR CLEANER
2952A	SEATS
2968	TOUR-PAK (BOTTOM)
29900038	ALTERNATOR AND REGULATOR
29900041	CRANKCASE AND ENGINE OIL FILTER ALTERNATOR AND REGULATOR
29900042	ALTERNATOR AND REGULATOR
2995	FENDERS, REAR (1 OF 2) FAIRING LOWERS, AIR COOLED - FLHTCU
3022A	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
3050	ALTERNATOR AND REGULATOR
3057	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
3061	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
3088	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
31400053	STARTER MOTOR
3143	FOOTBOARDS AND FOOTPEGS, PASSENGER
3152	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
31586-07	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
31600012	ELECTRONIC CONTROL MODULE (ECM) AND COIL
31600017	ELECTRONIC CONTROL MODULE (ECM) AND COIL
31600018	ELECTRONIC CONTROL MODULE (ECM) AND COIL
31600023	ELECTRONIC CONTROL MODULE (ECM) AND COIL
31600078	ELECTRONIC CONTROL MODULE (ECM) AND COIL
31600079	ELECTRONIC CONTROL MODULE (ECM) AND COIL
3225	NACELLE AND HEADLAMP - FLHR AND FLHRC
32306-08	THROTTLE CONTROL
3249	TRANSMISSION BEARINGS AND COVERS
3265A	NACELLE AND HEADLAMP - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC

	WINDSHIELD - FLHR AND FLHRC
32700010	SWITCHES
32700015	WHEELS, FRONT
32700017	WHEELS, FRONT
32700046	EXHAUST SYSTEM
32700048	SENSORS AND SWITCHES, ENGINE
32700050	THROTTLE CONTROL
32700054	SENSORS AND SWITCHES, ENGINE
32700065	INDUCTION MODULE, FUEL SENSORS AND SWITCHES, ENGINE
32700066	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
3275	INDUCTION MODULE, FUEL SENSORS AND SWITCHES, ENGINE SHIFTER, GEAR
33085-74	FOOTBOARDS AND FOOTPEGS, PASSENGER
33389-07	SHIFTER, GEAR
33409-06B	SHIFTER, GEAR
33600088	SHIFTER, GEAR
33600091	SHIFTER, GEAR
33719-79B	SHIFTER, GEAR
33895-82D	SHIFTER, GEAR
33900172	SHIFTER, GEAR
33900175	SHIFTER, GEAR
33926-06B	TRANSMISSION HOUSING, TOP COVER AND OIL PAN SWITCHES
34064-00C	SHIFTER, GEAR
34091-08	TRANSMISSION GEARS
34611-65A	SHIFTER, GEAR
34700084	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
34800025	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
34800038	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
34987-06	SHIFTER, GEAR
35000152	BELT, CHAINS AND SPROCKETS
35000198	SHIFTER, GEAR TRANSMISSION GEARS
35081-06	SHIFTER, GEAR
35082-07	SHIFTER, GEAR TRANSMISSION BEARINGS AND COVERS
35087-99A	TRANSMISSION BEARINGS AND COVERS
35114-02	CRANKCASE AND ENGINE OIL FILTER
35122-06	TRANSMISSION GEARS
35124-06	TRANSMISSION GEARS
35126-06	TRANSMISSION GEARS
3514	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
35186-06	SHIFTER, GEAR TRANSMISSION BEARINGS AND COVERS
35187-06	SHIFTER, GEAR

35200021	CRANKCASE AND ENGINE OIL FILTER
35200027	PISTONS AND FLYWHEEL ASSEMBLY
35201-10	TRANSMISSION GEARS
35202-06	TRANSMISSION GEARS
35204-06	TRANSMISSION GEARS
35210-06	SHIFTER, GEAR
35217-06	SHIFTER, GEAR
35222-06	SHIFTER, GEAR
35223-06	SHIFTER, GEAR
35241-06	BELT, CHAINS AND SPROCKETS
35242-06	BELT, CHAINS AND SPROCKETS
35243-06	SHIFTER, GEAR
35244-06	SHIFTER, GEAR
35249-06A	SHIFTER, GEAR
35259-06	SHIFTER, GEAR
35260-06B	TRANSMISSION BEARINGS AND COVERS
3536	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
35467-06B	TRANSMISSION GEARS
35470-10	TRANSMISSION GEARS
35600103	TRANSMISSION GEARS
3560WA	FENDERS, FRONT
3561WC	FENDERS, FRONT
3563	BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS HORN
35654-06	TRANSMISSION BEARINGS AND COVERS
3576	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
35801-10	TRANSMISSION GEARS
35807-06	TRANSMISSION GEARS
35811-06	TRANSMISSION GEARS
35814-06	TRANSMISSION GEARS
3588	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
3594	BELT, CHAINS AND SPROCKETS FRAME AND JIFFY STAND
3601	GUARDS, SADDLEBAG
3607	SHOCK ABSORBERS, REAR
3612	FENDERS, FRONT LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
3622	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
3634	ELECTRONIC CONTROL MODULE (ECM) AND COIL FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC BATTERY
36500052	PRIMARY HOUSING
36500075	PRIMARY HOUSING
3655A	WHEELS, FRONT FAIRING LOWERS, AIR COOLED - FLHTCU

	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
3656	SADDLEBAGS (1 OF 2)
36700113	CLUTCH CONTROL
36700128	CLUTCH CONTROL
36700130	CLUTCH CONTROL
36700131	CLUTCH CONTROL
36700132	CLUTCH CONTROL
36700133	CLUTCH CONTROL
36706-01K	CLUTCH
36731-91	CLUTCH
3676	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
36805-06	TRANSMISSION BEARINGS AND COVERS
3684	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT FENDERS, REAR (1 OF 2) GUARDS, SADDLEBAG GUARDS, SADDLEBAG
3699D	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
37000032A	CLUTCH
37000033	CLUTCH
37000034	CLUTCH
37000036	CLUTCH
37000083	CLUTCH
37000168	CLUTCH
37000169	CLUTCH
37000217	CLUTCH
37000218	CLUTCH
37000219	CLUTCH
37000254	CLUTCH
37000258	CLUTCH
37000270	CLUTCH
37065-06A	TRANSMISSION BEARINGS AND COVERS
37200128	CLUTCH CONTROL
37200129	CLUTCH CONTROL
37200131	TRANSMISSION BEARINGS AND COVERS
37200146	CLUTCH CONTROL
37496-90A	CLUTCH
3767B	TOUR-PAK (BOTTOM) LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
3787	COVERS AND AIR DEFLECTORS COVERS AND AIR DEFLECTORS FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
37904-90	CLUTCH
37909-90	CLUTCH
38722-94	WINDSHIELD - FLHR AND FLHRC
3892	BELT, CHAINS AND SPROCKETS
3901	SEATS
3910	TOUR-PAK (BOTTOM)

3929	EXHAUST SYSTEM
3976	ROCKER ARM ASSEMBLY AND PUSHRODS
3983	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
3987	FRAME AND JIFFY STAND TURN SIGNALS, FRONT - FLHX AND FLHXS
40024-09A	BELT, CHAINS AND SPROCKETS
40037-07	BELT, CHAINS AND SPROCKETS
40100041	BELT, CHAINS AND SPROCKETS
40100064	BELT, CHAINS AND SPROCKETS
40100076	BELT, CHAINS AND SPROCKETS
40217-09	BELT, CHAINS AND SPROCKETS WHEELS, REAR
40278-09	BELT, CHAINS AND SPROCKETS WHEELS, REAR
40558-82	WHEELS, FRONT
40592-09	WHEELS, REAR
40615-08	WHEELS, REAR
40900026	WHEELS, REAR
40900033	WHEELS, REAR
40900391	WHEELS, REAR
40901-05	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
40960-09	WHEELS, FRONT
40999-87	WHEELS, FRONT WHEELS, REAR
41000307	ELECTRONIC CONTROL MODULE (ECM) AND COIL
41000341A	SWITCHES
41000342A	SWITCHES
41000351A	SWITCHES
41052-09	WHEELS, REAR
41100061	BRAKE LINES AND MODULE, REAR - ABS
41123-79	WHEELS, FRONT WHEELS, REAR
41229-08	WHEELS, REAR
41242-08	WHEELS, REAR
4132	CLUTCH CONTROL BRAKE CONTROL, FRONT
41349-07	WHEELS, REAR
41445-09	WHEELS, REAR
41500017	WHEELS, FRONT
41500018	WHEELS, FRONT
41500019	WHEELS, FRONT
41500020	WHEELS, FRONT
41547-07A	WHEELS, FRONT
41600029A	BRAKE LINE, FRONT - NON-ABS BRAKE LINES, FRONT - ABS FORK BRACKETS, FRONT
41600031	CLUTCH CONTROL BRAKE LINES, FRONT - ABS

41600032	BRAKE LINES, FRONT - ABS
41600078	BRAKE LINES AND MODULE, REAR - ABS
41600091	BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
41700028	BRAKE CONTROL, REAR
41700195	BRAKE CONTROL, REAR
41700321	BRAKE CONTROL, FRONT
41700367	CLUTCH CONTROL BRAKE CONTROL, FRONT
41746-09	WHEELS, REAR
41750-06B	CLUTCH CONTROL BRAKE CONTROL, FRONT BRAKE LINE, FRONT - NON-ABS BRAKE LINES, FRONT - ABS BRAKE CONTROL, REAR BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
41751-06A	CLUTCH CONTROL BRAKE CONTROL, FRONT BRAKE LINE, FRONT - NON-ABS BRAKE LINES, FRONT - ABS BRAKE CONTROL, REAR BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
41783-08	BRAKE LINE, FRONT - NON-ABS BRAKE LINES, FRONT - ABS
41800011	BRAKE LINES, FRONT - ABS
41800012	BRAKE CONTROL, REAR BRAKE LINES AND MODULE, REAR - ABS
41800174	BRAKE LINE, FRONT - NON-ABS
41800175	BRAKE CONTROL, REAR
41800314	BRAKE LINES, FRONT - ABS
41800340	BRAKE LINE, FRONT - NON-ABS
41800510	BRAKE LINES, FRONT - ABS
41800541	BRAKE LINES AND MODULE, REAR - ABS
41800542	BRAKE LINES, FRONT - ABS
41800543	BRAKE LINES, FRONT - ABS
41800544	BRAKE LINES, FRONT - ABS
41800545	BRAKE LINES, FRONT - ABS
41800546	BRAKE LINES, FRONT - ABS
41800547	BRAKE LINES, FRONT - ABS
41808-08A	WHEELS, FRONT
41809-08A	WHEELS, FRONT
41810-08B	WHEELS, REAR
41819-02	WHEELS, REAR
41852-08B	BRAKE CALIPER, REAR
41854-08	BRAKE CALIPER, FRONT
41900-08	WHEELS, FRONT
41901-08	WHEELS, FRONT WHEELS, FRONT

4194	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
42018-09	WHEELS, REAR
4240	FORK BRACKETS, FRONT HANDLEBAR
42410-04	BRAKE CONTROL, REAR
42416-06	BRAKE CONTROL, REAR
42444-04	BRAKE CONTROL, REAR
42460-80B	BRAKE CONTROL, REAR
42849-08	BRAKE CALIPER, FRONT
42851-06	BRAKE CALIPER, FRONT
42852-06A	BRAKE CALIPER, FRONT
42853-06	BRAKE LINE, FRONT - NON-ABS BRAKE LINES, FRONT - ABS BRAKE CALIPER, REAR
42854-06	BRAKE CONTROL, FRONT BRAKE CONTROL, REAR
42855-06C	BRAKE CONTROL, FRONT
42856-06	CLUTCH CONTROL BRAKE CONTROL, FRONT
42857-06B	BRAKE CONTROL, FRONT
42858-06A	CLUTCH CONTROL BRAKE CONTROL, FRONT BRAKE CONTROL, REAR
42859-06B	BRAKE CONTROL, FRONT
42860-06B	CLUTCH CONTROL BRAKE CONTROL, FRONT
42861-06B	BRAKE CONTROL, FRONT
42862-06B	BRAKE CONTROL, FRONT
42863-06	BRAKE CALIPER, REAR
42865-06B	BRAKE CALIPER, REAR
42867-06A	BRAKE CALIPER, REAR
42889-06	BRAKE CONTROL, REAR
42932-08A	BRAKE CONTROL, REAR
42934-08	BRAKE CONTROL, REAR
42937-08B	BRAKE CONTROL, REAR
43000002	WHEELS, REAR
43027-08	BRAKE CALIPER, FRONT
43085-97	WHEELS, FRONT
43099-09	WHEELS, REAR
43100013	WHEELS, FRONT
43109-09A	WHEELS, FRONT
43118-92A	WHEELS, FRONT
4312C	BATTERY
43147-40	WHEELS, FRONT
43200027	WHEELS, REAR
43230-09	WHEELS, REAR
43241-05	WHEELS, FRONT

43300019	WHEELS, FRONT
43300027	WHEELS, FRONT
43300386	WHEELS, FRONT
43567-92	WHEELS, REAR
44023-08	BRAKE CALIPER, FRONT
44080-08C	BRAKE CALIPER, REAR
44089-08	BRAKE CALIPER, REAR
44160-00	BRAKE CALIPER, FRONT
4419	STARTER MOTOR
44341-08	BRAKE CALIPER, FRONT
44551-08E	BRAKE CONTROL, FRONT
45041-01A	FOOTBOARDS AND FOOTPEGS, PASSENGER
45138-08A	CLUTCH CONTROL BRAKE CONTROL, FRONT
45400102	FORK, FRONT, LEFT AND RIGHT - STANDARD
45400103	FORK, FRONT, LEFT AND RIGHT - STANDARD
45400104	FORK, FRONT, LEFT AND RIGHT - LOW
45400105	FORK, FRONT, LEFT AND RIGHT - LOW
45400181	FORK, FRONT, LEFT AND RIGHT - STANDARD
45400182	FORK, FRONT, LEFT AND RIGHT - STANDARD
45500109	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500111	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500117	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500118	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500132	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500337	FORK, FRONT, LEFT AND RIGHT - STANDARD
45500338	FORK, FRONT, LEFT AND RIGHT - LOW
45500339	FORK, FRONT, LEFT AND RIGHT - STANDARD
45500340	FORK, FRONT, LEFT AND RIGHT - LOW
45500341	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500396	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500397	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500398	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500421	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500424	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
45500456	FORK, FRONT, LEFT AND RIGHT - STANDARD
45600003	FORK BRACKETS, FRONT
45700009	FORK BRACKETS, FRONT

	FRAME AND JIFFY STAND
45700020A	FORK BRACKETS, FRONT
45800023	FORK BRACKETS, FRONT
45900024	FORK BRACKETS, FRONT
45900091A	FORK BRACKETS, FRONT
4597M	BRAKE CALIPER, REAR
4612	EVAPORATIVE EMISSIONS COMPONENTS FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
46508-01	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
46509-01	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
46513-01	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
46514-01A	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
46515-01	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
46615-06	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
4688	ENGINE MOUNTS AND STABILIZER LINK FRAME AND JIFFY STAND FOOTBOARDS, OPERATOR
4694	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
47000088BHP	FRAME AND JIFFY STAND
4705	COOLING SYSTEM, ENGINE, AIR-COOLED ELECTRONIC CONTROL MODULE (ECM) AND COIL SENSORS AND SWITCHES, ENGINE TRANSMISSION BEARINGS AND COVERS TRANSMISSION HOUSING, TOP COVER AND OIL PAN EXHAUST SYSTEM BATTERY
4706	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
4718A	TRANSMISSION BEARINGS AND COVERS
47200080	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
47200081	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
47200217	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
47200261	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
47200262	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
47200266	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
47200275	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
47200302A	FOOTBOARDS, OPERATOR
4740A	CAMSHAFTS AND CAMSHAFT COVER
4741A	ROCKER ARM ASSEMBLY AND PUSHRODS TRANSMISSION BEARINGS AND COVERS TRANSMISSION HOUSING, TOP COVER AND OIL PAN WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
47540-11	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
47549-09A	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
47584-09	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT

4775	HORN
4790	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
48079-09BHP	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
4813A	ELECTRONIC CONTROL MODULE (ECM) AND COIL PRIMARY HOUSING
4816A	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
4820A	PRIMARY HOUSING
4822A	CAMSHAFTS AND CAMSHAFT COVER
48487-02	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
48489-02	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
4856	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
4867	ANTENNAS
4890	TRANSMISSION BEARINGS AND COVERS BRAKE LINE, FRONT - NON-ABS BRAKE LINES, FRONT - ABS BRAKE CALIPER, REAR
4916	FOOTBOARDS AND FOOTPEGS, PASSENGER
49184-09A	FRAME AND JIFFY STAND
4924	FRAME AND JIFFY STAND SEATS GUARDS, SADDLEBAG GUARDS, SADDLEBAG
49725-07A	FRAME AND JIFFY STAND
50000083	FRAME AND JIFFY STAND
50000097	FRAME AND JIFFY STAND
50000141A	FRAME AND JIFFY STAND
50015-74A	FRAME AND JIFFY STAND
50075-07A	FRAME AND JIFFY STAND
50126-08A	FRAME AND JIFFY STAND
50208-04	FOOTBOARDS AND FOOTPEGS, PASSENGER
50245-07	FRAME AND JIFFY STAND
50345-04	FOOTBOARDS AND FOOTPEGS, PASSENGER
50350-04	FOOTBOARDS AND FOOTPEGS, PASSENGER
50500143	FOOTBOARDS AND FOOTPEGS, PASSENGER
50500145	FOOTBOARDS AND FOOTPEGS, PASSENGER
50500146	FOOTBOARDS AND FOOTPEGS, PASSENGER
50500332A	FOOTBOARDS AND FOOTPEGS, PASSENGER
50500334A	FOOTBOARDS AND FOOTPEGS, PASSENGER
50500339	FOOTBOARDS, OPERATOR
50500360	FOOTBOARDS, OPERATOR
50500460A	FOOTBOARDS AND FOOTPEGS, PASSENGER
50500462A	FOOTBOARDS AND FOOTPEGS, PASSENGER
50518-09	FOOTBOARDS, OPERATOR
50600067	BRAKE CONTROL, REAR
50606-06	FOOTBOARDS AND FOOTPEGS, PASSENGER
50613-91A	FOOTBOARDS AND FOOTPEGS, PASSENGER
50614-06	FOOTBOARDS, OPERATOR

50621-06	FOOTBOARDS, OPERATOR
50622-09A	FOOTBOARDS, OPERATOR
50674-05	FOOTBOARDS, OPERATOR
50683-04	FOOTBOARDS, OPERATOR
50684-11	FOOTBOARDS, OPERATOR
50688-04	FOOTBOARDS, OPERATOR
50689-11	FOOTBOARDS, OPERATOR
50899-99A	FOOTBOARDS AND FOOTPEGS, PASSENGER
50912-72	FOOTBOARDS AND FOOTPEGS, PASSENGER
50933-86A	FOOTBOARDS AND FOOTPEGS, PASSENGER
5118	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS TURN SIGNALS, FRONT - FLHX AND FLHXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) SWITCHES, HANDLEBAR, RIGHT WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
515	BRAKE CONTROL, REAR
52000033	SEATS
52000038	SEATS
52000060	SEATS
52000122	SEATS
52000142	SEATS
52000173	SEATS
52000174	SEATS
5210	NACELLE AND HEADLAMP - FLHR AND FLHRC LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
5211	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
52300053	SEATS LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
52300121	SEATS
52300122	SEATS
52300123	SEATS
52300127	SEATS
52320-11	SEATS
52400015	SEATS
52400016	SEATS
52400017	SEATS
52400018	SEATS
52400021	SEATS
52400054	SEATS
52400067	SEATS
52400099	SEATS

52400116	SEATS
52441-95	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
52719-10	FOOTBOARDS AND FOOTPEGS, PASSENGER
53000090	TOUR-PAK (COVER)
53000091	TOUR-PAK (BOTTOM)
53000123	TOUR-PAK (BOTTOM)
53000124	TOUR-PAK (BOTTOM)
53000125	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
53000132	TOUR-PAK (BOTTOM)
53000137	TOUR-PAK (COVER)
53000138	TOUR-PAK (BOTTOM)
53000139	TOUR-PAK (BOTTOM) TOUR-PAK (COVER)
53000140	TOUR-PAK (BOTTOM) TOUR-PAK (COVER)
53000141	TOUR-PAK (COVER)
53000308	TOUR-PAK (BOTTOM)
53000311	TOUR-PAK (BOTTOM) LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
53000346	TOUR-PAK (BOTTOM)
53000347	TOUR-PAK (COVER)
53000370	TOUR-PAK (COVER)
53436-97	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
53598-88A	TOUR-PAK (BOTTOM) LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
53665-87	TOUR-PAK (COVER)
53734-06	TOUR-PAK (BOTTOM)
53735-06	TOUR-PAK (BOTTOM)
53788-06	TOUR-PAK (BOTTOM)
53789-06	TOUR-PAK (BOTTOM)
53919-04A	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
54000093	SHOCK ABSORBERS, REAR
54000094	SHOCK ABSORBERS, REAR
54000095	SHOCK ABSORBERS, REAR
54000096	SHOCK ABSORBERS, REAR
54000113	SHOCK ABSORBERS, REAR
54000114	SHOCK ABSORBERS, REAR
54000141	SHOCK ABSORBERS, REAR
54321-85	WHEELS, FRONT WHEELS, REAR
54395-10	SEATS
55800091	NACELLE AND HEADLAMP - FLHR AND FLHRC
55800099	HANDLEBAR
55800305	HANDLEBAR
55800332	HANDLEBAR

55800436	HANDLEBAR
55900071	HANDLEBAR
55900078	HANDLEBAR
55900079	HANDLEBAR
55918-08	HANDLEBAR
55924-14	HANDLEBAR
56000011	MIRRORS
56000012	MIRRORS
56000015	MIRRORS
56000016	MIRRORS
56100075	THROTTLE CONTROL
56159-73	HANDLEBAR
56161-83A	HANDLEBAR
56163-93	HANDLEBAR
56209-10	THROTTLE CONTROL
56248-08	THROTTLE CONTROL
56249-10	THROTTLE CONTROL
56250-10	THROTTLE CONTROL
56304-08	THROTTLE CONTROL
56667-04	THROTTLE CONTROL
57000017	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
57000064BYM	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
57000064DH	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
57000065BYM	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
57000065DH	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
57000169	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
57000170	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
57000172	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
57000175	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
57000186	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
57000299	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
57000302	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
57000305	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
57000374BYM	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
57000377	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
57000383	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
57000412	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
57000501	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
57000504	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
57000508	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
57100098	FAIRING LOWERS, AIR COOLED - FLHTCU
57100099	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100101	FAIRING LOWERS, AIR COOLED - FLHTCU
57100102	FAIRING LOWERS, AIR COOLED - FLHTCU
57100103	FAIRING LOWERS, AIR COOLED - FLHTCU
57100104	FAIRING LOWERS, AIR COOLED - FLHTCU

57100107	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100108	FAIRING LOWERS, AIR COOLED - FLHTCU
57100109	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100110	FAIRING LOWERS, AIR COOLED - FLHTCU
57100111	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100112	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100113	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100114	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100147	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100148	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100149	FAIRING LOWERS, AIR COOLED - FLHTCU
57100150	FAIRING LOWERS, AIR COOLED - FLHTCU
57100151	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100152	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100153	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100154	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100155	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100161	FAIRING LOWERS, AIR COOLED - FLHTCU
57100162	FAIRING LOWERS, AIR COOLED - FLHTCU
57100164	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100165	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100166	FAIRING LOWERS, AIR COOLED - FLHTCU
57100167	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2) FAIRING LOWERS, AIR COOLED - FLHTCU
57100170	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100171	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100172	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100187	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100188	FAIRING LOWERS, AIR COOLED - FLHTCU
57100200	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100208	FAIRING LOWERS, AIR COOLED - FLHTCU
57100225	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57100227	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
57100247	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
57100256	FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
57200012	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)

57200017	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
57200063	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
57200064	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
57200065	COVERS AND AIR DEFLECTORS LOOSE PARTS (2 OF 3)
57200066	COVERS AND AIR DEFLECTORS LOOSE PARTS (2 OF 3)
57300063	MIRRORS
57400001	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) LOOSE PARTS (1 OF 3) LOOSE PARTS (1 OF 3)
57400002	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) LOOSE PARTS (1 OF 3)
57400003	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) LOOSE PARTS (3 OF 3) LOOSE PARTS (3 OF 3)
57400004	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) LOOSE PARTS (3 OF 3)
57400005	WINDSHIELD - FLHR AND FLHRC
57400058	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) LOOSE PARTS (1 OF 3) LOOSE PARTS (3 OF 3)
57400187	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
57400191	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
57400250	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) LOOSE PARTS (1 OF 3)
57400260	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
57400262	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
57400302	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
57400303	LOOSE PARTS (2 OF 3)
57400305	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
57400308	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
57400309	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
57450-14	HANDLEBAR
57451-14	HANDLEBAR
57638-08	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3)
57668-10	WINDSHIELD - FLHR AND FLHRC LOOSE PARTS (3 OF 3)
57978-00	TOUR-PAK (BOTTOM)
57994-94	WINDSHIELD - FLHR AND FLHRC WINDSHIELD - FLHR AND FLHRC LOOSE PARTS (3 OF 3)
58002-09A	LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)

	LOOSE PARTS (3 OF 3) LOOSE PARTS (3 OF 3)
58084-94	WINDSHIELD - FLHR AND FLHRC
58088-94	WINDSHIELD - FLHR AND FLHRC
58167-09A	COVERS AND AIR DEFLECTORS COVERS AND AIR DEFLECTORS
58169-09	COVERS AND AIR DEFLECTORS COVERS AND AIR DEFLECTORS
5817	SHIFTER, GEAR
58193-94	WINDSHIELD - FLHR AND FLHRC WINDSHIELD - FLHR AND FLHRC
58325-06	WINDSHIELD - FLHR AND FLHRC LOOSE PARTS (3 OF 3)
58327-06	WINDSHIELD - FLHR AND FLHRC
5837A	TRANSMISSION GEARS
58406-75A	WINDSHIELD - FLHR AND FLHRC
58408-75A	WINDSHIELD - FLHR AND FLHRC
58416-77A	WINDSHIELD - FLHR AND FLHRC
58417-77	WINDSHIELD - FLHR AND FLHRC
58428-94	WINDSHIELD - FLHR AND FLHRC
58431-94	WINDSHIELD - FLHR AND FLHRC
58702-09	FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2)
58888-98A	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
58900009	FENDERS, FRONT
58900032	FENDERS, FRONT
59174-99	FENDERS, REAR (1 OF 2)
59211-74A	FENDERS, FRONT
59259-90	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
59292-94	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
59481-00	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
59482-00	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
59500046	FENDERS, REAR (1 OF 2)
59581-05	FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2)
59600003	FENDERS, FRONT
59600006	FENDERS, FRONT
59600008	FENDERS, REAR (2 OF 2)
59600009	FENDERS, FRONT
59600011	FENDERS, FRONT
59600029	FENDERS, REAR (2 OF 2)
59731-09	FENDERS, REAR (1 OF 2)
59739-09	FENDERS, REAR (1 OF 2)

59749-06	FENDERS, REAR (1 OF 2)
59768-97	SEATS
59778-06	FENDERS, REAR (1 OF 2)
59786-01	FENDERS, REAR (1 OF 2)
59788-01	FENDERS, REAR (1 OF 2)
59818-09	FENDERS, REAR (1 OF 2)
59988-72A	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
601	CAMSHAFTS AND CAMSHAFT COVER
6019	HORN
60254-07	GUARDS, SADDLEBAG
6026	SEATS
60328-98B	TRANSMISSION HOUSING, TOP COVER AND OIL PAN PRIMARY HOUSING
6036	COVERS AND AIR DEFLECTORS COVERS AND AIR DEFLECTORS
60386-09	BELT, CHAINS AND SPROCKETS
6054	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
60575-10	FENDERS, REAR (1 OF 2)
60678-85	PRIMARY HOUSING
6072	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
60800006	EVAPORATIVE EMISSIONS COMPONENTS
60800026	EVAPORATIVE EMISSIONS COMPONENTS
60907-09	LICENSE PLATE BRACKETS
60909-09	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
60918-10A	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
6101	CLUTCH CONTROL BRAKE CONTROL, FRONT
61011-04A	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
61012-04A	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
61015-04A	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
61029-92A	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
61081-92	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC NACELLE AND HEADLAMP - FLHR AND FLHRC SWITCHES TOUR-PAK (BOTTOM)
6109	HORN
61100055	FUEL TANK - FLHR AND FLHRC
61109-85D	FUEL TANK - FLHR AND FLHRC CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
61112-08	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
6113	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
6116	FRAME AND JIFFY STAND

6119	WINDSHIELD - FLHR AND FLHRC
61192-96A	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
61200022	INDUCTION MODULE, FUEL FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC
61213-04A	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
61268-08	FUEL TANK - FLHR AND FLHRC
6127	ENGINE MOUNTS AND STABILIZER LINK
61270-08	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
61272-92C	FUEL TANK - FLHR AND FLHRC
61274-92	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
61278-08A	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
61300095	NACELLE AND HEADLAMP - FLHR AND FLHRC
61300096	NACELLE AND HEADLAMP - FLHR AND FLHRC
61300467	AIR CLEANER
61300501	AIR CLEANER
61300523	HORN
61313-88	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2)
61356-08	FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS
61400057	FENDERS, FRONT
61400063	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
61400064	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
61400077	NACELLE AND HEADLAMP - FLHR AND FLHRC
61400080	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
61400081	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
61400135	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
61400159	NACELLE AND HEADLAMP - FLHR AND FLHRC LOOSE PARTS (3 OF 3)
61400173	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
61400198	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
61402-08	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
6150W	NACELLE AND HEADLAMP - FLHR AND FLHRC SWITCHES
62152-08	FUEL TANK TRIM
62153-08	FUEL TANK TRIM
6220W	BRAKE CONTROL, REAR LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
62228-08C	FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC
62229-08B	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
62241-08	FUEL TANK TRIM LOOSE PARTS (1 OF 3)
62242-08	FUEL TANK TRIM

	LOOSE PARTS (1 OF 3)
62243-08	FUEL TANK TRIM LOOSE PARTS (1 OF 3)
6235	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
62372-09	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
62400052	CAMSHAFTS AND CAMSHAFT COVER
62400055	CAMSHAFTS AND CAMSHAFT COVER
62400121	CAMSHAFTS AND CAMSHAFT COVER
62400124	CAMSHAFTS AND CAMSHAFT COVER
62400125	CAMSHAFTS AND CAMSHAFT COVER
62400126	CAMSHAFTS AND CAMSHAFT COVER
62400132	CAMSHAFTS AND CAMSHAFT COVER
62435-11	FUEL TANK TRIM
62437-11	FUEL TANK TRIM
62519-03	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
62700089	CRANKCASE AND ENGINE OIL FILTER
62700117	CRANKCASE AND ENGINE OIL FILTER
62700136	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
62700141	SENSORS AND SWITCHES, ENGINE
62700143	COOLANT DISTRIBUTION, AIR-COOLED
62700144	COOLANT DISTRIBUTION, AIR-COOLED
62700146	COOLING SYSTEM, ENGINE, AIR-COOLED TRANSMISSION BEARINGS AND COVERS
62700150	TRANSMISSION BEARINGS AND COVERS
62700196	COOLANT DISTRIBUTION, AIR-COOLED
62775-08	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
62800004	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
62800013	CRANKCASE AND ENGINE OIL FILTER SENSORS AND SWITCHES, ENGINE
62800028	COOLING SYSTEM, ENGINE, AIR-COOLED
62908-08	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
6294	CAMSHAFTS AND CAMSHAFT COVER
6333	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
63731-99A	CRANKCASE AND ENGINE OIL FILTER
6416	BRAKE CONTROL, REAR
6421	BRAKE CONTROL, REAR
64900235	EXHAUST SYSTEM
64900236	EXHAUST SYSTEM
64900237	EXHAUST SYSTEM
64900238	EXHAUST SYSTEM
64900239	EXHAUST SYSTEM
64900240	EXHAUST SYSTEM
6497HW	SHIFTER, GEAR
6532	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
65324-83B	EXHAUST SYSTEM

65325-83A	EXHAUST SYSTEM
65328-83A	EXHAUST SYSTEM
65400176	EXHAUST SYSTEM
65400177	EXHAUST SYSTEM
65400178	EXHAUST SYSTEM
65400179	EXHAUST SYSTEM
65500042	EXHAUST SYSTEM
65500043	EXHAUST SYSTEM
65600176	EXHAUST SYSTEM
65600177	EXHAUST SYSTEM
65600178	EXHAUST SYSTEM
65723-85	EXHAUST SYSTEM
65724-85A	EXHAUST SYSTEM
65900012	EXHAUST SYSTEM
65900015	EXHAUST SYSTEM
6590HW	SHOCK ABSORBERS, REAR
6594	WHEELS, FRONT
66000010	BATTERY
66000066	BATTERY
66000116	BATTERY
66010-97C	BATTERY
66048-09A	COVERS AND AIR DEFLECTORS
66051-08	BATTERY
66250-09	COVERS AND AIR DEFLECTORS
66290-06	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
66373-06	SWITCHES
66861-09A	EXHAUST SYSTEM
66881-09	EXHAUST SYSTEM
6702	FRAME AND JIFFY STAND
6703	SEATS FENDERS, REAR (1 OF 2) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) TOUR-PAK (BOTTOM) TOUR-PAK (BOTTOM) TOUR-PAK (COVER) LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
67208-08	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
67266-94	FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
67341-04B	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
67493-08	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
67621-94	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC WINDSHIELD - FLHR AND FLHRC
6762D	ROCKER ARM ASSEMBLY AND PUSHRODS

67700060	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
67700062	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
67700065	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
67700105	NACELLE AND HEADLAMP - FLHR AND FLHRC
67700199	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
67700204	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
67700205	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
67712-83B	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
67716-60C	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
67717-01	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
67721-48	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
67726-08	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
67778-60A	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
67780-60A	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
67800093	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
67800101	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
67800103	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
67800104	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
67800109	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
67800132	TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)
67800147	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
67800148	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
67800254	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
67800299	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
67800300	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
67800301	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (2 OF 2)
67800302	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (2 OF 2)
67800303	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (2 OF 2)
67800471	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (2 OF 2)
67800512	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (2 OF 2)
67800513	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (2 OF 2)
67875-11	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
6789	NACELLE AND HEADLAMP - FLHR AND FLHRC
67900065	SADDLEBAGS (1 OF 2)
67900066	SADDLEBAGS (1 OF 2)
67900067	SADDLEBAGS (1 OF 2)
67900068	SADDLEBAGS (1 OF 2)
67900120	GUARDS, SADDLEBAG

67900213A	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
67900256	SADDLEBAGS (1 OF 2)
67900445	LICENSE PLATE BRACKETS
68000020	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
68000021	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
68000022	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
68000036	TURN SIGNALS, FRONT - FLHX AND FLHXS
68000037	TURN SIGNALS, FRONT - FLHX AND FLHXS
68000038	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
68000056	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68026-99	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
68042-99	CRANKCASE AND ENGINE OIL FILTER
68066-99A	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
68120-00	CAMSHAFTS AND CAMSHAFT COVER
68140-04	TAIL LAMP (1 OF 2)
68142-04	TAIL LAMP (1 OF 2)
68163-84	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68167-04	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
68168-89A	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68245-03	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
68253-08A	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
68296-99A	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
68331-02	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
68369-03	TAIL LAMP (1 OF 2)
68370-03A	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
68414-05A	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68440-86	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68452-86	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68497-07	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68505-90	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68506-92	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)

68519-68A	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68550-09	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68558-03	TAIL LAMP (1 OF 2)
68559-07	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68572-64B	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68629-05	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68712-94A	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68713-94A	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68720-62	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68721-62	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68725-62A	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
68742-09	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68765-94A	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68766-94	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68767-94	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68821-00	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
68830-99A	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
68846-09	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68847-09	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
68881-01	NACELLE AND HEADLAMP - FLHR AND FLHRC WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
68904-00	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS
68905-00	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68956-07	SWITCHES
68958-07C	SWITCHES
68973-00	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
68997-09	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
69000083	HORN
69060-90H	HORN
69062-91A	HORN
69120-91	HORN
69123-92A	HORN
69187-03A	TAIL LAMP (1 OF 2)
69200031	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
69200032	WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
69200109	WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)
69200121	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)

	WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)
69200122	INSTRUMENTS - FLTRU, FLTRX AND FLTRXS WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
69200124	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC WIRING HARNESS, CONSOLE - FLHR AND FLHRC
69200125	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS
69200127	INTERCOM CONTROL POD
69200128	FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) TAIL LAMP (2 OF 2)
69200129	FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)
69200130	FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)
69200131	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200135	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200136	WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
69200138	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200139	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200170	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
69200171	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
69200172	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
69200173	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
69200174	ELECTRONIC CONTROL MODULE (ECM) AND COIL BATTERY
69200175	WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)
69200178	SWITCHES, HANDLEBAR, LEFT
69200179	SWITCHES, HANDLEBAR, RIGHT
69200183	WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
69200184	WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8)

[illegible]

	WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
69200199	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
69200201	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)
69200202	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)
69200202A	COVERS AND AIR DEFLECTORS
69200203A	COVERS AND AIR DEFLECTORS WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)
69200205	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)
69200210	ANTENNAS LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200211	ANTENNAS LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200212	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8)

	WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
69200214	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8)
69200215	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8)
69200220	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
69200221	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
69200222	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
69200223	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
69200224	FORK BRACKETS, FRONT HANDLEBAR
69200225	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200226	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200237	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200238	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
69200247	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
69200248	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
69200254	WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
69200255	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
69200256	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
69200257	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
69200258	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
69200271	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
69200272	WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
69200284A	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)

69200285	WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
69200293	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
69200294	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
69200295	ANTENNAS
69200298	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
69200305	SWITCHES, HANDLEBAR, RIGHT
69200306	SWITCHES, HANDLEBAR, LEFT SWITCHES, HANDLEBAR, RIGHT
69200307	SWITCHES, HANDLEBAR, LEFT SWITCHES, HANDLEBAR, RIGHT THROTTLE CONTROL
69200308	SWITCHES, HANDLEBAR, LEFT SWITCHES, HANDLEBAR, RIGHT
69200311	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
69200312	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
69200313	ANTENNAS
69200336	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) LOOSE PARTS (1 OF 3)
69200337	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)
69200529	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
69200536	HANDLEBAR
69200629	WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8)

	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
69200630	SWITCHES, HANDLEBAR, LEFT
69200631	SWITCHES, HANDLEBAR, RIGHT
69200700	WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)
69200701	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
69200702	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
69200752	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
69200753	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
69200826	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
69200840	SENSORS AND SWITCHES, ENGINE
69201017	WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
69201018A	WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8)
69201119	WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8)
69201120	WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8)
69201121	WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8)
69201122	WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8)
69201123	WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)

	WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
69201124	WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8)
69201125	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8)
69201126	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8)
69201127	WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8)
69201130	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) BATTERY
69201162	THROTTLE CONTROL
69201163	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)
69201164	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8)

	WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)
69201168	WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
69201178	ELECTRONIC CONTROL MODULE (ECM) AND COIL BATTERY
69201240	WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)
69201286	COOLANT DISTRIBUTION, AIR-COOLED
69201287	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)
69201299	SENSORS AND SWITCHES, ENGINE
69201300	SENSORS AND SWITCHES, ENGINE
69201301	SENSORS AND SWITCHES, ENGINE WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
69201302	SENSORS AND SWITCHES, ENGINE
69201307	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) BATTERY

[illegible]

[illegible]

69201405	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
69201406	WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
69201407	WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
69201410	WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
69201411	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
69201412	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
69201414	WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
69201415	WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8)
69201416	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
69201417	BRAKE LINES AND MODULE, REAR - ABS
69201423	ALTERNATOR AND REGULATOR WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8)

	WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
69201440	WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8)
69201441	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
69201442	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
69201459	COVERS AND AIR DEFLECTORS WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)
69201548	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
69214-08	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
69241-08	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2)
69292-06	TURN SIGNALS, FRONT - FLHX AND FLHXS
69293-06	TURN SIGNALS, FRONT - FLHX AND FLHXS
69309-10	SWITCHES
69353-05	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
69377-10	FENDERS, REAR (2 OF 2)
69378-09	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2)
69380-09BHP	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
69490-07	SADDLEBAGS (1 OF 2)
69563-06	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL

69615-10	FENDERS, REAR (2 OF 2)
6982	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
6990	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
70291-89	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
70292-89	NACELLE AND HEADLAMP - FLHR AND FLHRC WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
70345-84	HANDLEBAR
7036	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
7038	FOOTBOARDS, OPERATOR FOOTBOARDS AND FOOTPEGS, PASSENGER
703B	CRANKCASE AND ENGINE OIL FILTER
7041	FRAME AND JIFFY STAND AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL EXHAUST SYSTEM
70493-08	WHEELS, FRONT
70494-08	WHEELS, FRONT
70522-06B	FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP (1 OF 2)
70554-69	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
70631-08	BRAKE LINES AND MODULE, REAR - ABS WHEELS, FRONT
70681-09	ELECTRONIC CONTROL MODULE (ECM) AND COIL EVAPORATIVE EMISSIONS COMPONENTS
70900117	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
70900118B	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS
70900119A	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS
70900120A	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS
70900121B	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900122A	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900123A	INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900124B	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900125A	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900126A	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS

70900138	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3) FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
70900161	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS
70900162	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900163	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900164	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS
70900165	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900166	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS
70900167B	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
70900168A	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
70900169A	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
70900372	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
70900373	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
70900374	INSTRUMENT HOUSING - FLTRU, FLTRX AND FLTRXS
70900392BYM	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
70900392DH	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
70901-09	FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC
70999-09	FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL TANK - FLHR AND FLHRC
7129	ANTENNAS
71294-08	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
7130W	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
71310-94	NACELLE AND HEADLAMP - FLHR AND FLHRC
71400005	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
71400006	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
71400007	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
71400010A	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC NACELLE AND HEADLAMP - FLHR AND FLHRC SWITCHES SADDLEBAGS (1 OF 2)
71400011A	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC NACELLE AND HEADLAMP - FLHR AND FLHRC SWITCHES
71400012A	SWITCHES
71400013A	SWITCHES
71400015A	SWITCHES SADDLEBAGS (1 OF 2)
71400016A	SWITCHES SADDLEBAGS (1 OF 2)
71400017A	SWITCHES
71400031	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)
71400044	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (3 OF 3)

71400073	SWITCHES
71400081	SWITCHES
71400112	SENSORS AND SWITCHES, ENGINE
71455-11	NACELLE AND HEADLAMP - FLHR AND FLHRC
71500044	SWITCHES, HANDLEBAR, LEFT
71500045	SWITCHES, HANDLEBAR, LEFT
71500046	SWITCHES, HANDLEBAR, RIGHT
71500047	SWITCHES, HANDLEBAR, LEFT
71500048	SWITCHES, HANDLEBAR, LEFT
71500049	SWITCHES, HANDLEBAR, RIGHT
71500050	SWITCHES, HANDLEBAR, RIGHT
71500053	SWITCHES, HANDLEBAR, LEFT
71500055	SWITCHES, HANDLEBAR, LEFT
71500057	SWITCHES, HANDLEBAR, RIGHT
71500063	SWITCHES, HANDLEBAR, RIGHT
71500094	SWITCHES, HANDLEBAR, LEFT
71500127B	SWITCHES, HANDLEBAR, RIGHT
71500128A	SWITCHES, HANDLEBAR, LEFT
71500129B	SWITCHES, HANDLEBAR, RIGHT
71500338	SWITCHES, HANDLEBAR, LEFT
71500340	SWITCHES, HANDLEBAR, RIGHT
71500342	SWITCHES, HANDLEBAR, LEFT
71500348	SWITCHES, HANDLEBAR, RIGHT
71500419	SWITCHES, HANDLEBAR, LEFT
71517-11	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
71522-08	NACELLE AND HEADLAMP - FLHR AND FLHRC
71540-94B	NACELLE AND HEADLAMP - FLHR AND FLHRC SWITCHES
7155	MIRRORS
71565-08	NACELLE AND HEADLAMP - FLHR AND FLHRC
71660-03	SWITCHES
72008-05	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72009-05	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72010-05	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8)

	WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72023-51E	BRAKE CONTROL, REAR SWITCHES
72038-71A	NACELLE AND HEADLAMP - FLHR AND FLHRC NACELLE AND HEADLAMP - FLHR AND FLHRC
72039-71A	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
72053-92	HANDLEBAR
72062-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72063-06	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
72064-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72065-06A	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72066-06A	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)
72081-11	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72097-06	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)

72098-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72099-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72106-94BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72110-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72111-06	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™
72127-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72130-04	FENDERS, REAR (2 OF 2) FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72135-06	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)
72145-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8)

	WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72146-94	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72160-06	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
72161-06	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC
72166-07BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
72167-07BK	WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)
72168-07	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ FENDERS, REAR (2 OF 2) CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8)

	WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS, CONSOLE - FLHR AND FLHRC WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS INTERCOM CONTROL POD LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
72169-07	FRAME AND JIFFY STAND WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
72175-07BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8)

	WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72177-07BK	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ EXHAUST SYSTEM
72188-07BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
72189-04	FENDERS, REAR (2 OF 2) FENDERS, REAR (2 OF 2) FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72190-94	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72194-94	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72195-94	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8)

	WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72209-11	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72213-94	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
72214-94	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
72222-11	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8)

	WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72226-11	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72227-11	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72232-96	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8)
72241-94A	HANDLEBAR
72242-94	BATTERY
72249-94	WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8)
72256-11	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8)

	WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72264-94	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)
72272-07	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
72283-09	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72290-94	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
72291-94	WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)
72294-94	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
72295-94	WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)
72296-95	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72298-95	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FLHTK AND FLHTKL WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8)

[illegible]

	WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72350-11	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72356-95	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72364-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8)
72405-98BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)
72412-97	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72414-07BK	FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) TAIL LAMP (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8)

	WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) INTERCOM CONTROL POD
72415-07GY	WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72444-07GY	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS EXHAUST SYSTEM
72449-01	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
72450-01	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
72473-07	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8)

	WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
72478-07BK	WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8)
72479-07BK	WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72484-08	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72485-07	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72486-08	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8)

	WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72488-07BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)
72489-07GY	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
72490-07GY	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)
72493-07	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72494-07	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS

	WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72499-07	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72511-07BK	FRAME AND JIFFY STAND
72512-07BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72518-01	WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
72519-09BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72527-01	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
72533-06	WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8)

	WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72543-07BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8)
72544-07	WIRING HARNESS, MAIN, NON-ABS - FLHX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (6 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (6 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (6 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72557-07	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72569-08	WIRING HARNESS, MAIN, NON-ABS - FLHX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (3 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (3 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (3 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (3 OF 8)
72575-11	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72589-09	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8)

	WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72594-11	SWITCHES
72606-08	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72607-08	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ WHEELS, FRONT WHEELS, REAR WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8)
72608-08	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ WHEELS, FRONT WHEELS, REAR WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8)
72609-08	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8)

	WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
72610-08	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
72632-10	WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
72633-02	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8)
72639-10	WHEELS, FRONT WHEELS, REAR WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)
72662-11	WIRING HARNESS, CONSOLE - FLHR AND FLHRC
72664-12A	WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8)

	WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
72666-12	WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
72720-07	WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
72721-07	WIRING HARNESS, MAIN, NON-ABS - FLHX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (4 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (4 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (4 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (4 OF 8)
72902-01BK	THROTTLE CONTROL THROTTLE CONTROL WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)
72904-01BK	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
72905-11	WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)
72906-11	SWITCHES, HANDLEBAR, RIGHT
72907-11	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8)

	WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
72908-11	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) SWITCHES, HANDLEBAR, LEFT SWITCHES, HANDLEBAR, RIGHT WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
72909-11	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
72910-11	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS TURN SIGNALS, FRONT - FLHX AND FLHXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS
72912-01BK	THROTTLE CONTROL WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (1 OF 2)
72914-01BK	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)
72990-01	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC THROTTLE CONTROL
72991-01	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)
73101-96BK	WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2)
73102-96BK	WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
73104-96BK	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)
73106-96BK	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8)
73152-96BK	FENDERS, FRONT FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS TOUR-PAK (BOTTOM)
73152-96WE	FENDERS, FRONT LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
73153-96BK	TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)

	TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)
73154-96BK	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC TAIL LAMP (2 OF 2)
73156-96BK	FENDERS, REAR (2 OF 2) FENDERS, REAR (2 OF 2) AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) TAIL LAMP (2 OF 2)
73190-96	WIRING HARNESS, MAIN, NON-ABS - FLHR (1 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, FAIRING - FLTRU, FLTRX AND FLTRXS LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
73191-96	FENDERS, FRONT FENDERS, REAR (2 OF 2) FENDERS, REAR (2 OF 2) FENDERS, REAR (2 OF 2) AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) TAIL LAMP (2 OF 2) TAIL LAMP (2 OF 2) TOUR-PAK (BOTTOM) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
73213-07	FRAME AND JIFFY STAND WIRING HARNESS, MAIN, NON-ABS - FLHX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (2 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8)

	WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (2 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
73254-10	TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)
73255-10	LICENSE PLATE BRACKETS LICENSE PLATE BRACKETS
7330	SHIFTER, GEAR
73301-04	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
73303-04	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8)
73304-04	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) BATTERY
73305-04	WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (8 OF 8) BATTERY
73307-10	EXHAUST SYSTEM
73309-10	TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)
7331	MIRRORS
73314-10	TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2)
7340	TRANSMISSION BEARINGS AND COVERS TRANSMISSION GEARS

74112-98BK	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
74152-98	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
7415A	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
74190-98	WHEELS, FRONT
74191-98	WIRING HARNESS, MAIN, NON-ABS - FLHX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (7 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (2 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (7 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (7 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (7 OF 8)
74194-98	SENSORS AND SWITCHES, ENGINE
74196-04	FENDERS, REAR (2 OF 2) FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, CONSOLE - FLHR AND FLHRC
74197-04	FENDERS, REAR (2 OF 2) FENDERS, REAR (2 OF 2) TAIL LAMP AND TURN SIGNALS, REAR (2 OF 2) WIRING HARNESS, MAIN, NON-ABS - FLTRX (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (1 OF 8) WIRING HARNESS, MAIN, ABS - FLTRU (1 OF 8) WIRING HARNESS,FAIRING-FLHTCU,FLHTK,FLHTKL,FLHX AND FLHXS (2 OF 2) WIRING HARNESS, CONSOLE - FLHR AND FLHRC
7434	FENDERS, REAR (1 OF 2)
74402-05B	TRANSMISSION HOUSING, TOP COVER AND OIL PAN
74408-08A	NACELLE AND HEADLAMP - FLHR AND FLHRC
74700025	ALTERNATOR AND REGULATOR
7492	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
7495	FRAME AND JIFFY STAND

	HORN
7499	FENDERS, REAR (1 OF 2) FENDERS, REAR (1 OF 2)
75069-08C	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS
75076-08B	FUEL PUMP - FLHR AND FLHRC
75089-08	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
75147-08B	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS
75205-08A	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
75229-08	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
75241-08	INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
75254-04A	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
75269-08	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
75291-08A	FUEL PUMP - FLHR AND FLHRC
7531	SEATS FENDERS, REAR (1 OF 2) GUARDS, SADDLEBAG
75322-09	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS FUEL PUMP - FLHR AND FLHRC
7549A	BRAKE CONTROL, REAR HORN
755	FENDERS, FRONT
7576	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
7586	TOUR-PAK (BOTTOM) SADDLEBAGS (1 OF 2)
7593	EXHAUST SYSTEM
7600	FENDERS, FRONT
76000055	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2)
76000075A	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
76000075B	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
76000076A	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
76000076B	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
76000092	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000096	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2) LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000107	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
76000127	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
76000160	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000161	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000164	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000165	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000172	TOUR-PAK (BOTTOM)
76000173	TOUR-PAK (BOTTOM)

76000174	TOUR-PAK (BOTTOM)
76000177	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000183	ANTENNAS
76000186	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000208	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (2 OF 2)
76000222	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000230B	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
76000231A	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
76000231B	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
76000232A	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
76000232B	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2)
76000234	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
76000243	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000252	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000370	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000373	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000374	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000376BYM	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000376DH	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000398	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000409BYM	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
76000409DH	FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 3)
76000422	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000425	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000426BYM	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000426DH	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000436	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000453	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000454	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000455	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000456	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000458	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000460	FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (2 OF 2)
76000468	SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
7601	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2) GUARDS, SADDLEBAG
7606	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
7624	FENDERS, FRONT
76259-86	ANTENNAS
76266-98A	INTERCOM CONTROL POD
7629	FENDERS, FRONT

76335-87	ANTENNAS
76353-00	LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2)
765	CRANKCASE AND ENGINE OIL FILTER
76503-08	ANTENNAS LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3) LOOSE PARTS (2 OF 3) LOOSE PARTS (3 OF 3)
7651A	WINDSHIELD - FLHR AND FLHRC
7667	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL
7686	FENDERS, REAR (1 OF 2) GUARDS, SADDLEBAG
7687	MIRRORS
77117-10	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (1 OF 3) LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3) LOOSE PARTS (2 OF 3)
77126-10	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
77148-10	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (1 OF 2)
7716	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™ FOOTBOARDS, OPERATOR FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU TOUR-PAK (BOTTOM)
7792	TRANSMISSION HOUSING, TOP COVER AND OIL PAN BATTERY
780	SHIFTER, GEAR
7813A	WHEELS, FRONT
7825	BRAKE CONTROL, REAR
786A	PRIMARY HOUSING
787	NACELLE AND HEADLAMP - FLHR AND FLHRC
7880	FENDERS, REAR (1 OF 2)
7888A	NACELLE AND HEADLAMP - FLHR AND FLHRC
7889	NACELLE AND HEADLAMP - FLHR AND FLHRC
7900	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2) WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2)
791A	PRIMARY HOUSING
7964	TAIL LAMP (1 OF 2) TAIL LAMP (1 OF 2)
7992	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS WINDSHIELD - FLHR AND FLHRC

8020	WHEELS, REAR
8026K	TRANSMISSION GEARS
8041	TRANSMISSION GEARS
8042	TRANSMISSION GEARS
8108	HORN
8126A	SADDLEBAGS - FLHRC
8135B	MIRRORS
8142	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC
8175	FAIRING LOWERS, AIR COOLED - FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU
8194	COVERS AND AIR DEFLECTORS COVERS AND AIR DEFLECTORS
83936-09A	BELT, CHAINS AND SPROCKETS
84850-92	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2)
856A	SHIFTER, GEAR
8860	FOOTBOARDS AND FOOTPEGS, PASSENGER
8873	CAMSHAFTS AND CAMSHAFT COVER
8885	CLUTCH
8963	TRANSMISSION BEARINGS AND COVERS
8967	TRANSMISSION BEARINGS AND COVERS
8970A	TRANSMISSION BEARINGS AND COVERS
8972	CRANKCASE AND ENGINE OIL FILTER
90200411	SADDLEBAGS (1 OF 2)
90200412	SADDLEBAGS (1 OF 2)
90200413	SADDLEBAGS (1 OF 2)
90200414	SADDLEBAGS (1 OF 2)
90200415	SADDLEBAGS (1 OF 2)
90200467	SADDLEBAGS (1 OF 2)
90200488	SADDLEBAGS (1 OF 2) LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
90200489	SADDLEBAGS (1 OF 2) LOOSE PARTS (1 OF 3)
90200499	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT GUARDS, SADDLEBAG
90200501	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT GUARDS, SADDLEBAG
90200504	GUARDS, SADDLEBAG
90200505	GUARDS, SADDLEBAG
90200506	GUARDS, SADDLEBAG
90200507	GUARDS, SADDLEBAG
90200519	SADDLEBAGS (1 OF 2)
90200520	SADDLEBAGS (1 OF 2)
90200521	SADDLEBAGS (1 OF 2)
90200522	SADDLEBAGS (2 OF 2)
90200543	GUARDS, SADDLEBAG
90200547	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT

	GUARDS, SADDLEBAG
90200549	GUARDS, SADDLEBAG
90200550	GUARDS, SADDLEBAG
90200611	SADDLEBAGS (2 OF 2)
90200684	SADDLEBAGS - FLHRC
90200685	SADDLEBAGS - FLHRC
90200899	SADDLEBAGS (2 OF 2)
90200900	SADDLEBAGS (2 OF 2)
90200901	SADDLEBAGS (2 OF 2)
90200902	SADDLEBAGS (2 OF 2)
90200903	SADDLEBAGS (2 OF 2)
90200905	SADDLEBAGS - FLHRC
90200983BYM	SADDLEBAGS (2 OF 2)
90200983DH	SADDLEBAGS (2 OF 2)
90200983DWC	SADDLEBAGS (2 OF 2)
90200983DZN	SADDLEBAGS (2 OF 2)
90200983DZP	SADDLEBAGS (2 OF 2)
90200983DZS	SADDLEBAGS (2 OF 2)
90200983DZT	SADDLEBAGS (2 OF 2)
90200983DZW	SADDLEBAGS (2 OF 2)
90200984BYM	SADDLEBAGS (2 OF 2)
90200984DH	SADDLEBAGS (2 OF 2)
90200984DWC	SADDLEBAGS (2 OF 2)
90200984DZN	SADDLEBAGS (2 OF 2)
90200984DZP	SADDLEBAGS (2 OF 2)
90200984DZS	SADDLEBAGS (2 OF 2)
90200984DZT	SADDLEBAGS (2 OF 2)
90200984DZW	SADDLEBAGS (2 OF 2)
90201295	SADDLEBAGS (2 OF 2)
90201296	SADDLEBAGS (2 OF 2)
90201540	SADDLEBAGS (2 OF 2)
90300024	SADDLEBAGS (2 OF 2)
90300030	TOUR-PAK (BOTTOM)
90300043	CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (2 OF 2) INSTRUMENTS, FUEL TANK - FLHR AND FLHRC NACELLE AND HEADLAMP - FLHR AND FLHRC SWITCHES TOUR-PAK (BOTTOM) SADDLEBAGS (2 OF 2) LOOSE PARTS (1 OF 3)
90300093	FUEL TANK - FLHR AND FLHRC
90300111	SWITCHES LOOSE PARTS (1 OF 3)
90300112	SWITCHES LOOSE PARTS (1 OF 3)
90382-98	SADDLEBAGS - FLHRC
90425-98	SADDLEBAGS - FLHRC
90439-10	SADDLEBAGS - FLHRC

90482-10	SADDLEBAGS - FLHRC
90520-07	FRAME AND JIFFY STAND
90820-93D	SHOCK ABSORBERS, REAR SADDLEBAGS - FLHRC LABELS
90821-74C	TOUR-PAK (COVER) LABELS
90844-80	TOUR-PAK (BOTTOM)
90869-85A	TOUR-PAK (COVER)
91140-09	FENDERS, REAR (2 OF 2)
91700025A	FORK, FRONT, LEFT AND RIGHT - STANDARD FORK, FRONT, LEFT AND RIGHT - LOW
91700034	SOUND SYSTEM - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (2 OF 2) SOUND SYSTEM - FLTRU, FLTRX AND FLTRXS (2 OF 2)
91800058	INDUCTION MODULE, FUEL
91800064	ENGINE ASSEMBLY, AIR-COOLED ENGINE ASSEMBLY, TWIN-COOLED™
91840-03B	MIRRORS
91845-03B	MIRRORS
92038-10	TOUR-PAK (BOTTOM) LOOSE PARTS (1 OF 3)
9208	FRAME AND FORK, REAR AND TOUR-PAK SUPPORT
9215	CRANKCASE AND ENGINE OIL FILTER CAMSHAFTS AND CAMSHAFT COVER
923	TOUR-PAK (COVER)
9231	PRIMARY HOUSING
9252	WHEELS, FRONT WHEELS, REAR
9276A	BELT, CHAINS AND SPROCKETS WHEELS, FRONT WHEELS, FRONT WHEELS, REAR WHEELS, REAR
933	WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2) LOOSE PARTS (2 OF 3)
94000084	LOOSE PARTS (1 OF 3)
94000326	LOOSE PARTS (1 OF 3)
942	CAMSHAFTS AND CAMSHAFT COVER
946	AIR CLEANER
95594-84B	WHEELS, FRONT WHEELS, REAR
95595-84B	WHEELS, FRONT WHEELS, REAR
9701A	TRANSMISSION BEARINGS AND COVERS
9819	WIRING HARNESS, MAIN, NON-ABS - FLHX (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTCU (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLHR (5 OF 8) WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (5 OF 8) WIRING HARNESS, MAIN, NON-ABS - FLTRX (5 OF 8) WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (5 OF 8)

	WIRING HARNESS, MAIN, ABS - FLTRU (5 OF 8)
9853	HANDLEBAR
9907	BRAKE CONTROL, REAR SWITCHES
99461-89	TOUR-PAK (BOTTOM) LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3)
99466-17	LOOSE PARTS (1 OF 3)
99517-17EN	LOOSE PARTS (1 OF 3) LOOSE PARTS (2 OF 3) LOOSE PARTS (2 OF 3) LOOSE PARTS (3 OF 3)
9955	EXHAUST SYSTEM
9956	EXHAUST SYSTEM

Component Types and Introduction Dates

101A1 - Generic Nuts	
7586	Unknown
8142	Unknown
7576	1990
7624	Unknown
7629	1990
7792	2012
8135B	Unknown
7813A	Unknown
8126A	Unknown
76259-86	1986
7888A	Unknown
7900	Unknown
7825	Unknown
5210	1991
5211	Unknown
7687	2009
84850-92	1992
7992	2010
74408-08A	2008

7889	Unknown
7495	1994
10100062	2017
7499	Unknown
7492	1993
7340	Unknown
7880	Unknown
7330	Unknown
71660-03	2003
7331	Unknown
7964	Unknown
90844-80	1980
8020	2002
8108	Unknown
7593	1991
7549A	Unknown
10100033	2014
7601	1990
102A1 - Generic Screws	
2446	Unknown
3536	Unknown
10200429	2017
3983	Unknown
3987	Unknown
68026-99	1999
10200414	2017
2452	Unknown
2563	2009
10200365	2015

10200141	2014
10200308	2017
10200142	2014
3622	Unknown
4741A	Unknown
10200147	2014
3050	Unknown
4916	Unknown
786A	Unknown
2692WB	Unknown
3655A	Unknown
3976	Unknown
3634	Unknown
3057	Unknown
3249	Unknown
4688	Unknown
4718A	Unknown
2479	Unknown
2933	Unknown
2478	2007
10200303	2017
35259-06	2006
10200373	2017
3022A	Unknown
10200400	2016
10200503	2017
43567-92	1992
10200156	2014
10200155	2014
3514	Unknown

10200154	2014
2482	Unknown
4597M	Unknown
10200408	2017
791A	2007
942	Unknown
4694	Unknown
3561WC	Unknown
2921	Unknown
3612	2012
3275	Unknown
4890	Unknown
4705	2005
68452-86	1986
4132	Unknown
4740A	Unknown
10200120	2011
3656	Unknown
4240	Unknown
933	Unknown
3607	2009
2731W	Unknown
10200393	2017
2952A	2003
10200134	2014
3560WA	Unknown
2968	Unknown
3601	Unknown
10200133	2014

2647B	Unknown
4822A	Unknown
68120-00	2000
3061	Unknown
4924	Unknown
3576	2013
3594	1992
3088	Unknown
4856	Unknown
10200112	2014
2995	Unknown
2708A	Unknown
923	Unknown
10200205	2014
4816A	Unknown
68042-99	1999
3152	Unknown
4419	Unknown
4612	Unknown
3699D	Unknown
3929	2009
2724	Unknown
10200463	2017
787	Unknown
3225	Unknown
3588	1990
35244-06	2014
3901	Unknown
3563	1999
10200103	2014

3143	Unknown
10200105	2014
780	Unknown
29269-83A	1983
67721-48	1948
1775	Unknown
3910	2014
2531	Unknown
4820A	Unknown
10200546	2017
4867	Unknown
10200042	2014
8175	2004
10200223	2014
3767B	2009
946	Unknown
10200446	2017
10200442	2016
10200052	2014
3684	Unknown
4312C	Unknown
3787	Unknown
10200533	2016
10200350	2015
3676	Unknown
856A	1990
1062	Unknown
10200217	2014
10200060	2014

10200061	2014
4813A	1990
10200062	2014
10200063	2014
10200569	2017
703B	Unknown
10200064	2014
10200065	2014
10200343	2017
10200059	2014
4790	Unknown
1332	2010
4194	Unknown
42858-06A	2006
3892	Unknown
4775	2000
10200257	2015
10200258	2014
10200422	2017
2445	Unknown
103A1 - Generic Washers	
6019	Unknown
6026	Unknown
7415A	Unknown
11891	Unknown
56159-73	1973
7130W	Unknown
6497HW	2010
7434	1999

6220W	Unknown
6294	2010
46509-01	2001
8972	Unknown
6116	Unknown
6789	Unknown
59788-01	2001
6113	Unknown
6333	Unknown
6150W	Unknown
6054	Unknown
6109	1980
6101	2011
6594	Unknown
7129	Unknown
6072	Unknown
6590HW	Unknown
6127	Unknown
6532	2000
6036	Unknown
6421	1996
6416	Unknown
7038	1998
6762D	2016
7041	1958
6703	1970
6702	Unknown
6235	Unknown
104A1 - Custom Nuts	
10400034	2016

54321-85	1985
7606	1983
105A1 - Custom Screws	
10500022	2014
10500017	2014
10500015	2014
10500031	2014
10500036	2014
10500069	2017
10500053	2015
108A1 - Hose Clamps	
10053	2010
10800023	2013
10800025A	2017
10354	Unknown
10344	Unknown
55918-08	2008
66861-09A	2009
10800078	2014
69563-06	2006
10340B	2015
10800052	2014
9956	1972
9955	Unknown
10080	Unknown
108B1 - P Clamps	
10800028	2014
10076	2010
109A1 - Studs	

59818-09	2009
3265A	Unknown
66290-06	2006
10184	Unknown
10900005	2014
10900015	2017
10900026	2016
10900009A	2016
110B1 - Plain Bushings	
11000139	2017
11519	Unknown
8967	2005
11000050	2014
9252	Unknown
12077	Unknown
67266-94	1994
8885	Unknown
9701A	2011
9208	Unknown
110C1 - Radial Shaft Seals	
11000134	2017
11000101	2013
12074	Unknown
12052A	2003
110D1 - Rolling Element Bearings	
8860	Unknown
9215	Unknown
8042	Unknown
8963	Unknown
11000010	2011

9231	Unknown
24605-07	2007
8970A	2012
9276A	2011
111A1 - Adhesive	
73304-04	2004
72194-94	1994
9819	Unknown
72264-94	1994
58417-77	1977
9907	Unknown
72527-01	2001
72990-01	2001
72008-05	2005
74196-04	2004
72110-06	2006
111B1 - Tape	
11100066	2013
111C1 - Insulating Tape	
11100115	2014
11668	Unknown
111D1 - Isolating Tape	
11100050	2014
11100051	2014
11100057	2014
11100152	2015
11100038	2014
111E2 - Mounting Pad	
11100195	2017

111F1 - Protective Tape	
11100068	2014
116A1 - Banjo Bolts	
50674-05	2005
41750-06B	2006
41783-08	2008
11600009	2014
11600001	2012
117A1 - Coil Springs	
33085-74	1974
11700005	2014
119A1 - O-Rings	
11900010	2013
11686	Unknown
11900092	2017
11105	Unknown
11900090	2017
11145A	2007
11900103	2017
11900116	2017
11289A	Unknown
46508-01	2001
11201	Unknown
11323A	2016
11120	Unknown
11132A	2007
11293	Unknown
27444-00Y	2000
11900021	2014

120A1 - Pins	
16583-00A	2000
601	Unknown
50933-86A	1986
221	Unknown
16574-99A	1999
16589-99A	1999
42460-80B	1980
515	Unknown
24754-75A	1975
12000005	2014
45041-01A	2001
121A1 - Grommets	
11692	Unknown
11437	Unknown
12100113	2017
12100020	2014
12100018	2014
12100017	2014
57978-00	2000
11543	Unknown
11650	2010
12100007	2014
12100077	2017
59778-06	2006
121B1 - Press-Fit Plugs	
59749-06	2006
12100034	2014
72097-06	2006
12100023	2014

70292-89	1989
765	1997
755	Unknown
90520-07	2007
12100069	2017
122A1 - Retaining Rings	
17945-36B	1936
10264	Unknown
35114-02	2002
65325-83A	1983
35087-99A	1999
10183	1996
10103	Unknown
11036	Unknown
61012-04A	2004
11150	Unknown
12200092	2014
11061A	2008
11143	Unknown
10395	Unknown
10396	Unknown
9853	Unknown
10991A	Unknown
61213-04A	2004
11177A	1996
12200025	2014
11389	Unknown
11304	Unknown
11082A	2016

11081A	2008
60678-85	1985
10318	Unknown
10147	Unknown
41229-08	2008
11575	Unknown
12200064	2014
11161	Unknown
122A2 - Retaining Clips	
12200147A	2017
123A1 - Sealing Washers	
41751-06A	2006
123B1 - Spring Washers	
7155	Unknown
124A1 - Spacers	
12400100	2015
12400034	2014
41900-08	2008
46515-01	2001
5837A	Unknown
12400099	2017
11599A	2012
11848	Unknown
125A1 - Tie Straps	
12500014	2017
10065	1985
12500018	2017
10039	1981
10177	1996
10006	1960

12500002	2012
126A1 - Miscellaneous Hardware	
8041	Unknown
68331-02	2002
59292-94	1994
12600073	2014
12600071	2014
12600070	2014
12600049	2014
56161-83A	1983
12600032	2014
12600031	2012
8873	1984
57638-08	2008
126B1 - Rivets Fasteners	
70291-89	1989
12600067	2014
11779	2008
12600016	2011
126B2 - Tree Fasteners	
12600197	2017
127B1 - Generic Mounting Bracket	
12700091	2017
12700090	2017
140A1 - Battery Warning Label	
15368-01A	2001
140A2 - General Warning Label	
14148-86	1986
90821-74C	1974

15385-08	2008
140A3 - Other Special Warning Label	
15342-06A	2006
15370-01A	2001
15346-98A	1998
90820-93D	1993
140G2 - EPA Label	
29108-08	2008
140G6 - VIN Overlay	
13729-16	2016
140M2 - Shift Pattern Label	
14272-06	2006
140P2 - General Label	
14000827	2013
13729-17	2017
141A1 - Medallion	
14100588	2015
14100587	2015
14100158	2014
14100766	2016
14100765	2016
14100764	2017
62437-11	2011
14100855	2017
14100074	2014
14100073	2014
44341-08	2008
14100075	2014
14100076	2014

14100079	2014
14100080	2014
14100085	2014
14100083	2014
53735-06	2006
14100230	2014
14100232	2014
14100231	2014
53734-06	2006
62435-11	2011
14100615	2015
14100254	2014
42856-06	2006
14100279	2014
14100087	2014
162D1 - Engine Assembly	
16200249	2017
16200248	2017
162D3 - Engine Assembly Short Block	
16200265	2017
163A1 - Engine Isolator	
16300005	2017
164A1 - Engine Mount Bracket	
16400049	2017
16400005	2014
16400042	2017
164B1 - Engine Mount Bracket sub-component	
7600	Unknown
7716	1990
7531	1980

7667	Unknown
7686	Unknown
16219-09	2009
8194	Unknown
164D1 - Tiebar Mount	
16400041	2017
165A1 - Cylinder Head	
16500508	2017
16500388	2017
16500393	2017
16500498	2017
165B1 - Cylinder Head and Base Gaskets	
17369-06	2006
16500326	2017
16500332	2017
167A1 - PT Assembly Miscellaneous Component	
36731-91	1991
168A1 - Cylinder	
16800100	2017
16800095	2017
168C1 - Cylinder Stud	
16800063	2017
173A1 - Rocker Arm	
17300055	2017
17300053	2017
173B1 - Rocker Arm Shaft	
17300059	2017
179A1 - Lifters	
18538-99C	2011

179B1 - Push Rod	
17900031	2017
17900030	2017
179C1 - Lifter Anti-Rotation Device	
17900035	2017
17900034	2017
180A1 - Valves	
18000034	2017
18000016	2017
181B1 - Valve Seals	
18100044	2017
181C1 - Valve Collars	
17947-36	1936
17968-99	1999
18100060	2017
18100045	2017
18100043	2017
184A1 - PT Camdrive and Valvetrain Miscellaneous Component	
18400073	2017
219Z1 - Kit,Piston	
21900049	2017
220A1 - Piston Ring	
22000031	2014
220Z1 - Kit,Piston Ring	
22000060	2017
221A1 - Piston Pin	
22097-99	1999
22100006	2017
239A1 - PT Lower End Miscellaneous Component	
8026K	Unknown

241A1 - Flywheel	
24100057	2017
241Z1 - Kit,Flywheel	
24100080	2017
244A1 - Crankcase	
24400120	2017
244B1 - Crankcase Gasket	
24400215	2017
244F1 - Oil Pan	
24400180	2017
254A1 - Camdrive Gear	
25566-06	2006
254B1 - Camshaft	
25675-06	2006
25673-06	2006
25400190	2017
254C1 - Camshaft Sprocket	
25400103	2017
254D1 - Camshaft Support	
25400133	2017
41819-02	2002
254Z1 - Kit,Camdrive	
25400257	2017
255C1 - Camdrive Chain Tensioner	
25500013	2017
256A1 - Timer Cover	
25600049	2017
25600042	2017
257A1 - Cam Cover	

25700367	2017
257B1 - Clutch Cover	
25700388	2015
257E1 - Cover Gaskets	
36805-06	2006
61402-08	2008
25700453	2017
25700452	2017
65324-83B	2009
67208-08	2008
35654-06	2006
25700455	2017
25700425	2017
25700370	2017
25700372	2017
71294-08	2008
25700362	2017
61109-85D	1985
11936	Unknown
42857-06B	2013
25700378	2017
25700433	2017
61192-96A	1996
11902	Unknown
257G1 - Ignition Cover	
25700489	2015
257L1 - Primary Cover	
25700418	2017
25700650	2017

25700178	2013
257M1 - Push Rod Cover	
17948-99	1999
25700488	2017
257N1 - Rocker-Arm / Valve Cover	
25700414	2017
25700409	2017
257P1 - Tappet Cover	
25700411	2017
25700410	2017
257Z1 - Kit,Cover/Sealing	
25700746	2017
25700731	2017
25700730	2017
25700729	2017
258A1 - PT Covers Miscellaneous Component	
25800054	2017
25800057	2017
25800056	2017
25800049	2017
25800048	2017
25800110	2017
25800109	2017
266B1 - Water Pump	
26600048	2017
268B1 - Cooling Fan	
26800007A	2014
26800019A	2014
268B2 - Cooling Fan Guard	
26800008	2014

268C1 - Radiator	
26800005	2014
26800006	2014
268E1 - Radiator sub-component	
26800020A	2014
268F1 - Radiator Pressure Cap	
26800021	2014
268H1 - Radiator System Cover	
26800092	2017
26800009	2014
26800077	2017
269A1 - Cooling Line Fitting	
26900117	2017
269A2 - Coolant Line Tube	
26900133	2017
269B1 - Radiator Hose	
26900088	2017
26900115	2017
26900018	2014
26900016	2013
26900017	2013
26900114	2017
26900010	2014
26900008	2014
26900009	2014
269F1 - Radiator Overflow Tank Cap	
26780-05A	2006
269G1 - Radiator Overflow Tank	
26900014	2014

272B1 - Throttle Body / Intake Manifold	
27200025	2017
273A1 - Intake Manifold	
27300121	2017
273A2 - Intake Manifold to Cylinder Head Seal	
27300087	2017
273C1 - Throttle Body/Intake Manifold sub-component	
27300086	2017
273G1 - Throttle Body	
27300122	2017
273K1 - Throttle Body to Manifold Seal	
27300082	2017
274B1 - Fuel Rail	
27400019	2017
274C1 - Fuel Injector	
27400015	2017
290A1 - Airbox Baseplate	
29000120	2017
29000121	2017
290D1 - Airbox Seal	
29000108	2017
29000106	2017
290Z1 - Kit,Airbox	
29000216	2017
292A1 - Air Duct	
29200041BYM	2015
29200063	2015
29200062	2015
29200061	2015
29200071	2015

29200073	2015
29200072	2015
29200075	2015
29200078	2015
29200080	2015
29200081	2015
29200039	2014
29200034	2014
29200035	2014
29200003	2014
29200041DH	2015
292B1 - Air Duct Bezel	
29200007	2014
294A1 - Air Filter Element	
29400212	2017
294B1 - Breather Bolt	
29465-08A	2014
294C1 - Breather Hose	
29400211	2017
294F1 - Engine Breather Valve	
29400210	2017
29400183	2017
299B1 - Charging Rotor Assembly	
29900038	2017
299C1 - Charging Rotor	
29900041	2017
299F1 - Stator Assembly	
29900042	2017
314F1 - Starter Motor	

31400053	2017
314H1 - Starter Solenoid	
27715-07	2007
316A1 - Ignition Coil	
31600017	2017
316B1 - Spark Plug Cable	
31600079	2017
31600078	2017
31600018	2017
31600023	2017
316C1 - Spark Plug	
31600012	2015
327A1 - Sensor	
32700050	2016
327B1 - Chemical / Gas Sensor	
32700046	2017
27809-10	2010
327C1 - Pressure Sensor	
40615-08	2008
327D1 - Proximity Sensor	
32700017	2014
32700015	2014
50126-08A	2008
32700048	2017
74402-05B	2012
327E1 - Temperature Sensor	
32700010	2014
32700066	2015
32700065	2017

32700054	2017
336A1 - Shift Linkage Rod Assembly	
33895-82D	2010
5817	2000
33600088	2017
33600091	2017
336C1 - Shift Linkage Rod End	
33719-79B	1979
336F1 - Toepeg	
34611-65A	1965
339A1 - Shift Lever	
33900175	2017
339D1 - Shifter Fork	
35222-06	2014
35217-06	2006
35223-06	2014
35210-06	2006
35187-06	2006
339H1 - Shifter Mechanism Components (internal)	
33900172	2017
34064-00C	2000
35243-06	2014
33389-07	2014
34091-08	2008
35249-06A	2006
34987-06	2006
35186-06	2006
35081-06	2006
33409-06B	2006
35082-07	2007

347B1 - Transmission Case	
34700084	2017
348C1 - Transmission Top Cover	
34800025	2017
34800038	2017
350A1 - Transmission Output Sprocket	
35000152	2017
350E1 - Transmission Gear	
35801-10	2010
35122-06	2006
350F1 - Transmission Mainshaft	
35467-06B	2008
350G1 - Transmission Shim / Spacer	
25736-06	2006
25731-06	2006
25729-06	2006
11207A	2009
25738-06	2006
25737-06	2006
25734-06	2006
350S2 - Sub-Assembly, Transmission Mainshaft	
35000198	2017
352A1 - Engine Balancer	
35200027	2017
352B1 - Engine Balancer sub-component	
35200021	2017
356A1 - Transmission Countershaft	
35807-06	2006
35814-06	2006

35811-06	2006
35600103	2017
35470-10	2010
356B1 - Transmission Dog Ring	
35204-06	2006
35126-06	2006
356C1 - Transmission Dog Ring Guide Hub	
35202-06	2006
35201-10	2010
35124-06	2006
363A1 - PT Driveline Miscellaneous Component	
40901-05	2005
35260-06B	2016
35241-06	2006
35242-06	2006
365A1 - Primary Chain	
40037-07	2007
365B1 - Primary Chain Tensioner	
36500075	2017
365E1 - Inner Primary Housing	
36500052	2017
367A1 - Clutch Lever	
36700133	2017
367B1 - Clutch Lever Master Cylinder	
36700128	2017
367D1 - Clutch Lever Master Cylinder Reservoir	
36700132	2017
36700130	2017
36700131	2017
367E1 - Clutch Lever Mount Clamp	

36700113	2015
367G1 - Clutch Lever Pivot Bolt	
36706-01K	2001
367H1 - Clutch Lever sub-component	
37904-90	1990
37909-90	1990
370A1 - Clutch Assembly	
37000254	2017
37496-90A	1990
37000168	2017
37000169	2017
370C1 - Clutch Hub	
37000083	2013
370F1 - Clutch Pressure Plate	
37000032A	2017
370F2 - Clutch Spring Pressure Plate	
37000270	2017
370J1 - Miscellaneous Clutch Sub-Component	
37000258	2017
37000033	2013
37000034	2013
37000036	2013
37000219	2017
37000217	2014
37000218	2014
372G1 - Clutch Hose	
37200129	2017
37200128	2017
37200146	2017

372P1 - Secondary Clutch Actuator	
37200131	2017
400A1 - Drive-Belt	
40024-09A	2015
401A1 - Engine Sprocket	
83936-09A	2013
40100064	2017
40100041	2014
401Z1 - Kit,Engine Sprocket	
40100076	2017
409A1 - Rear Wheel	
40900026	2013
41052-09	2009
40900391	2015
40900033	2013
410A1 - Body Control Module (BCM)	
41000342A	2017
41000351A	2017
41000341A	2017
410D1 - Electronic Control Module (ECM)	
41000307	2017
411A3 - ABS Hydraulic Control Unit	
41100061	2017
413A1 - Brake Caliper	
43027-08	2008
44023-08	2008
44160-00	2000
413B1 - Brake Bleeder Screw	
42853-06	2006

413C1 - Brake Caliper sub-component	
12102	Unknown
42851-06	2006
413D1 - Brake Pad	
42867-06A	2006
41854-08	2008
41852-08B	2012
413E1 - Brake Pad Pin	
42865-06B	2006
42849-08	2008
415B1 - Brake Rotor	
41500017	2014
41500018	2014
41809-08A	2014
41808-08A	2014
41500019	2014
41500020	2014
41810-08B	2012
416A1 - Brakes Miscellaneous Component	
42860-06B	2006
42852-06A	2006
42934-08	2008
42863-06	2006
72023-51E	2012
44089-08	2008
416B1 - Brake Mounting Bracket	
41600091	2014
41600078	2014
41600029A	2015
41600032	2014

41600031	2014
417A1 - Brake Master Cylinder Assembly	
44551-08E	2015
41700028	2014
417B1 - Brake Master Cylinder	
42889-06	2006
417C1 - Brake Master Cylinder Piston Set	
41700195	2014
42861-06B	2006
42932-08A	2013
417D1 - Brake Master Cylinder sub-Component	
42862-06B	2010
42855-06C	2013
41700367	2015
42937-08B	2010
417G1 - Front Brake Lever	
42859-06B	2006
417H1 - Front Brake Master Cylinder Mount Clamp	
41700321	2015
45138-08A	2008
418B1 - Brake Line	
41800012	2014
41800011	2014
41800314	2015
41800510	2016
41800175	2014
41800174	2014
41800544	2017
41800545	2017

41800542	2017
41800543	2017
41800546	2017
41800547	2017
41800541	2017
41800340	2015
420A1 - Wheel Rim	
41445-09	2009
43085-97	1997
421A1 - Wheel Spoke with Nipple	
43241-05	2005
42018-09	2009
41746-09	2009
422B1 - Wheel Sprocket	
40217-09	2009
422C1 - Wheel Sprocket Compensating Cushion	
40278-09	2009
423C1 - Rim Strip	
43099-09	2009
43147-40	1940
423D1 - Tire Inner Tube	
40592-09	2009
40558-82	1982
423G1 - Valve Stem	
40999-87	1987
423H1 - Valve Stem Cap	
41123-79	1979
423K1 - Wheel Weights	
95595-84B	2014
95594-84B	2014

424A1 - Wheels, Tires and Final Drive Miscellaneous Component	
44080-08C	2012
430D1 - Front Axle	
41547-07A	2007
430E1 - Rear Axle	
43000002	2014
431A1 - Front Tire	
43118-92A	1992
43100013	2014
43109-09A	2009
432A1 - Rear Tire	
43200027	2014
43230-09	2009
433A1 - Front Wheel	
40960-09	2009
43300386	2015
43300027	2013
43300019	2013
433B1 - Front Wheel Bearing Spacer	
56163-93	1993
48489-02	2002
11843	2009
41242-08	2008
41901-08	2008
41349-07	2007
454A1 - Front Telescopic Fork	
45400181	2017
45400182	2017
45400102	2017

45400103	2017
45400104	2017
45400105	2017
455A1 - Front Telescopic Fork Slider	
45500111	2014
45500109	2014
455B1 - Front Telescopic Fork Spring	
45500456	2017
45500396	2017
45500337	2017
45500338	2017
455C1 - Front Telescopic Fork sub-component	
71310-94	1994
46514-01A	2010
45500397	2017
45500424	2017
45500398	2017
45500421	2001
46513-01	2001
45500132	2014
45500339	2017
45500118	2014
45500117	2014
45500340	2017
45500341	2017
456A1 - Fork Protector	
45600003	2014
456C1 - Fork Lock	
71540-94B	2016

457D1 - Steering Stem	
45700020A	2014
457E1 - Steering Stem Bearing Insert Cup	
45700009	2014
458A1 - Front Suspension and Steering Miscellaneous Component	
45800023	2014
46615-06	2006
459B1 - Lower Triple Clamp	
45900024	2014
45900091A	2014
470A1 - Frame	
48079-09BHP	2009
47000088BHP	2017
470Z1 - Kit,Frame	
58002-09A	2017
472A1 - Frame sub-component	
6982	Unknown
10600007	2014
7036	Unknown
472C1 - Front Fairing Support Bracket	
47200217	2015
47200266	2015
47200262	2015
47200261	2015
58888-98A	1998
472C2 - Fairing Lower Support Bracket	
47200275	2014
472D2 - Chassis Structure Mounting Bracket	
68712-94A	1994
68629-05	2005

47200302A	2017
91140-09	2009
472E1 - Frame Cover	
47200080	2014
47200081	2014
474C1 - Swingarm	
47549-09A	2017
474E1 - Swingarm Assembly sub-component	
47584-09	2009
67875-11	2011
474F1 - Swingarm Bearing Spacer	
48487-02	2002
475B1 - Swingarm Pivot Shaft	
47540-11	2011
490C1 - Engine Guard	
49184-09A	2014
500B1 - Sidestand Bracket	
50000141A	2017
50000097	2017
500C1 - Sidestand Bracket sub-component	
49725-07A	2007
500D1 - Sidestand Leg	
50075-07A	2011
50000083	2015
500E1 - Sidestand Leg sub-component	
50015-74A	1974
50245-07	2007
505A1 - Footboard	
52719-10	2010

50689-11	2011
50500143	2012
50500146	2012
50500145	2012
50613-91A	1991
50688-04	2004
50899-99A	1999
50500360	2015
50683-04	2004
50684-11	2011
505B1 - Footpeg Mount Bracket	
50518-09	2009
50500332A	2016
50500462A	2016
50500334A	2016
50208-04	2004
50500460A	2016
50622-09A	2015
505C1 - Heel Guard / Pad	
50606-06	2006
50614-06	2006
505D1 - Passenger Footpeg	
50345-04	2004
50621-06	2006
505K1 - Footpeg Wear Peg	
50500339	2015
50350-04	2004
506A1 - Brake Pedal	
42444-04	2004
50912-72	1972

50600067	2014
42416-06	2006
42410-04	2004
507A1 - Rider Interface Miscellaneous Component	
54395-10	2010
520A1 - Rider Seat or Full Seat	
52000174	2015
52000173	2015
52000038	2014
52000033	2014
52000122	2014
52000060	2014
52000142	2015
52320-11	2011
523B1 - Back Rest Pad	
52300053	2014
523C1 - Back Rest Support Structure	
52300127	2014
52300122	2014
52300121	2014
52300123	2014
524A1 - Passenger Grab Handle	
52400018	2014
52400021	2014
52400054	2014
52400099	2014
52400116	2015
52400015	2014
52400017	2014

52400016	2014
524C1 - Passenger Seat sub-component	
52400067	2014
530A1 - Tour Pak	
53000124	2014
53000123	2014
530B1 - Tour Pak sub-component	
53000311	2014
53000132	2014
53000347	2014
53000346	2014
92038-10	2010
53000308	2014
53000141	2014
53598-88A	1988
53000091	2014
53000090	2014
90869-85A	1985
53000370	2014
530C2 - Case Latch	
90382-98	1998
90425-98	1998
53000140	2014
53000137	2014
53000139	2014
53000138	2014
530E1 - Tour-Pak Luggage Rack	
53665-87	1987
53000125	2014

540B1 - Rear Shock	
54000113	2017
54000114	2017
54000096	2017
54000095	2017
54000094	2017
54000093	2017
540E1 - Rear Shock sub-component	
54000141	2017
558A1 - Handlebar	
55800099	2014
55800436	2016
55924-14	2014
55800305	2015
55800332	2015
558B1 - Handlebar Tube	
55800091	2014
559D1 - Lower Handlebar Clamp	
57450-14	2014
57451-14	2014
55900079	2015
55900078	2015
559E1 - Upper Handlebar Clamp	
55900071	2015
560A1 - Mirror	
91840-03B	2003
56000011	2014
56000012	2014
56000015	2014
56000016	2014

91845-03B	2003
561B1 - Left Hand Grip	
56667-04	2004
561E1 - Throttle Grip	
56304-08	2008
56100075	2015
56248-08	2008
570A1 - Front Fairing	
57000412	2015
57000508	2015
57000504	2015
57000501	2015
57000017	2014
57000383	2014
57000377	2015
57000302	2015
570C1 - Inner Fairing	
57000299	2014
57000374BYM	2015
57000064DH	2014
57000175	2014
57000064BYM	2014
57000186	2014
57000065DH	2014
57000169	2014
57000305	2015
57000170	2014
57000172	2014
57000065BYM	2014

571A1 - Fairing Lower	
57100112	2014
57100111	2014
57100114	2014
57100113	2014
571B1 - Fairing Lower sub-component	
57100110	2014
57100107	2014
57100109	2014
57100225	2014
57100108	2014
57100103	2014
57100102	2014
57100227	2014
57100104	2014
57100101	2014
57100208	2014
57100188	2014
57100187	2014
57100200	2014
57100172	2014
57100171	2014
57100170	2014
57100099	2014
57100098	2014
57100166	2014
57100167	2014
57100164	2014
57100165	2014
57100152	2014

57100151	2014
57100150	2014
57100148	2014
57100149	2014
57100147	2014
57100161	2014
57100162	2014
57100153	2014
57100154	2014
57100155	2014
57100256	2014
57100247	2015
572C1 - Chin Spoiler Side	
57200066	2015
57200064	2015
57200065	2015
57200063	2015
57200012	2014
57200017	2014
572D1 - Engine Shroud	
58169-09	2009
58167-09A	2017
572E1 - Side Cover	
32306-08	2008
66048-09A	2012
66250-09	2009
573A1 - Bodywork Miscellaneous Component	
57300063	2015
4706	Unknown

38722-94	1994
53919-04A	2004
7651A	Unknown
573B1 - Bodywork Mounting Bracket	
59786-01	2001
574B1 - Windscreen / Windshield	
58088-94	1994
58428-94	1994
57668-10	2010
58084-94	1994
57400058	2014
58193-94	1994
57400001	2014
57400003	2014
57400002	2014
57400005	2010
57400004	2014
57400309	2016
57400308	2016
57400305	2016
57400303	2015
57400302	2015
58431-94	1994
57400250	2015
58325-06	2006
58327-06	2006
57400262	2015
57400260	2015
57400191	2015

58416-77A	1977
58406-75A	1975
57400187	2015
67621-94	1994
57994-94	1994
58408-75A	1975
589A1 - Front Fender	
58900009	2014
58900032	2014
595B1 - Tailsection Center	
59739-09	2009
595D1 - Rear Fender	
59500046	2014
59731-09	2009
58702-09	2009
60575-10	2010
59768-97	1997
59174-99	1999
596B1 - Fender Tip	
59600003	2014
59600009	2014
59600008	2014
69615-10	2010
59600006	2014
59600011	2014
59581-05	2005
59600029	2017
603B1 - Belt / Chain Guard	
60386-09	2009
608A1 - Carbon Canister	

60800006	2012
608B1 - Carbon Canister Hose	
27298-09A	2014
27291-09A	2014
60800026	2017
27297-09A	2014
609A1 - Fuel Miscellaneous Component	
70999-09	2009
6119	2016
61112-08	2008
62229-08B	2011
75069-08C	2011
75076-08B	2011
75147-08B	2011
75291-08A	2011
75254-04A	2004
75269-08	2008
609B1 - Fuel and Intake Mounting Bracket	
70901-09	2009
610A1 - Fuel Tank	
61356-08	2008
61268-08	2008
611B1 - Fuel Cap	
61274-92	1992
61100055	2014
10334	2014
61272-92C	1992
611F1 - Fuel Tank Vapor Vent Hose	
27440-09A	2014

69241-08	2008
612A1 - Fuel Filter	
61011-04A	2004
612B1 - Fuel Level Sensor	
75205-08A	2012
612B2 - Fuel Valve	
61015-04A	2004
62228-08C	2016
612C1 - Fuel Line	
61200022	2017
612F1 - Fuel Pump	
62908-08	2008
613A1 - Trim Panel	
62775-08	2008
613B1 - Horn Cover	
61300523	2017
613C1 - Intake / Fuel Tank Cover	
61278-08A	2016
613D1 - Intake / Fuel Tank Cover Trim	
61313-88	1988
613L1 - Airbox Cover sub-component	
61300467	2017
61300501	2017
613M1 - Headlight Cover, Race	
61300096	2014
61300095	2014
614A1 - Headlight Bezel	
61400173	2015
61400198	2015
614C1 - Trim	

61400135	2014
62152-08	2008
61400077	2014
15341-08	2008
61400081	2014
61400080	2014
61400159	2014
61400057	2014
62153-08	2008
59211-74A	1974
61400063	2014
61400064	2014
62242-08	2008
62243-08	2008
62241-08	2008
624A1 - Oil Pump Assembly	
62400121	2017
62400124	2017
624B1 - Oil Pump Assembly sub-component	
62400052	2017
62400055	2017
26210-99	1999
62400125	2017
62400126	2017
62400132	2017
627A1 - Oil Cooler	
62700196	2017
627B1 - Oil Drain Plug	
62700150	2017

60328-98B	1998
627E1 - Oil Filler Plug / Dipstick	
62700136	2017
37065-06A	2017
627E2 - Sight Glass	
42854-06	2006
627F1 - Oil Filter	
63731-99A	1999
627G1 - Oil Jet	
62700117	2017
62700089	2017
627H1 - Oil Line	
62372-09	2009
62700143	2017
62700144	2017
627K1 - Oil Line Fitting	
26352-95A	1995
62700146	2017
627M1 - Oil Pressure Regulator Valve	
62700141	2017
628A1 - PT Lubrication and Cooling Miscellaneous Component	
62800028	2017
62800013	2013
62800004	2014
649A1 - Muffler	
64900238	2017
64900239	2017
64900235	2017
64900236	2017

64900237	2017
64900240	2017
651A1 - Muffler End-Cap / Outlet Finisher	
56250-10	2010
654A1 - Exhaust Shield	
62519-03	2003
65400176	2017
65400179	2017
65400177	2017
65400178	2017
655A1 - Muffler Mount	
65723-85	1985
65724-85A	2016
655B1 - Exhaust Mount Strap / Clamp	
65500042	2017
65500043	2017
655C1 - Exhaust Mounting Bracket	
66881-09	2009
656E1 - Header Pipe	
65600176	2017
65600177	2017
65600178	2017
659A1 - Exhaust Clamp	
65900015	2017
65900012	2014
659B1 - Exhaust Flange	
65328-83A	2010
660A1 - Battery	
66000066	2013
66010-97C	1997

66373-06	2006
660C1 - Battery Pan	
66000010	2014
660D1 - Battery Strap	
66051-08	2008
660E1 - Ground Strap	
75322-09	2009
660F1 - Negative Battery Cable	
66000116	2017
677A1 - Headlight	
67778-60A	1960
67700199	2015
67700060	2014
67700062	2014
67716-60C	2014
68725-62A	1962
67780-60A	1960
67700105	2014
67726-08	2008
677B1 - Headlight sub-component	
67717-01	2001
67700065	2014
67712-83B	2014
69200109	2014
677C1 - Headlight Support Bracket	
67700205	2014
67700204	2014
678A1 - Taillight	
68245-03	2003

68558-03	2003
68066-99A	2004
69187-03A	2003
68369-03	2003
68142-04	2004
68830-99A	1999
68296-99A	2004
68140-04	2004
68370-03A	2003
67800093	2014
68440-86	1986
67800101	2014
678B1 - Taillight Housing	
67800109	2014
72160-06	2006
678D1 - Turnsignal	
67800103	2014
67800299	2015
68550-09	2009
69293-06	2006
68767-94	1994
67800512	2015
67800513	2015
69292-06	2006
67800302	2015
67800303	2015
67800300	2015
67800301	2015
68766-94	1994
68765-94A	1994

73314-10	2010
68713-94A	1994
68997-09	2009
67800132	2014
67800147	2012
67800471	2015
68742-09	2009
67800148	2012
67800254	2014
68497-07	2007
68821-00	2000
67800104	2014
678E1 - Turnsignal Lens	
68973-00	2000
68506-92	1992
69378-09	2009
68559-07	2007
68505-90	1990
679B1 - Reflector	
69490-07	2007
60907-09	2009
59259-90	1990
59482-00	2000
59481-00	2000
60254-07	2007
67900256	2014
59988-72A	1972
67900066	2014
67900067	2014

67900068	2014
67900065	2014
679C1 - Reflector Mount Bracket / Holder	
67900120	2014
67900445	2017
679D1 - License Plate Bracket	
69380-09BHP	2009
73255-10	2010
67900213A	2015
60909-09	2009
60918-10A	2015
11687	Unknown
73254-10	2010
680A1 - Decorative Light	
53789-06	2006
69377-10	2010
69353-05	2005
68414-05A	2014
53788-06	2006
68721-62	1962
73309-10	2010
68846-09	2009
68720-62	1962
680C1 - Incandescent Bulb	
68572-64B	1964
68881-01	2001
68168-89A	1989
53436-97	1997
68000056	2012

68847-09	2009
68163-84	1984
68000038	2014
68167-04	2004
52441-95	1995
680D1 - Fog Light	
68000021	2014
68000020	2014
68000022	2014
68000037	2014
68000036	2014
690A1 - Emergency Siren	
68958-07C	2010
690B1 - Emergency Siren sub-component	
69309-10	2010
690C1 - Horn	
69060-90H	2014
690D1 - Horn Bracket	
69000083	2017
692B1 - Auxiliary Power Outlet	
69200826	2014
69200170	2014
69200171	2014
692C1 - Electrical Miscellaneous Component	
72232-96	1996
72299-95	1995
69200285	2014
72062-06	2006
69200840	2017
72189-04	2004

69200172	2014
69200174	2014
69200175	2014
68253-08A	2012
6990	2011
692C2 - Electrical Mounting Bracket	
69201178	2017
69201417	2017
70493-08	2008
71455-11	2011
69123-92A	1992
69200202A	2017
69201459	2016
69200202	2014
69200203A	2016
69120-91	1991
68519-68A	1968
69200257	2014
69200258	2014
69201287	2017
69200284A	2016
69062-91A	1991
67341-04B	2004
692D1 - Fuse	
69200293	2014
72330-95	1995
72345-02	2002
69200336	2014
72331-95	1995

692E1 - Fuse / Relay Block	
31586-07	2007
69200194	2014
69200312	2014
692E2 - Fuse / Relay Block Cover	
69201411	2017
692F1 - Wire Harness	
69201548	2017
69200128	2014
69200129	2014
69200127	2014
69200124	2014
69200125	2014
69200122	2015
69200121	2014
69200130	2014
69200139	2013
69200135	2014
69201017	2015
69200136	2014
69200138	2013
69200131	2014
69200032	2014
69200031	2014
69200294	2014
69200298	2014
69200211	2014
69200752	2015
69200753	2015
69201018A	2016

69200311	2014
69201119	2017
69200248	2014
69200247	2014
69200629	2015
69201120	2017
69200178	2014
69201123	2017
69200179	2014
69201124	2017
69201121	2017
69201122	2017
69201127	2017
69201125	2017
69201126	2017
69200224	2014
69200223	2014
69201130	2017
692G1 - Conduit / Sheathing / Sleeving	
72249-94	1994
70522-06B	2011
70554-69	1969
692G2 - Wire Guide	
69200702	2015
69200700	2015
69200701	2015
72412-97	1997
69200215	2014
72298-95	1995

692H1 - Connector	
72906-11	2011
76266-98A	2012
73152-96BK	1996
69201410	2017
69201414	2017
72632-10	2010
69201415	2017
72519-09BK	2009
69201400	2017
69201401	2017
69200271	2014
69200272	2014
69201405	2017
69201406	2017
72908-11	2011
72081-11	2011
69200193	2014
69200529	2012
72905-11	2011
72063-06	2006
69200212	2014
69201397	2017
72161-06	2006
72111-06	2006
69201441	2017
69201440	2017
72127-06	2006
72664-12A	2013

72098-06	2006
72444-07GY	2007
69200256	2014
72009-05	2005
69201302	2017
69200255	2014
69200254	2014
69201395	2017
69201394	2017
69201393	2017
69201390	2017
69200306	2014
69201299	2017
69200184	2014
72064-06	2006
69200183	2014
69200305	2014
73301-04	2004
72594-11	2011
69200220	2014
69200226	2014
72518-01	2001
72533-06	2006
69200225	2014
72575-11	2011
72130-04	2004
69200337	2014
72639-10	2010
72907-11	2011
692H2 - Terminal	

72296-95	1995
72343-10	2010
69201240	2014
72256-11	2011
72910-11	2011
72364-06	2006
72227-11	2011
69200187	2014
69200186	2014
72272-07	2007
72356-95	1995
69200536	2014
72909-11	2011
5118	2011
72608-08	2008
69201168	2016
72213-94	1994
72484-08	2008
72662-11	2012
72493-07	2007
72226-11	2011
72308-97	1997
72344-10	2010
72721-07	2007
72290-94	1994
72222-11	2011
72169-07	2007
72242-94	1994
72168-07	2007

72291-94	1994
69201300	2017
73307-10	2010
72294-94	1994
72241-94A	1994
69200307	2014
69200185	2014
69200237	2014
69200238	2011
69200308	2014
69200221	2014
72666-12	2012
72991-01	2001
74190-98	1998
74194-98	1998
72283-09	2009
72569-08	2008
692K1 - Connector / Terminal Seal	
69201412	2017
69201416	2017
68904-00	2000
69201404	2017
69201407	2017
69201162	2016
69201163	2016
69201164	2016
73303-04	2004
72912-01BK	2001
69201396	2017
69201398	2017

72039-71A	1971
69201442	2017
72449-01	2001
69201301	2017
74197-04	2004
68905-00	2000
69201392	2017
69201391	2017
72450-01	2001
692L1 - Wire Harness sub-component	
74191-98	1998
72606-08	2008
73213-07	2007
70345-84	1984
72512-07BK	2007
72488-07BK	2007
75229-08	2008
74152-98	1998
72195-94	1994
72415-07GY	2007
72099-06	2006
69200189	2014
72633-02	2002
69200188	2014
72175-07BK	2007
72902-01BK	2001
72473-07	2007
72214-94	1994
73190-96	1996

72511-07BK	2007
69200190	2014
69200191	2014
69200199	2014
72177-07BK	2007
73101-96BK	1996
73156-96BK	1996
69200295	2014
73106-96BK	1996
72904-01BK	2001
72479-07BK	2007
73152-96WE	1996
72499-07	2007
69200214	2014
69200210	2014
72145-06	2006
69200205	2014
72557-07	2007
72486-08	2008
69200201	2014
72167-07BK	2007
72166-07BK	2007
73153-96BK	1996
72478-07BK	2007
72720-07	2007
72038-71A	1971
70494-08	2008
69200631	2014
69200630	2014

72589-09	2009
69201307	2017
70681-09	2009
72106-94BK	1994
72053-92	1992
72405-98BK	1998
72066-06A	2006
73191-96	1996
72065-06A	2006
69200313	2014
72146-94	1994
72489-07GY	2007
72190-94	1994
72010-05	2005
72609-08	2008
72188-07BK	2007
72543-07BK	2007
73104-96BK	1996
73305-04	2004
72607-08	2008
72544-07	2007
72209-11	2011
73102-96BK	1996
72485-07	2007
69200222	2014
72295-94	1994
70631-08	2008
72490-07GY	2007
72494-07	2007
74112-98BK	1998

69201423	2017
73154-96BK	1996
72414-07BK	2007
72135-06	2006
72914-01BK	2001
72610-08	2008
692M1 - Electrical Component / Wire Cover	
69201286	2017
692N1 - Engine Harness Support	
69200173	2014
709A1 - Dash Panel	
70900138	2014
70900392DH	2014
70900392BYM	2014
709B1 - Instrument Cluster or Speedometer	
70900125A	2017
70900122A	2017
70900121B	2017
70900124B	2017
70900123A	2017
70900167B	2017
70900168A	2017
70900120A	2017
70900169A	2017
70900118B	2017
70900119A	2017
70900373	2015
70900372	2015
70900374	2015

70900126A	2017
709B2 - Fuel Gauge	
70900163	2014
70900164	2014
70900161	2014
70900162	2014
70900166	2014
70900165	2014
75241-08	2008
709E1 - Tank Console	
61270-08	2008
70900117	2014
69214-08	2008
714A1 - Ignition Switch	
71400011A	2016
71400073	2012
71400012A	2016
71400081	2014
71400017A	2016
71400015A	2016
71400016A	2016
71400010A	2016
71517-11	2011
71400013A	2016
714B1 - Mechanical Switch	
71565-08	2008
71522-08	2008
33926-06B	2006
71400031	2014
71400044	2014

71400005	2014
71400006	2014
71400007	2014
714C1 - Pressure Switch	
71400112	2017
715A1 - Hand Control	
71500045	2014
71500046	2014
71500044	2014
71500049	2014
71500047	2014
71500048	2014
71500342	2016
71500340	2016
71500348	2016
56249-10	2010
71500094	2014
71500129B	2016
71500063	2014
67493-08	2008
71500128A	2016
71500057	2014
71500055	2014
71500053	2014
71500050	2014
71500127B	2016
71500419	2017
56209-10	2010
71500338	2016

747A1 - Voltage Regulator	
74700025	2017
72350-11	2011
760B1 - Antenna	
76503-08	2008
68956-07	2007
76000183	2014
76000186	2014
76000164	2014
76000165	2014
76353-00	2000
76000208	2014
76335-87	1987
76000222	2014
760C2 - Audio System Speaker	
76000454	2015
76000455	2015
76000453	2015
76000456	2015
76000055	2014
76000096	2014
76000092	2014
760C3 - Radio Receiver	
76000076B	2017
76000076A	2016
76000231A	2016
76000231B	2017
76000230B	2017
76000232A	2016

76000232B	2017
76000075B	2017
76000075A	2016
760C4 - Rider-Passenger Communication System	
77117-10	2010
76000243	2013
77148-10	2010
77126-10	2010
760C5 - Speaker Enclosure	
76000458	2015
76000460	2015
76000160	2014
76000161	2014
760C6 - Media Storage Compartment	
76000234	2014
76000409DH	2014
76000376BYM	2015
76000373	2015
76000374	2015
76000370	2015
76000376DH	2015
76000436	2015
76000422	2015
76000425	2015
76000127	2014
76000409BYM	2014
76000107	2014
76000426BYM	2015
76000426DH	2015
76000398	2015

760C8 - Satellite Radio	
76000252	2014
760D1 - Infotainment Mount	
76000468	2015
760D2 - Infotainment Mount sub-component	
76000177	2014
76000173	2014
76000174	2014
76000172	2014
902A1 - Saddlebag	
90200983DZP	2017
90200984DZP	2017
90200685	2014
90200684	2014
902B1 - Saddlebag Cover	
90200411	2014
90200413	2014
902C1 - Saddlebag Inner	
90200488	2014
90200489	2014
902E1 - Saddlebag Bottom	
90200983DZW	2016
90200984BYM	2014
90200983DZT	2016
90200983DZS	2016
90200984DZN	2016
90200984DWC	2015
90200412	2014
90200983DH	2014

90200414	2014
90200415	2014
90200519	2014
90200522	2014
90200521	2014
90200520	2014
90200984DZS	2016
90200984DZT	2016
90200984DZW	2016
90200550	2014
90200549	2014
90200547	2014
90200543	2014
90200467	2014
90200611	2014
90200501	2014
90200505	2014
90200504	2014
90200983DZN	2016
90200983BYM	2014
90200899	2014
90201296	2015
90201295	2015
90200983DWC	2015
90200984DH	2014
90200900	2014
90200901	2014
90200499	2014
90200903	2014
90200902	2014

90200905	2014
75089-08	2008
902F1 - Saddlebag Guard	
90200506	2014
90200507	2014
902Z1 - Kit,Saddlebag	
90201540	2017
903A1 - Lockset	
61029-92A	1992
90300030	2014
90300024	2014
903B1 - Key or Key-set	
61081-92	1992
90300093	2014
903C1 - Key Transponder	
90300111	2017
90300112	2017
917B1 - Service Program Kit	
91700034	2014
90482-10	2010
91700025A	2014
90439-10	2010
918B1 - Hardware Kit	
91800064	2017
91800058	2017
940A1 - Owner's Kit	
99517-17EN	2017
94000326	2016
940A2 - Owner's Manual	

99466-17	2017
99461-89	1989
940H1 - Electronic / Digital Media	
94000084	2014

Common Service Parts

BEARINGS, SEALS & HARDWARE

Part No.	Description	Part and Model(s)
10080	CLAMP	<i>COOLANT DISTRIBUTION, AIR-COOLED:</i> FLHR FLHTCU FLHRC FLHX FLHXS FLTRX FLTRXS
1062	SCREW	PRIMARY HOUSING: All Models BRAKE LINES AND MODULE, REAR - ABS: All Models <i>FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2):</i> FLTRX FLTRXS FLTRU
10900015	STUD	CYLINDERS, HEADS AND VALVES: All Models EXHAUST SYSTEM: All Models
11000101	OIL SEAL	SHIFTER, GEAR: All Models TRANSMISSION BEARINGS AND COVERS: All Models
11105	O-RING	TRANSMISSION HOUSING, TOP COVER AND OIL PAN: All Models PRIMARY HOUSING: All Models
11132A	O-RING	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models TRANSMISSION BEARINGS AND COVERS: All Models
11143	RETAINING RING	CLUTCH: All Models
11145A	O-RING	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models
11150	RETAINING RING	SHIFTER, GEAR: All Models
11293	O-RING	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models CAMSHAFTS AND CAMSHAFT COVER: All Models
11304	RING	<i>FOOTBOARDS AND FOOTPEGS, PASSENGER:</i> FLHX FLHXS FLTRX FLTRXS FLHTKL

11900103	O-RING	CAMSHAFTS AND CAMSHAFT COVER: All Models
12052A	SEAL	PRIMARY HOUSING: All Models
12074	SEAL	TRANSMISSION BEARINGS AND COVERS: All Models
17369-06	GASKET SERVICE KIT	PRIMARY HOUSING: All Models
2445	SCREW	WINDSHIELD, FAIRING AND HEADLAMP - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 2): FLHTCU FLHX FLHTK FLHTKL FLHXS FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3): FLHTCU FLHX FLHTK FLHTKL FLHXS
2446	SCREW	LICENSE PLATE BRACKETS: FLHX FLHXS FLTRX FLTRXS LICENSE PLATE BRACKETS: FLHTK FLHTKL FLTRU
2531	SCREW	FENDERS, FRONT: FLHR FLHTCU FLHRC FLHTK FLHTKL
2563	SCREW	INSTRUMENTS - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS: FLHTCU FLHX FLHTK FLHTKL FLHXS INSTRUMENTS - FLTRU, FLTRX AND FLTRXS: FLTRX FLTRXS FLTRU WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2): FLTRX FLTRXS FLTRU FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3): FLHX FLHXS FAIRING, INNER - FLHTCU, FLHTK, FLHTKL, FLHX AND FLHXS (1 OF 3):

		3): FLHTCU FLHTK FLHTKL FAIRING, INNER - FLTRU, FLTRX AND FLTRXS (1 OF 2): FLTRX FLTRXS FLTRU
25700362	GASKET	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models
25700370	GASKET	CAMSHAFTS AND CAMSHAFT COVER: All Models
25700372	GASKET	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models
25700378	GASKET	PRIMARY HOUSING: All Models
25700425	GASKET	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models
25700453	GASKET	TRANSMISSION HOUSING, TOP COVER AND OIL PAN: All Models
25700455	GASKET	PRIMARY HOUSING: All Models
25700731	GASKET KIT	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models CAMSHAFTS AND CAMSHAFT COVER: All Models
25700746	GASKET KIT	PRIMARY HOUSING: All Models
27300087	SEAL	INDUCTION MODULE, FUEL: All Models
27444-00Y	O-RING	STARTER MOTOR: All Models
2952A	SCREW	SEATS: All Models
2995	SCREW	FENDERS, REAR (1 OF 2): FLHX FLHXS FLTRX FLTRXS FAIRING LOWERS, AIR COOLED - FLHTCU: FLHTCU
3050	SCREW	ALTERNATOR AND REGULATOR: All Models
3275	SCREW	INDUCTION MODULE, FUEL: All Models SENSORS AND SWITCHES, ENGINE: All Models SHIFTER, GEAR: All Models
34091-08	BEARING	TRANSMISSION GEARS: All Models
35654-06	GASKET	TRANSMISSION BEARINGS AND COVERS: All Models
3655A	SCREW	WHEELS, FRONT: FLHRC FAIRING LOWERS, AIR COOLED - FLHTCU: FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU: FLHTK FLHTKL

		FLTRU
3656	SCREW	<i>SADDLEBAGS (1 OF 2):</i> FLHR FLHTCU FLHX FLHTK FLTRX FLHTKL FLHXS FLTRXS FLTRU
36805-06	GASKET	TRANSMISSION BEARINGS AND COVERS: All Models
4132	SCREW	CLUTCH CONTROL: All Models BRAKE CONTROL, FRONT: All Models
41751-06A	GASKET	CLUTCH CONTROL: All Models BRAKE CONTROL, FRONT: All Models <i>BRAKE LINE, FRONT - NON-ABS:</i> FLHR FLHX FLTRX BRAKE LINES, FRONT - ABS: All Models <i>BRAKE CONTROL, REAR:</i> FLHR FLHX FLTRX BRAKE CONTROL, REAR: All Models BRAKE LINES AND MODULE, REAR - ABS: All Models
43567-92	SCREW	WHEELS, REAR: All Models
4740A	SCREW	CAMSHAFTS AND CAMSHAFT COVER: All Models
5210	WELL NUT	<i>NACELLE AND HEADLAMP - FLHR AND FLHRC:</i> FLHR FLHRC <i>LAMPS AND SPEAKER HOUSINGS, ULTRA TOUR-PAK (1 OF 2):</i> FLHTCU FLHTK FLHTKL FLTRU
59768-97	SEAT NUT KIT	SEATS: All Models
6054	WASHER	<i>WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2):</i> FLTRX FLTRXS <i>LOOSE PARTS (2 OF 3):</i> FLTRX FLTRXS
60678-85	RETAINING RING	PRIMARY HOUSING: All Models
65324-83B	GASKET	EXHAUST SYSTEM: All Models
65325-83A	RETAINING RING	EXHAUST SYSTEM: All Models

6702	WASHER	FRAME AND JIFFY STAND: All Models
7041	LOCKWASHER	FRAME AND JIFFY STAND: All Models AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL: FLHTCU FLHTK FLHTKL EXHAUST SYSTEM: All Models
7586	JAMNUT	TOUR-PAK (BOTTOM): FLHTCU FLHTK FLHTKL FLTRU SADDLEBAGS (1 OF 2): FLHR FLHTCU FLHX FLHTK FLTRX FLHTKL FLHXS FLTRXS FLTRU
7593	NUT	EXHAUST SYSTEM: All Models
7600	NUT	FENDERS, FRONT: FLHR FLHTCU FLHRC FLHTK FLHTKL
7716	LOCKNUT	RADIATOR, COOLANT HOSES AND BOTTLE, TWIN-COOLED™: FLHTK FLTRU FLHTKL FOOTBOARDS, OPERATOR: All Models FAIRING LOWERS, AIR COOLED - FLHTCU: FLHTCU FAIRING LOWERS, TWIN-COOLED™ - FLHTK, FLHTKL AND FLTRU: FLHTK FLHTKL FLTRU TOUR-PAK (BOTTOM): FLHTCU FLHTK FLHTKL FLTRU
786A	BOLT	PRIMARY HOUSING: All Models
856A	SCREW	SHIFTER, GEAR: All Models
9252	BALL BEARING	WHEELS, FRONT: All Models WHEELS, REAR: All Models

9276A	BALL BEARING	BELT, CHAINS AND SPROCKETS: All Models <i>WHEELS, FRONT:</i> FLHR FLHX FLTRX WHEELS, FRONT: All Models WHEELS, REAR: All Models <i>WHEELS, REAR:</i> FLHR FLHX FLTRX
933	SCREW	<i>WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2):</i> FLTRX FLTRXS <i>LOOSE PARTS (2 OF 3):</i> FLTRX FLTRXS
9955	CLAMP	EXHAUST SYSTEM: All Models

BRAKING & SUSPENSION

Part No.	Description	Part and Model(s)
41852-08B	PAD AND PIN KIT	BRAKE CALIPER, REAR: All Models
41854-08	PAD AND PIN KIT	BRAKE CALIPER, FRONT: All Models
46514-01A	OIL SEAL	<i>FORK, FRONT, LEFT AND RIGHT - STANDARD:</i> FLHR FLHTCU FLHRC FLHX FLHTK FLTRX FLHXS FLTRXS FLTRU <i>FORK, FRONT, LEFT AND RIGHT - LOW:</i> FLHTKL
46615-06	PACKING SEAL	<i>FORK, FRONT, LEFT AND RIGHT - STANDARD:</i> FLHR FLHTCU FLHRC FLHX FLHTK FLTRX FLHXS FLTRXS FLTRU <i>FORK, FRONT, LEFT AND RIGHT - LOW:</i> FLHTKL

CHASSIS & COMPONENTS

Part No.	Description	Part and Model(s)
49725-07A	SPRING	<i>FRAME AND JIFFY STAND: All Models</i>
50245-07	BUMPER	<i>FRAME AND JIFFY STAND: All Models</i>

DECORATIVE & TRIM

Part No.	Description	Part and Model(s)
61274-92	FUEL FILLER CAP	<i>CONSOLE, FUEL TANK - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS (1 OF 2):</i> FLHTCU FLHX FLHTK FLHXS FLTRXS FLHTKL FLTRX FLTRU

ELECTRICAL

Part No.	Description	Part and Model(s)
29900042	STATOR ASSEMBLY	<i>ALTERNATOR AND REGULATOR: All Models</i>
70345-84	RETAINER	<i>HANDLEBAR:</i> FLHR FLHRC
72023-51E	KIT SWITCH	<i>BRAKE CONTROL, REAR: All Models</i> <i>SWITCHES: All Models</i>
72330-95	FUSE	<i>WIRING HARNESS, MAIN, NON-ABS - FLHX (8 OF 8):</i> FLHX <i>WIRING HARNESS, MAIN, ABS - FLHX AND FLHXS (8 OF 8):</i> FLHX FLHXS <i>WIRING HARNESS, MAIN, ABS - FLHTCU (8 OF 8):</i> FLHTCU <i>WIRING HARNESS, MAIN, ABS - FLHTK AND FLHTKL (8 OF 8):</i> FLHTK FLHTKL <i>WIRING HARNESS, MAIN, NON-ABS - FLHR (8 OF 8):</i> FLHR <i>WIRING HARNESS, MAIN, ABS - FLHR AND FLHRC (8 OF 8):</i> FLHR FLHRC <i>WIRING HARNESS, MAIN, NON-ABS - FLTRX (8 OF 8):</i> FLTRX <i>WIRING HARNESS, MAIN, ABS - FLTRX AND FLTRXS (8 OF 8):</i> FLTRX FLTRXS

ENGINE, TRANSMISSION & PRIMARY

Part No.	Description	Part and Model(s)
18538-99C	HYDRAULIC LIFTER	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models
29400183	BREATHER ASSEMBLY	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models
29400210	BREATHER ASSEMBLY	ROCKER ARM ASSEMBLY AND PUSHRODS: All Models
33600091	SHAFT	SHIFTER, GEAR: All Models
37000258	CLUTCH DISKS KIT	CLUTCH: All Models
37909-90	RING	CLUTCH: All Models

FOOT CONTROLS

Part No.	Description	Part and Model(s)
33895-82D	SHIFT LEVER KIT	SHIFTER, GEAR: All Models
34611-65A	TOE SHIFTER PEG KIT	SHIFTER, GEAR: All Models

INTAKE, EXHAUST & FUEL MGMT

Part No.	Description	Part and Model(s)
61011-04A	FUEL FILTER KIT	FUEL PUMP - FLHTCU, FLHTK, FLHTKL, FLHX, FLHXS, FLTRU, FLTRX AND FLTRXS: FLHTCU FLHX FLHTK FLHXS FLTRXS FLHTKL FLTRX FLTRU FUEL PUMP - FLHR AND FLHRC: FLHR FLHRC
65900012	CLAMP	EXHAUST SYSTEM: All Models
65900015	CLAMP	EXHAUST SYSTEM: All Models

LIGHTING

Part No.	Description	Part and Model(s)

68000056	BULB	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC: FLHR FLHRC
68168-89A	BULB	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC: FLHR AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL: FLHTCU FLHTK FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS: FLHX FLHXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2): FLTRX FLTRXS FLTRU TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2): FLHX FLHXS FLTRX FLTRXS
68572-64B	BULB	TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2): FLHR TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2): FLHX FLHXS FLTRX FLTRXS
68973-00	LENS	AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHTCU, FTHTK AND FLHTKL: FLHTCU FLHTK FLHTKL TURN SIGNALS, FRONT - FLHX AND FLHXS: FLHX FLHXS WINDSHIELD, FAIRING AND HEADLAMP - FLTRU, FLTRX AND FLTRXS (1 OF 2): FLTRX FLTRXS FLTRU TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2): FLHX FLHXS FLTRX FLTRXS TAIL LAMP AND TURN SIGNALS, REAR (1 OF 2): FLHTK FLHTKL FLTRU

MAINTENANCE & TOOLS

Part No.	Description	Part and Model(s)
63731-99A	OIL FILTER	CRANKCASE AND ENGINE OIL FILTER: All Models
66010-97C	BATTERY	BATTERY: All Models
66373-06	BATTERY	SWITCHES: All Models
95594-84B	WEIGHT	<i>WHEELS, FRONT:</i> FLHR FLHTCU FLHX FLHTK FLHXS FLTRX FLTRXS <i>WHEELS, REAR:</i> FLHR FLHTCU FLHX FLHTK FLHXS FLHTKL FLTRX FLTRXS FLTRU
95595-84B	WEIGHT	<i>WHEELS, FRONT:</i> FLHRC <i>WHEELS, REAR:</i> FLHRC

SECURITY & STORAGE

Part No.	Description	Part and Model(s)
90300111	REMOTE CONTROL FOB	SWITCHES: All Models LOOSE PARTS (1 OF 3): All Models

TIRES

Part No.	Description	Part and Model(s)
40558-82	INNER TUBE	<i>WHEELS, FRONT:</i> FLHRC
40999-87	VALVE STEM	<i>WHEELS, FRONT:</i> FLHR FLHTCU FLHX FLHTK FLHTKL FLHXS FLTRX

		FLTRXS FLTRU <i>WHEELS, REAR:</i> FLHR FLHTCU FLHX FLHTK FLHXS FLTRX FLTRXS FLTRU
43109-09A	TIRE	<i>WHEELS, FRONT:</i> FLHR FLHTCU FLHTK FLHTKL FLTRU
43118-92A	TIRE	<i>WHEELS, FRONT:</i> FLHRC
43147-40	RIM STRIP	<i>WHEELS, FRONT:</i> FLHRC
43200027	TIRE	<i>WHEELS, REAR:</i> FLHR FLHTCU FLHX FLHTK FLHXS FLTRX FLTRXS FLTRU

WINDSHIELDS & AIR DEFLECTORS

Part No.	Description	Part and Model(s)
67621-94	BUSHING	<i>AUXILIARY/FOG LAMPS AND TURN SIGNALS, FRONT - FLHR AND FLHRC:</i> FLHR FLHRC <i>WINDSHIELD - FLHR AND FLHRC:</i> FLHR FLHRC